



DEEP SEA ELECTRONICS

DSE7410 MKII & DSE7420 MKII

Configuration Suite PC Software Manual

Document Number: 057-262

Author: Bedig Boghossian



Deep Sea Electronics Ltd.

Highfield House
Hunmanby
North Yorkshire
YO14 0PH
England

Sales Tel: +44 (0) 1723 890099

E-mail: sales@deepseaelectronics.com

Website: www.deepseaelectronics.com

DSE7410 MKII & DSE7420 MKII Configuration Suite PC Software Manual

© Deep Sea Electronics Ltd.

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication must be addressed to Deep Sea Electronics Ltd. at the address above.

The DSE logo and the names DSEGenSet®, DSEATS®, DSEPower® and DSEControl® are UK registered trademarks of Deep Sea Electronics Ltd.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Ltd. reserves the right to change the contents of this document without prior notice.

Amendments Since Last Publication

Issue	Comments
1	Initial release
2	Add support for the DSE25xx MKII Remote Display Module
3	Add support for the 2510/2520 Display Modules on the expansion port, Filter Voltage feature added
4	Updated to version 4 of the module, added Fuel Tank Bund High Level & Water in Fuel alarm inputs, Screensaver, Low Load, WebScada over the Ethernet, Override Gencomm Instruments in the PLC, PLC Module Display, and more...
5	Updated to version 5 of the module, adding Check Sync, communications with CAN AVRs, CAN Icon Instruments, additional DSE25xx MKII support from Expansion, ECU Specific and Escape Mode functions.
6	Updated to version 6 of the module introduction separate AC system support for mains & generator (applicable on DSE7420 MKII only), Accumulated Instrumentation Lock, Governor Gain & Frequency Adjust from the Scada, RS485 Stop Bits & Parity selection, SysName OID in Trap Messages, and more...
7	Updated to version 7.0 of the module, added Power Up in Mode in Miscellaneous Options, MPU Fail Delay in start timers, and a major re-design of the configurable CAN instruments.
8	Terminology changes from master/slave to client/server.
9	Added Auto Voltage Sensing

Typeface: The typeface used in this document is *Arial*. Care must be taken not to mistake the upper-case letter I with the numeral 1. The numeral 1 has a top serif to avoid this confusion.

TABLE OF CONTENTS

Section	Page
1 INTRODUCTION.....	6
1.1 BIBLIOGRAPHY	6
1.1.1 INSTALLATION INSTRUCTIONS	6
1.1.2 MANUALS	6
1.1.3 OTHER	6
1.1.4 CLARIFICATION OF NOTATION	7
1.1.5 GLOSSARY OF TERMS	7
1.2 INSTALLATION AND USING THE DSE CONFIGURATION SUITE SOFTWARE	8
2 EDITING THE CONFIGURATION	9
2.1 SCREEN LAYOUT	9
2.2 MODULE	10
2.2.1 MODULE OPTIONS	10
2.2.2 MISCELLANEOUS OPTIONS.....	12
2.2.3 CONFIGURABLE FRONT PANEL EDITOR	15
2.2.4 DISPLAY CONFIGURATION	16
2.2.5 USER DEFINED STRINGS.....	19
2.2.6 EVENT LOG	20
2.2.7 DATA LOGGING	23
2.3 APPLICATION	27
2.4 INPUTS.....	34
2.4.1 ANALOGUE INPUT CONFIGURATION	34
2.4.2 FLEXIBLE SENSOR E & F	35
2.4.3 EDITING THE SENSOR CURVE	37
2.4.4 DIGITAL INPUTS	38
2.4.5 ANALOGUE INPUTS	40
2.4.6 INPUT FUNCTIONS.....	41
2.5 OUTPUTS.....	46
2.5.1 DIGITAL OUTPUTS	46
2.5.2 VIRTUAL LEDS	47
2.5.3 OUTPUT SOURCES.....	48
2.6 TIMERS	58
2.6.1 START TIMERS	58
2.6.2 LOAD / STOPPING TIMERS	61
2.6.3 MODULE TIMERS	62
2.7 GENERATOR.....	63
2.7.1 GENERATOR OPTIONS	63
2.7.2 GENERATOR VOLTAGE.....	66
2.7.3 GENERATOR FREQUENCY	68
2.7.4 GENERATOR CURRENT	71
2.7.5 GENERATOR POWER	83
2.7.6 AVR	86
2.8 MAINS	87
2.8.1 MAINS OPTIONS.....	87
2.8.2 MAINS ALARMS	90
2.8.3 MAINS CURRENT	91
2.9 ENGINE.....	92
2.9.1 ENGINE OPTIONS	93
2.9.2 ECU (ECM).....	95
2.9.3 OIL PRESSURE	109
2.9.4 COOLANT TEMPERATURE.....	110
2.9.5 FUEL OPTIONS	113
2.9.6 DEF LEVEL	123
2.9.7 GAS ENGINE OPTIONS	124
2.9.8 CRANKING.....	125
2.9.9 SPEED SENSING	127

2.9.10	SPEED SETTINGS	128
2.9.11	PLANT BATTERY	130
2.9.12	ENGINE ICON DISPLAYS	131
2.10	COMMUNICATIONS	135
2.10.1	COMMUNICATION OPTIONS	135
2.10.2	RS232 PORT	136
2.10.3	RS485 PORT	143
2.10.4	REMOTE DISPLAY	145
2.10.5	ETHERNET PORT	146
2.10.6	CAN PORTS	150
2.10.7	SNMP	151
2.11	SCHEDULER	154
2.11.1	SCHEDULER OPTIONS	154
2.11.2	BANK 1 / BANK 2	155
2.12	MAINTENANCE ALARM	156
2.13	CONFIGURABLE CAN INSTRUMENTATION	157
2.13.1	RECEIVED INSTRUMENTATION (1-30)	157
2.13.2	TRANSMITTED INSTRUMENTATION	162
2.14	ALTERNATIVE CONFIGURATIONS	165
2.14.1	ALTERNATIVE CONFIGURATION OPTIONS	165
2.14.2	ALTERNATIVE CONFIGURATION 1 TO 5	166
2.15	EXPANSION	167
2.15.1	2130 INPUT MODULES	168
2.15.2	DSE2131 INPUT MODULES	175
2.15.3	DSE2133 INPUT MODULES	182
2.15.4	DSE2152 OUTPUT MODULES	186
2.15.5	DSE2157 RELAY MODULES	190
2.15.6	2510/2520 DISPLAY MODULE	191
2.15.7	2510/2520 MKII DISPLAY MODULES	192
2.15.8	2548 ANNUNCIATOR MODULES	193
2.15.9	BATTERY CHARGERS	195
2.16	ADVANCED	196
2.16.1	ADVANCED OPTIONS	196
2.16.2	PLC	202
2.16.3	CONFIGURABLE GENCOMM PAGES	204
3	SCADA	206
3.1	GENERATOR IDENTITY	207
3.2	MIMIC	207
3.3	DIGITAL INPUTS	208
3.4	DIGITAL OUTPUTS	209
3.5	VIRTUAL LEDS	210
3.6	MAINS	211
3.6.1	FREQUENCY, VOLTAGES AND CURRENT	211
3.6.2	POWER	212
3.7	GENERATOR	213
3.7.1	FREQUENCY, VOLTAGES AND CURRENT	213
3.7.2	POWER	214
3.7.3	MULTISET	215
3.8	ENGINE	216
3.9	FUEL USE AND EFFICIENCY	217
3.10	FLEXIBLE SENSOR	218
3.10.1	FLEXIBLE SENSOR A - C	218
3.10.2	FLEXIBLE SENSOR D - F	218
3.11	CONFIGURABLE CAN INSTRUMENTATION	219
3.12	ALARMS	220
3.13	ENGINE ALARMS	221
3.13.1	CURRENT ENGINE ALARMS	221
3.13.2	PREVIOUS ENGINE ALARMS	221
3.14	STATUS	222
3.15	EVENT LOG	223

3.16	ENHANCED CANBUS	224
3.17	REMOTE CONTROL	225
3.18	MAINTENANCE.....	226
3.18.1	RECALIBRATE TRANSDUCERS	226
3.18.2	EXPANSION CALIBRATION	230
3.18.3	HOURS RUN AND NUMBER OF STARTS	230
3.18.4	TIME	231
3.18.5	ACCUMULATED INSTRUMENTATION	232
3.18.6	FUEL USE AND EFFICIENCY.....	234
3.18.7	MAINTENANCE ALARM RESET	235
3.18.8	ELECTRONIC ENGINE CONTROLS	236
3.18.9	MANUAL SPEED TRIM	237
3.18.10	MODULE LOCK.....	238
3.19	COMMUNICATIONS INFORMATION.....	240
3.20	DATA LOG	241
3.20.1	DATA LOG STATUS	241
3.21.1	PLC LOGIC	242
3.21.2	PLC SOTRES	242
3.22	AVR.....	243
3.22.1	FREQUENCY, VOLTAGES AND CURRENT	243
3.22.2	DIAGNOSTICS.....	244
3.22.3	STATUS	245
3.22.4	CONTROL.....	245
3.22.5	AVR ALARMS	245
3.23	EXPANSION	246
4	ALARM TYPES.....	247
5	ALARM ARMING.....	248
5.1	NEVER	249
5.2	ALWAYS	249
5.3	WHEN STATIONARY	249
5.4	WAIT FOR ECU	249
5.5	FROM STARTING.....	249
5.6	ENGINE PROTECTION	249
5.7	FROM SAFETY ON.....	249
5.8	OVERSHOOT	250
5.9	LOADING ALARMS.....	250

1 INTRODUCTION

The **DSE Configuration Suite PC Software** allows the DSE74xx MKII modules to be connected to a PC via USB A –USB B cable. Once connected the various operating parameters within the module are viewed or edited as required by the engineer. This software allows easy controlled access to these values.

This manual details the configuration of the DSE7410 MKII & DSE7420 MKII series controllers.

A separate document covers the older DSE7410 and DSE7420 modules configuration.

The DSE Configuration Suite PC Software must only be used by competent, qualified personnel, as changes to the operation of the module may have safety implications on the panel / generating set to which it is fitted. Access to critical operational sequences and settings for use by qualified engineers, may be barred by a security code set by the generator provider.

The information contained in this manual must be read in conjunction with the information contained in the appropriate module documentation. This manual only details which settings are available and how they may be used. A separate manual deal with the operation of the individual module (See section entitled *Bibliography* elsewhere in this document).

1.1 BIBLIOGRAPHY

This document refers to and is referred to by the following DSE publications which is obtained from the DSE website www.deepseaelectronics.com .

1.1.1 INSTALLATION INSTRUCTIONS

DSE PART	DESCRIPTION
053-191	DSE7410 MKII & DSE7420 MKII Installation Instructions

1.1.2 MANUALS

DSE PART	DESCRIPTION
057-151	DSE Configuration Suite PC Software Installation & Operation Manual
057-004	Electronic Engines and DSE wiring
057-263	DSE7410 MKII & DSE7420 MKII Operator Manual
057-278	DSE2510 MKII & DSE2520 MKII Operator Manual
057-279	DSE2510 MKII & DSE2520 MKII Software Manual
057-281	DSEA108 Operator Manual
057-283	DSEA108 Software Manual




1.1.3 OTHER

The following third party documents are also referred to:

ISBN	DESCRIPTION
1-55937-879-4	IEEE Std C37.2-1996 IEEE Standard Electrical Power System Device Function Numbers and Contact Designations. Published by Institute of Electrical and Electronics Engineers Inc

1.1.4 CLARIFICATION OF NOTATION

Clarification of notation used within this publication.

	NOTE:	Highlights an essential element of a procedure to ensure correctness.
	CAUTION!	Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.
	WARNING!	Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.

1.1.5 GLOSSARY OF TERMS

Term	Description
DSE7400 MKII, DSE74xx MKII	All modules in the DSE74xx MKII range.
DSE7410 MKII	DSE7410 MKII module/controller
DSE7420 MKII	DSE7420 MKII module/controller
DSE2510 MKII	DSE2510 MKII remote display module
DSE2520 MKII	DSE2520 MKII remote display module
DSE2500 MKII, DSE25xx MKII	DSE25xx MKII range remote display modules.
CAN	Controller Area Network Vehicle standard to allow digital devices to communicate to one another.
CDMA	Code Division Multiple Access. Cell phone access used in small number of world areas including parts of the USA and Australia.
CT	Current Transformer An electrical device that takes a large AC current and scales it down by a fixed ratio to a smaller scale.
BMS	Building Management System A digital/computer-based control system for a building's infrastructure.
DEF	Diesel Exhaust Fluid (AdBlue) A liquid used as a consumable in the SCR process to lower nitric oxide and nitrogen dioxide concentration in engine exhaust emissions.
DM1	Diagnostic Message 1 A DTC that is currently active on the engine ECU (ECM).
DM2	Diagnostic Message 2 A DTC that was previously active on the engine ECU (ECM) and has been stored in the ECU's (ECM) internal memory.
DPF	Diesel Particulate Filter A filter fitted to the exhaust of an engine to remove diesel particulate matter or soot from the exhaust gas.
DPTC	Diesel Particulate Temperature Controlled Filter A filter fitted to the exhaust of an engine to remove diesel particulate matter or soot from the exhaust gas which is temperature controlled.
DTC	Diagnostic Trouble Code The name for the entire fault code sent by an engine ECU (ECM).
ECU/ECM	Engine Control Unit/Management An electronic device that monitors engine parameters and regulates the fuelling.
FMI	Failure Mode Indicator A part of DTC that indicates the type of failure, e.g. high, low, open circuit etc.

Continued over page...

Term	Description
GSM	Global System for Mobile communications. Cell phone technology used in most of the World.
HEST	High Exhaust System Temperature Initiates when DPF filter is full in conjunction with an extra fuel injector in the exhaust system to burn off accumulated diesel particulate matter or soot.
HMI	Human Machine Interface A device that provides a control and visualisation interface between a human and a process or machine.
IDMT	Inverse Definite Minimum Time
MSC	Multi-Set Communication
OC	Occurrence Count A part of DTC that indicates the number of times that failure has occurred.
PGN	Parameter Group Number A CAN address for a set of parameters that relate to the same topic and share the same transmission rate.
PLC	Programmable Logic Controller A programmable digital device used to create logic for a specific purpose.
SCADA	Supervisory Control And Data Acquisition A system that operates with coded signals over communication channels to provide control and monitoring of remote equipment
SCR	Selective Catalytic Reduction A process that uses DEF with the aid of a catalyst to convert nitric oxide and nitrogen dioxide into nitrogen and water to reduce engine exhaust emission.
SIM	Subscriber Identity Module. The small card supplied by the GSM/CDMA provider that is inserted into the cell phone, GSM modem or DSEGateway device to give GSM/GPRS connection.
SMS	Short Message Service The text messaging service of mobile/cell phones.
SPN	Suspect Parameter Number A part of DTC that indicates what the failure is, e.g. oil pressure, coolant temperature, turbo pressure etc.



1.2 INSTALLATION AND USING THE DSE CONFIGURATION SUITE SOFTWARE

For information in regards to instating and using the DSE Configuration Suite Software please refer to DSE publication: **057-151 DSE Configuration Suite PC Software Installation & Operation Manual** which is found on our website: www.deepseaelectronics.com

2 EDITING THE CONFIGURATION

This menu allows module configuration, to change the function of Inputs, Outputs and LED's, system timers and level settings to suit a particular application.

2.1 SCREEN LAYOUT



2.2 MODULE

The module section is subdivided into smaller sections.


Select the required section with the mouse.

This section allows the user to change the options related to the module itself.




2.2.1 MODULE OPTIONS

Description




Parameter	Description
Description	Free entry boxes to allow the user to give the configuration file a description. Typically used to enter the job number, customer name, engineers name etc. This text is not shown on the module display and is only seen in the configuration file.


LED Indicators




Parameter	Description
Function	Allows the user to select the function of the module's user configurable LED indicators. For details of selections, please see section entitled <i>Output sources</i> elsewhere in this document.
Insert Card Text	Enter a custom text to print on the text insert
Text Insert	Allows the user to print the text insert cards
Logo Insert	Allow the user to choose and print an image for the logo insert

Start Up Image





Parameter	Description
Show at Start Up	<p><input type="checkbox"/> = Start Up screen is disabled</p> <p><input checked="" type="checkbox"/> = Enable a <i>Start Up Text</i> or <i>Image</i> to be displayed on the module's LCD at power up.</p> 
Use for Screensaver	<p><input type="checkbox"/> = Screensaver is disabled</p> <p><input checked="" type="checkbox"/> = Module activates the Screensaver to show the selected image after inactivity in any mode for the configured <i>Delay</i> time. Press any button to 'end' the Screensaver.</p>
Select Image	Browse and select the image file to display at power up. The file required has to be a monochrome bitmap image of size 132 pixels in width by 64 pixels in height.
Clear	Clears the image file selection
Duration	Set the duration for which the <i>Start Up Image</i> is displayed at power up

2.2.2 MISCELLANEOUS OPTIONS



Parameter	Description
Enable Fast Loading	<p>NOTE: Enabling Fast Loading is only recommended where steps have been taken to ensure rapid startup of the engine is possible. (For example when fitted with engine heaters, electronic governors etc.)</p> <p><input type="checkbox"/> = Normal Operation, the safety on timer is observed in full. This feature is useful if the module is to be used with some small engines where pre-mature termination of the delay timer leads to overspeed alarms on startup.</p> <p><input checked="" type="checkbox"/> = The module terminates the safety on timer once all monitored parameters have reached their normal settings. This feature is useful if the module is to be used as a standby controller as it allows the generator to start and go on load in the shortest possible time.</p>
Audible Alarm Prior to Starting	<p><input type="checkbox"/> = The module starts the engine with no audible indication</p> <p><input checked="" type="checkbox"/> = The module gives an audible warning during the pre-start sequence as an indicator that the set is about to run. This is often a site's specification requirement of AUTO mode operation.</p>
All Warnings Are Latched	<p><input type="checkbox"/> = Normal Operation, the warnings, and pre-alarms automatically reset once the triggering condition has cleared.</p> <p><input checked="" type="checkbox"/> = Warnings and pre-alarms latch when triggered. Resetting the alarm is performed by either an external reset applied to one of the inputs or, the 'Stop/Reset' pushbutton operated (once the triggering condition has been cleared).</p>

Parameters are continued overleaf...


Parameter	Description
Enable Sleep Mode	<p><input type="checkbox"/> =Normal operation <input checked="" type="checkbox"/> = Module goes into sleep (low current) mode after inactivity in STOP mode for the configured <i>Sleep Timer</i> time in <i>Module Timers</i> section. Press any button to 'wake' the module.</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p> NOTE: Sleep Mode is disabled when the module's USB, or any of its Modbus communication ports (RS232, RS485, Ethernet) are in use, or when it is Data Logging.</p> </div> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p> NOTE: The Sleep Mode is disabled when the DSE25xx MKII remote display module is connected.</p> </div>
Enable Manual Fuel Pump Control	<p><input type="checkbox"/> =Normal operation <input checked="" type="checkbox"/> =Allows manual fuel pump control when the "fuel level" instrument is being viewed.</p>
Enable Manual Frequency Trim Control	<p><input type="checkbox"/> =Normal operation <input checked="" type="checkbox"/> = When speed control over CAN is available, this allows manual speed trim control through the <i>Front Panel Running Editor</i>.</p>
Support Right-To-Left Languages in Module Strings	<p>Determines the direction of text input where supported (i.e. configurable input text) <input type="checkbox"/> = Left to right language support <input checked="" type="checkbox"/> = Right to left language support</p>
Power Up in Mode	<p>Select the power up option: Stop: Allows the module to boot into <i>Stop Mode</i> Auto: Allows the module to boot into <i>Auto Mode</i> Manual: Allows the module to boot into <i>Manual Mode</i> Test: Allows the module to boot into <i>Test Mode</i></p>
Enable Cool Down in Stop Mode	<p><input type="checkbox"/> =Normal operation. Pressing the Stop button instantly opens the load switch and stops the generator. <input checked="" type="checkbox"/> =Alternative operation. Pressing the Stop button instantly opens the load switch and puts the generator into a cooling run. Pressing the Stop button again instantly stops the generator.</p>
Enable Maintenance Reset on Module Front Panel	<p><input type="checkbox"/> = The maintenance alarms are only reset through the SCADA section of the DSE Configuration Suite software or digital input if configured. <input checked="" type="checkbox"/> = The maintenance alarms are also reset by scrolling to the maintenance page on the module. By pressing and holding the <i>Stop / Reset</i> button on each alarm, the operator is able to reset each individual alarm.</p>
Enable Backlight Power Saving Mode	<p>Enables DC power saving by turning off the LCD Backlight when the module is not operated for the duration of the <i>Backlight Timer</i>.</p>
Show Active DTC ECU / ECM Only	<p>Enable this option to show the active ECU / ECM fault codes on the module display. (Active DTC are also called DM1 in J1939 ECU)</p>
Show Inactive DTC ECU / ECM Only	<p>Enable this option to show the in-active ECU (ECM) DTC on the module display. Inactive DTCs are the historical log of the ECU, where previous alarms have been cleared from the active DTC list. (Inactive DTC are called DM2 in J1939).</p>

Parameters are continued overleaf...

Parameter	Description
Filter Generator Voltage Display	<p><input type="checkbox"/> = Normal operation. The display of generator voltage shows the instantaneous measurement.</p> <p><input checked="" type="checkbox"/> = Filtered display. Generator voltage is averaged over time to produce a smoother display. This does not affect the response of voltage alarms.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>NOTE: The filtered voltage is only applicable on the module's display, and not applicable on the Scada or on any remote monitoring devices.</p> </div>
Filter Constant	<p>Increase <i>Filter Constant</i> to further smooth the display of Generator Voltage.</p>
Filter Mains Voltage Display	<p><input type="checkbox"/> = Normal operation. The display of mains voltage shows the instantaneous measurement.</p> <p><input checked="" type="checkbox"/> = Filtered display. Bus voltage is averaged over time to produce a smoother display. This does not affect the response of voltage alarms.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>NOTE: The filtered voltage is only applicable on the module's display, and not applicable on the Scada or on any remote monitoring devices.</p> </div>
Filter Constant	<p>Increase <i>Filter Constant</i> to further smooth the display of Mains Voltage.</p>

2.2.3 CONFIGURABLE FRONT PANEL EDITOR


The Configurable Front Panel Editor allows generator OEMs to create a PIN protected, customised Front Panel Editor with up to two security access levels. Items may be added or removed as required by the generator supplier.





Items	Description
Enable	<input type="checkbox"/> = Configuration parameters are all accessible from Front Panel Editor. <input checked="" type="checkbox"/> = The Configuration parameters depend on their Access level.
Access	Permits the relevant item to be edited through the Front Panel Editor of the module. Not in FPE: The item cannot be edited through the Front Panel Editor No PIN: Allowing access to edit the item with no PIN Level 1 PIN: The Front Panel Editor asks for the configured <i>Level 1 PIN</i> to allow access to the relevant item. Level 2 PIN: The Front Panel Editor asks for the configured <i>Level 2 PIN</i> to allow access to the relevant item.
Level 1 PIN	Set the four digit PIN number, then repeat the PIN in the <i>Confirmation</i> to configure <i>Level 1 PIN</i> for this access level.
Level 2 PIN	Set the four digit PIN number, then repeat the PIN in the <i>Confirmation</i> to configure <i>Level 2 PIN</i> for this access level.

2.2.4 DISPLAY CONFIGURATION

Home Page



Parameter	Description
Home Page	<p>  Instrumentation: When no Navigation buttons are pressed for the duration of the <i>Page Timer</i>, the module's display scrolls through the <i>Configurable Status Screens</i>. Each of the <i>Configurable Status Screens</i> remains on the display for the duration of the <i>Scroll Timer</i>. The <i>Control Mode</i> page is not displayed automatically but is still accessible by manually pressing the Navigation buttons. </p> <p>  Mode: When no Navigation buttons are pressed for the duration of the <i>Page Timer</i>, the module's display reverts back to show the <i>Control Mode Page</i>. The <i>Configurable Status Screens</i> are not displayed automatically but is still accessible by manually pressing the Navigation buttons. </p>

Displayed Pages

Displayed Pages			
Page 1	Summary Screen	Page 6	Not Used
Page 2	Not Used	Page 7	Not Used
Page 3	Not Used	Page 8	Not Used
Page 4	Not Used	Page 9	Not Used
Page 5	Not Used	Page 10	Not Used


Parameter	Description
Page 1 to 10	Select the instrumentation parameter that is to be displayed for the specific <i>Configurable Status Screen</i> .




Example

In the example below, the *Home Page* is configured to *Instrumentation* so will scroll through the *Configurable Status Screens*. Depending on the application, the system designer selects the instrumentation parameters that are most important to constantly show on the module.

Home Page			
Home Page		Instrumentation	
Configurable Status Screens			
Page 1	Engine Coolant Temp	Page 6	Generator kW
Page 2	Engine Oil Pressure	Page 7	Generator Pf
Page 3	Engine Fuel Level	Page 8	Not Used
Page 4	Generator Frequency	Page 9	Not Used
Page 5	Generator Voltage L-N	Page 10	Not Used

Instrumentation Suppression



Parameter	Description
Generator Frequency	<input type="checkbox"/> = The <i>Generator Frequency Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Generator Frequency Instrumentation</i> is suppressed.
Generator Voltage	<input type="checkbox"/> = The <i>Generator Voltage Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Generator Voltage Instrumentation</i> is suppressed.
Mains Frequency 	<input type="checkbox"/> = The <i>Mains Frequency Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Mains Frequency Instrumentation</i> is suppressed.
Mains Voltage 	<input type="checkbox"/> = The <i>Mains Voltage Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Mains Voltage Instrumentation</i> is suppressed.
Current	<input type="checkbox"/> = The <i>Current Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Current Instrumentation</i> is suppressed.
Power Factor	<input type="checkbox"/> = The <i>Power Factor Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Power Factor Instrumentation</i> is suppressed.
kW	<input type="checkbox"/> = The <i>kW Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kW Instrumentation</i> is suppressed.
kWh	<input type="checkbox"/> = The <i>kWh Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kWh Instrumentation</i> is suppressed.
kvar	<input type="checkbox"/> = The <i>kvar Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kvar Instrumentation</i> is suppressed.
kvarh	<input type="checkbox"/> = The <i>kvarh Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kvarh Instrumentation</i> is suppressed.
kVA	<input type="checkbox"/> = The <i>kVA Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kVA Instrumentation</i> is suppressed.
kVAh	<input type="checkbox"/> = The <i>kVAh Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>kVAh Instrumentation</i> is suppressed.
Charge Alternator	<input type="checkbox"/> = The <i>Charge Alternator Instrumentation</i> is displayed. <input checked="" type="checkbox"/> = The <i>Charge Alternator Instrumentation</i> is suppressed.
Generator PhPh Voltage	<input type="checkbox"/> = The <i>Generator Phase to Phase Voltage Instrumentation</i> is displayed and alarms are active. <input checked="" type="checkbox"/> = The <i>Generator Phase to Phase Voltage Instrumentation</i> is suppressed and alarms are disabled.
Mains PhPh Voltage 	<input type="checkbox"/> = The <i>Mains Phase to Phase Voltage Instrumentation</i> is displayed and fault detection are active. <input checked="" type="checkbox"/> = The <i>Mains Phase to Phase Voltage Instrumentation</i> is suppressed and fault detection are disabled.

2.2.5 USER DEFINED STRINGS

Page 1 and 2

Parameter	Description
Page Title	A free entry box to allow the user to give the custom display screen a title relating to the information contained on <i>Line 1 to 3</i> .
Line 1 to 3	Three free entry boxes, one for each line of the module's display. Typically used to show contact details or other information on the module's that is helpful to the end user of the generator.

About Page / Start Up Text

Parameter	Description
Text	A free entry box to allow the user to enter the text to be used for the <i>About Page</i> and <i>Start Up Text</i> .
Show at Start Up	<input type="checkbox"/> = The <i>Start Up Text</i> is disabled. <input checked="" type="checkbox"/> = The <i>Start Up Text</i> is enabled. The <i>Start Up Text</i> is displayed on the module's LCD for the configured <i>Duration</i> during power up.

2.2.6 EVENT LOG

Display Options

Display Options

Module display Date and time
 Engine hours run

Parameter	Description
Module Display	<p><input checked="" type="radio"/> Date and Time = The module displays what the <i>Date and Time</i> was when the <i>Event</i> was logged.</p> <p><input type="radio"/> Engine Hours Run = The module displays what the <i>Engine Hours</i> was when the <i>Event</i> was logged.</p>

Logging Options

Logging Options

Log the following events to the event log

Power up <input checked="" type="checkbox"/>	Fuel level when at rest <input type="checkbox"/>
ECU Lamps <input checked="" type="checkbox"/>	Fuel Level <input checked="" type="checkbox"/>
Mains return <input checked="" type="checkbox"/>	Engine starts <input checked="" type="checkbox"/>
Mains fail <input checked="" type="checkbox"/>	Engine stops <input checked="" type="checkbox"/>

'Repeat SMS' requires a GSM modem to be configured on the Communications/RS232 Port/Basic page

Shutdown alarms

Repeat SMS

Repeat delay 12h

Repeats 2

Electrical trip alarms

Repeat SMS

Repeat delay 12h

Repeats 2

Latched warnings

Unlatched warnings

Repeat SMS

Repeat delay 12h



Repeats 2

Maintenance alarms

Repeat SMS

Repeat delay 12h

Repeats 2

Parameter	Description
Power Up	<p><input type="checkbox"/> = Power up events are not logged in the module's event log</p> <p><input checked="" type="checkbox"/> = Power up events are logged when the DC Supply is applied to the module or whenever the module is rebooted</p>
ECU (ECM) Lamps	<p>NOTE: ECU Alarms are only available when the module is configured to communicate to an engine's ECU/ECM over CANbus.</p> <p><input type="checkbox"/> = The ECU (ECM) alarm lamps signals are not logged.</p> <p><input checked="" type="checkbox"/> = The ECU (ECM) alarm lamps signals are logged when generated by the ECU (ECM)</p>
Mains Fail 	<p><input type="checkbox"/> = <i>Mains Fail</i> events are not logged.</p> <p><input checked="" type="checkbox"/> = <i>Mains Fail</i> events are logged when the mains voltage/frequency rise above/falls below the configured trip levels for the duration of the <i>Mains Transient Delay</i> timer.</p>
Mains Return 	<p><input type="checkbox"/> = <i>Mains Return</i> events are not logged.</p> <p><input checked="" type="checkbox"/> = <i>Mains Return</i> events are logged when the mains voltage/frequency falls below/rise above the configured return levels for the duration of the <i>Mains Transient Delay</i> timer.</p>

NOTE: Sending events by SMS is only available when the module is configured to communicate to a supported modem by RS232. Refer to section entitled RS232 Port elsewhere in this document for further details.

Parameter	Description
Fuel Level When at Rest	<input type="checkbox"/> = <i>Fuel Monitoring</i> events are not logged when the generator is at rest. Fuel level alarms are still logged if the appropriate alarm category is logged. <input checked="" type="checkbox"/> = <i>Fuel Monitoring</i> events are logged when the generator is at rest.
Fuel Level	<input type="checkbox"/> = <i>Fuel Monitoring</i> events are not logged when the generator running. Fuel level alarms are still logged if the appropriate alarm category is logged. <input checked="" type="checkbox"/> = <i>Fuel Monitoring</i> events are logged when the generator is running.
Engine Starts	<input type="checkbox"/> = <i>Engine Start</i> events are not logged. <input checked="" type="checkbox"/> = <i>Engine Start</i> events are logged when the generator successfully crank disconnects.
Engine Stops	<input type="checkbox"/> = <i>Engine Stop</i> events are not logged. <input checked="" type="checkbox"/> = <i>Engine Stop</i> events are when the <i>Stopping Timer</i> ceases.
Shutdown Alarms	<input type="checkbox"/> = <i>Shutdown Alarms</i> are not logged. <input checked="" type="checkbox"/> = <i>Shutdown Alarms</i> are logged when the moment they activate.
Shutdown Alarms Repeat SMS	<input type="checkbox"/> = <i>Shutdown Alarms</i> are only sent once via an SMS message. <input checked="" type="checkbox"/> = <i>Shutdown Alarms</i> are sent via SMS repeatedly until the <i>Repeats</i> value has been met. The delay between the repeated SMS is set by the <i>Repeats Delay</i> value.
Electrical Trip Alarms	<input type="checkbox"/> = <i>Electrical Trip Alarms</i> are not logged. <input checked="" type="checkbox"/> = <i>Electrical Trip Alarms</i> are logged when the moment they activate.
Electrical Trip Alarms Repeat SMS	<input type="checkbox"/> = <i>Electrical Trip Alarms</i> are only sent once via an SMS message. <input checked="" type="checkbox"/> = <i>Electrical Trip Alarms</i> are sent via SMS repeatedly until the <i>Repeats</i> value has been met. The delay between the repeated SMS is set by the <i>Repeats Delay</i> value.
Latched Warnings	<input type="checkbox"/> = <i>Latched Warnings Alarms</i> are not logged. <input checked="" type="checkbox"/> = <i>Latched Warnings Alarms</i> are logged when the moment they activate.
Unlatched Warnings	<input type="checkbox"/> = <i>Unlatched Warnings Alarms</i> are not logged. <input checked="" type="checkbox"/> = <i>Unlatched Warnings Alarms</i> are logged when the moment they activate.
Unlatched Warnings Alarms Repeat SMS	<input type="checkbox"/> = <i>Unlatched Warnings Alarms</i> are only sent once via an SMS message. <input checked="" type="checkbox"/> = <i>Unlatched Warnings Alarms</i> are sent via SMS repeatedly until the <i>Repeats</i> value has been met. The delay between the repeated SMS is set by the <i>Repeats Delay</i> value.
Maintenance Alarms	<input type="checkbox"/> = <i>Maintenance Alarms</i> are not logged. <input checked="" type="checkbox"/> = <i>Maintenance Alarms</i> are logged when the moment they activate.
Maintenance Alarms Repeat SMS	<input type="checkbox"/> = <i>Maintenance Alarms</i> are only sent once via an SMS message. <input checked="" type="checkbox"/> = <i>Maintenance Alarms</i> are sent via SMS repeatedly until the <i>Repeats</i> value has been met. The delay between the repeated SMS is set by the <i>Repeats Delay</i> value.

Engine DTC Logging


Logging Options (SMS messages will not be sent)

Engine DTC Logging

Parameter	Description
Always	When selected, DTCs are immediately logged upon occurrence
Never	Select to disable Engine DTC logging
Shutdowns and Warnings	When selected, Engine DTCs are logged when an ECU Shutdown or ECU Warning occurs, the timestamp for the DTC in the event log is that of the Shutdown or Warning
Shutdowns Only	When selected, Engine DTCs are logged when an ECU Shutdown occurs, the timestamp for the DTC in the event log is that of the Shutdown

2.2.7 DATA LOGGING

 **NOTE: Data Logging to internal and external memory is available.**




The module holds a rolling temporary store of up to twenty parameters. This is saved to the *Data Log* as a *Logging Window* when any of the parameters exceed its configured *Trigger* or on an *External Trigger* (such as an alarm) activates. The configurable *Logging Window* allows the logged data to be recorded both *Pre-Trigger* and *Post-Trigger*.

The module has the ability to store up to 16 *Logging Windows* in its internal memory. If 20 parameters were configured to be logged, each with a *Log Interval* of 1 second, the length of the *Logging Window* would be 6 minutes and 43 seconds. As the module has the ability to store up to 16 *Logging Windows* on a rolling update, this results in a minimum total of 1 hour 47 minutes and 28 seconds of logged data. This time is extendable as the size of each *Logging Window* varies upon the number of selected parameters and their *Log Interval*.

The number of *Logging Windows* increases when an external USB storage device is connected to the module's USB Host port. The increased number of *Logging Windows* is dependent upon the size of the USB storage device connected. When using the maximum size USB storage device of 16 GB, the number of *Logging Windows* is increased to 250,000.

The *Data Logging* is viewed using the *Data Log Viewer* application, which is accessed from the DSE Configuration Suite PC Software under the *Tools* menu.

2.2.7.1 CONFIGURATION




Parameter	Description
Logged Data	Select the instrument required to be logged: <i>Specific Register</i> <i>Instrumentation</i> <i>Status</i>
Log Interval	Select the logging interval of the data
Trigger	Select when the instrument is logged compared to the configurable value of the slider

Specific Register

NOTE: The Gencomm (MODBUS) address table for the module is available upon request by contacting DSE technical support: support@deepseaelectronics.com.

Specific Register enables the user to configure a Gencomm (MODBUS) address for the *Data Logger* to obtain information from.

The image below shows a typical example when reading battery voltage:



2.2.7.2 OPTIONS

Settings

Settings

Only log when engine is running

Log to USB drive

Keep oldest data

Parameter	Description
Only Log When Engine is Running	<input type="checkbox"/> = The module logs data regardless of engine running state. <input checked="" type="checkbox"/> = The module only logs data when the engine is running.
Log to USB Drive	<input type="checkbox"/> = The module logs data to the module's internal memory. <input checked="" type="checkbox"/> = The module logs data to an external USB device, connected to the USB host socket on the module.
Keep Oldest Data	<input type="checkbox"/> = When the logging memory is full, the module overwrites the oldest data first with the new data. <input checked="" type="checkbox"/> = When the logging memory is full, the module stops recording new data.

External Triggers

External Triggers

Trigger 1 Polarity

Trigger 2 Polarity

Trigger 3 Polarity

Trigger 4 Polarity

Parameter	Description
Trigger	Select an external trigger to initiate a data log.
Polarity	Select the polarity of the trigger. Energise: the data log is triggered when the configured trigger goes active. De-Energise: the data log is triggered when the configured trigger goes inactive.

Logging Window

Logging Window

Pre-Trigger Post-Trigger

26h 13m 22h 20m

Logging Window 48h 33m

Parameter	Description
Pre-Trigger	Shows the duration of time before the trigger, during which the data is logged.
Post-Trigger	Shows the duration of time after the trigger, during which the data is logged.
Logging Window	Shows the total duration of data logging time, combining the duration before and after the trigger.

Example 1

In the example below, the selected three parameters are logged when the *Generator Total Power* exceeds the set trip level of 150 kW.

The *Data Log* in the module contains the values of these three parameters for the duration of the *Logging Window*, which is 22 m 25 s before the *Generator Total Power* exceeded 150 kW and 22 m 25 s after that.

The screenshot shows the configuration interface for 'Configuration Items 1 - 10'. The 'Configuration' section is a table with the following data:

Item	Logged data	Log Interval	Trigger	Value	Unit
1	Coolant / Engine Temperature	1 second	Not Used	0	°C
2	Oil Pressure	1 second	Not Used	0.00	Bar
3	Generator Total Power	1 second	Is greater than	150	kW
4	<Not Used>	1 second	Not Used	0	
5	<Not Used>	1 second	Not Used	0	
6	<Not Used>	1 second	Not Used	0	
7	<Not Used>	1 second	Not Used	0	
8	<Not Used>	1 second	Not Used	0	
9	<Not Used>	1 second	Not Used	0	
10	<Not Used>	1 second	Not Used	0	

Below the configuration table is the 'Logging Window' section, which shows a horizontal timeline. The 'Pre-trigger' duration is 22m 25s, and the 'Post-trigger' duration is 22m 25s. The total 'Logging Window' is 44m 50s.

Example 2

In the example below, the selected four parameters are logged when a *Common Alarm* occurs on the controller.

The *Data Log* in the module contains the values of these four parameters for the duration of the *Logging Window*, which is 33 m 38 s before the *Alarm* occurred.

The screenshot shows the configuration interface for 'Configuration Items 1 - 10'. The 'Configuration' section is a table with the following data:

Item	Logged data	Log Interval	Trigger	Value	Unit
1	Coolant / Engine Temperature	1 second	Not Used	0	°C
2	Oil Pressure	1 second	Not Used	0.00	Bar
3	Generator Total Power	1 second	Is greater than	150	kW
4	Generator Frequency	1 second	Not Used	0.0	Hz
5	<Not Used>	1 second	Not Used	0	
6	<Not Used>	1 second	Not Used	0	
7	<Not Used>	1 second	Not Used	0	
8	<Not Used>	1 second	Not Used	0	
9	<Not Used>	1 second	Not Used	0	
10	<Not Used>	1 second	Not Used	0	

Below the configuration table is the 'External Triggers' section, which shows four triggers:

- Trigger 1: Common Alarm, Polarity: Energise
- Trigger 2: Not Used, Polarity: Energise
- Trigger 3: Not Used, Polarity: Energise
- Trigger 4: Not Used, Polarity: Energise

Below the external triggers is the 'Logging Window' section, which shows a horizontal timeline. The 'Pre-Trigger' duration is 33m 38s, and the 'Post-Trigger' duration is 0m 0s. The total 'Logging Window' is 33m 38s.

2.3 APPLICATION

ECU (ECM) Options

NOTE: For further details and instructions on ECU (ECM) options and connections, refer to DSE Publication: *057-004 Electronic Engines and DSE Controllers* which are found on our website: www.deepseaelectronics.com

ECU (ECM) Options

Engine Type Conventional Diesel ▾

Enhanced J1939

Alternative Engine Speed

Modbus Engine Comms Port RS485 Port ▾

Parameter	Description
Engine Type	<p>Select the appropriate engine type</p> <p>Conventional Engine: Select this for a traditional (non-electronic) engine, either Energise to Run or Energise to Stop.</p> <p>Conventional Gas Engine: Select this for a traditional (non-electronic) engine and require Gas engine functionality. This enables control of configurable outputs for <i>Gas Choke and Gas Ignition</i> and instructs the module to follow the gas engine timers.</p> <p>Other Engines: The list of supported CAN (or MODBUS) engines is constantly updated, check the DSE website at www.deepseaelectronics.com for the latest version of Configuration Suite software.</p>

Parameters are continued overleaf...

Parameter	Description
Enhanced J1939	<p><input type="checkbox"/> = The module reads 'Basic' instrumentation from the engine ECU (ECM) and display (where supported by the engine) :</p> <ul style="list-style-type: none"> • Engine Speed • Oil Pressure • Engine Coolant Temperature • Hours Run <p><input checked="" type="checkbox"/> = The module reads and display an 'Enhanced' instrumentation list (where supported by the engine) :</p> <ul style="list-style-type: none"> • Engine Speed • Engine Speed Biasing (Subject to <i>ECM Speed Control</i> setting) • Oil Pressure • Engine Coolant Temperature • Hours Run • Engine Oil Temperature • Exhaust Temperature • Fuel Pressure • Total Fuel used • Fuel Consumption • Inlet Manifold Temperature • Coolant Pressure • Turbo Pressure <p>Where an instrument is not supported by the engine ECU (ECM), the instrument is not displayed. DSE Reserve the right to change these lists in keeping with our policy of continual development.</p>
Alternative Engine Speed	<p><input type="checkbox"/> = The engine is instructed to run at its <i>Nominal Speed</i> as configured by the Engine Manufacturer.</p> <p><input checked="" type="checkbox"/> = The engine is instructed to run at its <i>Alternative Speed</i> as configured by the Engine Manufacturer.</p>
MODBUS Engine Comms Port	<p>RS485 Port : The modules RS485 port is used to communicate to the engine (when a MODBUS engine type is selected).</p> <p>DSENet Port : The modules DSENet port is used to communicate to the engine (when a MODBUS engine type is selected. This 'frees' the RS485 port in case connection to BMS or other RS485 compatible equipment is required.</p>


Dual Mutual Standby

When a start request is available, the module in duty starts the generator set to supply power to the load.

The start request is initiated by one of the following:

Activation of a digital input configured as *Remote Start on Load Mains Failure (DSE7420MKII Only)*

If the engine fails to start, or is unavailable due to maintenance, engine shutdown etc, the next priority set starts and takes over to supply power to the load.




Parameter	Description
Dual Mutual Standby	Select when the feature is active. Disabled: The module operates as a standalone controller. Always: The <i>Dual Mutual Standby</i> is always active. On Input: The <i>Dual Mutual Standby</i> is only active when a digital input configured for <i>Dual Mutual Standby</i> is active. This allows an external device or switch to enable/disable the feature.
Balancing Mode	Select how the modules are chosen for <i>Dual Mutual Standby</i> duty run. Dual Mutual Time: Load balancing is based upon the configuration of the <i>DutyTime</i> , the modules duty runs change over at the configured <i>Duty Time</i> intervals. Engine Hours: The <i>Dual Mutual Standby</i> is based upon the difference in engine run hours, the modules change over when the difference in <i>Engine Hours</i> is higher than the configured <i>Duty Time</i> . Set Priority: The <i>Dual Mutual Standby</i> is based upon the <i>MSC Priority</i> set in the SCADA
Start On Current (Amps) Alarms	This option allows the module to start and run the generator when the other module has a <i>Current (Amps) Alarm</i> . The alarms are: Generator Overcurrent IDMT Generator Earth Fault Generator Short Circuit <input type="checkbox"/> = The module does not start the generator when the other module has an active <i>Current (Amps) Alarm</i> . This prevents the generator from starting and closing onto the same potential fault, for example a short circuit. <input checked="" type="checkbox"/> = The module starts the generator when the other module has an active <i>Current (Amps) Alarm</i> .
Duty Time	Defines the hours difference the module maintains with the other controllers in <i>Dual Mutual Standby</i> . Based on the <i>Balancing Mode</i> selection, this defines <i>DutyTime</i> or the <i>Engine Hours</i> difference. The modules change over when the difference in hour meters is higher than the configured <i>Duty Time</i> or <i>Engine Hours</i> (whichever is selected).
Dual Mutual Comms Port	Select the communication port used for the <i>Dual Mutual Standby</i> : RS485 RS232

Auto Voltage Sensing


NOTE: The Auto Voltage Sensing feature is available on the 7410 MKII only.

NOTE: Auto Voltage Sensing is not compatible with the AVR configuration based on manually selected voltage feature. Therefore, when one feature is enabled the other must be disabled.




Option	Description
Enable Auto Voltage Sensing	<input type="checkbox"/> = The module operates as normal. <input checked="" type="checkbox"/> = <i>Auto Voltage Sensing</i> is enabled. When the generator is started, the module monitors the generator voltage. Depending on the voltage level and AC System detected, the module automatically selects between the Mains Configuration and Alternative Configuration. This is useful for hire generators where the AC System is selectable as no digital input signals are required to be given to the DSE module.



Auto Load Sensing



Option	Description
Enable Auto Load Sensing	<input type="checkbox"/> = The module operates as normal. <input checked="" type="checkbox"/> = <i>Auto Load Sensing</i> is enabled. When called to run off load, if a load is detected, the module forces the load switch to close (if connected) and enables the cooldown timer when the set is requested to stop. This is to ensure the set is cooled down before stopping after running with an unexpected load (i.e. In a manual load switch system).

Breaker Control




Parameter	Description
Enable Alternative Breaker Control Button	<p>Controls the operation of the fascia mounted load switch control buttons (manual mode only)</p> <p><input type="checkbox"/> = Normal operation, pressing the respective load switch control button causes the supply to go on load, if it was available. Only a transfer is possible without the ability to open both breakers.</p> <p><input checked="" type="checkbox"/> = Alternative operation. If a supply is on load and that supply's load switch button is pressed, the load switch opens. Pressing the button again closes the button. Pressing the 'other' button when a supply is on load causes a transfer to the 'other' supply (if available).</p>
Enable Manual Breaker Control	<p><input type="checkbox"/> = Normal operation. When running in Manual mode, activation of any on load request causes the generator breaker to close.</p> <p><input checked="" type="checkbox"/> = When running in Manual mode, only the following load requests cause the generator breaker to close:</p> <ul style="list-style-type: none"> - Pressing the <i>Close Generator Button</i> on the module front fascia - Activating a digital input configured for <i>Close Generator</i> <p>This also allows opening the generator breaker when running in Manual even if a load request is available.</p>
Active	<p>Always: <i>Manual Breaker Control</i> is always active.</p> <p>On Input: <i>Manual Breaker Control</i> is only active when a digital input configured for <i>Manual Breaker Mode</i> is active.</p>
 Check Sync	<p><input type="checkbox"/> = None check sync operation</p> <p><input checked="" type="checkbox"/> = During load transfer from Mains to Generator or Generator to Mains, the module only closes its breaker within the check sync window. See overleaf for description of the <i>Check Sync</i> options.</p>
 Closed Transition	<div style="border: 2px solid black; padding: 5px;"> <p>NOTE: It is not possible to write the configuration to the module if the Closed Transition option is enabled and the AC Systems in the Generator Options and in the Mains Options are not the same, in either the Main or Alternative Configurations.</p> </div> <p><input type="checkbox"/> = Break before make operation</p> <p><input checked="" type="checkbox"/> = During load transfer, the module only closes its breaker within the check sync window. See overleaf for description of the <i>Check Sync</i> options.</p>

Check Sync



= Only available on DSE7420 MKII AMF Modules

Before the breaker is closed, the following configurable conditions must be met.




Parameter	Description
Low Frequency High Frequency	The difference between the two supplies frequencies must be between the <i>Check Sync Low Frequency</i> and <i>Check Sync High Frequency</i>
Voltage	The difference between the two supplies voltages must be equal to or below the <i>Check Sync Voltage</i>
Phase	The phase of the two supplies must be equal to or below the <i>Check Sync Phase Angle</i>

Check Sync Assistant



= Only available on DSE7420 MKII AMF Modules



Parameter	Description
AVR	<p>NOTE: Check Sync Assistant with <i>AVR</i> is used when a CAN AVR is connected to the module's ECU port. This enables the module to control the Generator voltage through CAN messages before the <i>Closed Transition</i> period.</p> <p>NOTE: At the time of writing, only the DSEA108 AVR is supported. For further details, refer to DSE Publication: <i>057-281 DSEA108 Operator Manual</i> available on our website: www.deepseaelectronics.com</p> <p><input type="checkbox"/> = No CAN messages is sent from the ECU port to the CAN AVR. <input checked="" type="checkbox"/> = The module sends CAN messages to the CAN AVR to control the generator's output voltage, for the <i>Voltage Check Sync</i> takes place.</p>
Speed Trim	<p>NOTE: Check Sync Assistant with <i>Speed Trim</i> is only applicable with speed trim enabled Electronic CAN Engines, and when <i>ECU Data Fail</i> alarm is not active.</p> <p><input type="checkbox"/> = No speed CAN message is sent to the engine ECU. <input checked="" type="checkbox"/> = The module controls the Electronic CAN Engine to match the generator frequency with the mains frequency for the <i>Frequency</i> and <i>Phase Angle Check Sync</i> take place.</p>

Fail To Sync Alarm




= Only available on DSE7420 MKII AMF Modules

Used to detect that the check sync process is taking a long time. This occurs when the supplies' are not in sync (within the *Check Sync* window).


Parameter	Description
Action	Determines the action to take upon a <i>Fail to Sync</i> . Electrical Trip: The set is stopped with an <i>Electrical Trip</i> alarm. Indication: The set continues to run and no alarm is raised. This is used for internal use, such as in the <i>PLC Logic</i> or <i>Virtual Leds</i> . Warning: The set continues to run without any transition to the Mains.
Return To Open Transition	<input type="checkbox"/> = The load remains on the generator. <input checked="" type="checkbox"/> = This is only applicable with <i>Action</i> to <i>Indication</i> . The load is transferred to Mains.
Delay	The time to allow for successful sync check to take place. Should the process continue longer than <i>Delay</i> , the <i>Action</i> above is taken.

2.4 INPUTS

The *Inputs* section is subdivided into smaller sections. Select the required section with the mouse.



2.4.1 ANALOGUE INPUT CONFIGURATION



Parameter	Description
Module To Measure Oil Pressure	(Available only when the module is configured for connection to a CAN engine.) <input type="checkbox"/> = The measurements are taken from the ECU (ECM). <input checked="" type="checkbox"/> = The module ignores the CAN measurement and uses the analogue sensor input.
Module To Measure Coolant Temperature	(Available only when the module is configured for connection to a CAN engine.) <input type="checkbox"/> = The measurements are taken from the ECU. <input checked="" type="checkbox"/> = The module ignores the CAN measurement and uses the analogue sensor input.
Analogue Input A	Select what the analogue input is to be used for: Digital Input: Configured on the <i>Inputs/Digital Inputs</i> pages Flexible Analogue: Configured on the <i>Inputs/Analogue Inputs</i> pages Fuel Sensor: Configured on the <i>Engine</i> pages Not Used: The input is disabled Oil Sensor: Configured on the <i>Engine</i> pages Temperature Sensor: Configured on the <i>Engine</i> pages
Analogue Input B, C, D, E, and F	Select what the analogue input is to be used for: Digital Input: Configured on the <i>Inputs/Digital Inputs</i> pages Flexible Analogue: Configured on the <i>Inputs/Analogue Inputs</i> pages Fuel Sensor: Configured on the <i>Engine</i> pages Not Used: The input is disabled Temperature Sensor: Configured on the <i>Engine</i> pages

2.4.2 FLEXIBLE SENSOR E & F

Analogue input D is configured for *Flexible Sensor*. Analogue inputs A, B, E, & F are configurable as ratio metric inputs.

Parameter	Description
Sensor Name	Enter the <i>Sensor Name</i> , this text is shown on the module display when a sensor alarm activates
Input Type	Select the sensor type and curve from a pre-defined list or create a user-defined curve Current: for sensors with maximum range of 0 mA to 20 mA Resistive: for sensors with maximum range of 0 Ω to 480 Ω on analogue inputs B,C,D,E,F For sensors with maximum range of 0 Ω to 240 Ω on analogue input A. Voltage: for sensors with maximum range of 0 V to 10 V Pressure: The input is configured as a pressure sensor Percentage: The input is configured as a percentage sensor Temperature: The input is configured as a temperature sensor
Enable Volume Calculation	(Available on all Flexible Analogue Inputs when configured to Percentage). <input type="checkbox"/> = The Volume Calculation is disabled. The sensor reading is displayed alone. <input checked="" type="checkbox"/> = The Volume Calculation is enabled to display the tank's liquid volume on the controller.
Volume	Select the tank size and the unit for the display (Imperial Gallons, Litres, or US Gallons).

Parameter	Description
Enable Alarm	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The module detects an open circuit when the sensor is disconnected
Alarm String	Enter the text that is shown on the display when the alarm occurs

Editing the Configuration

The screenshot shows the 'Sensor Alarms' configuration window. It is organized into several sections:

- Alarm Arming:** Set to 'Always' via a dropdown menu.
- Low Alarm Enable:** Checked. Action is 'Shutdown'. Low Alarm is set to 11%.
- Low Pre-alarm Enable:** Checked. Low Pre-alarm Trip is 23%. Low Pre-alarm Return is 34%.
- Low Alarm String:** Flexible Sensor F Low
- High Pre-alarm Enable:** Checked. High Pre-alarm Return is 57%. High Pre-alarm Trip is 69%.
- High Alarm Enable:** Checked. Action is 'Shutdown'. High Alarm is set to 92%.
- High Alarm String:** Flexible Sensor F High

Parameter	Description
Alarm Arming	Refer to the <i>Alarm Arming</i> section elsewhere in this document for more details. Select when the input becomes active: Always: The input state is always monitored From Safety On: The state of the input is monitored from the end of the <i>Safety On Delay</i> timer From Starting: The state of the input is only monitored from engaging the crank
Low Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Alarm</i> is active when the measured quantity drops below the <i>Low Alarm</i> setting.
Low Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Pre-Alarm</i> is active when the measured quantity drops below the <i>Low Pre-Alarm</i> setting. The <i>Low Pre-Alarm</i> is automatically reset when the measured quantity rises above the configured <i>Low Pre-Alarm Return</i> level.
High Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Pre-Alarm</i> is active when the measured quantity rises above the <i>High Pre-Alarm</i> setting. The <i>High Pre-Alarm</i> is automatically reset when the measured quantity falls below the configured <i>High Pre-Alarm Return</i> level.
High Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Alarm</i> is active when the measured quantity rises above the <i>High Alarm</i> setting.

2.4.3 EDITING THE SENSOR CURVE

While the *DSE Configuration Suite* holds sensor specifications for the most commonly used resistive, voltage, or current sensors, occasionally it is required that the module be connected to a sensor not listed by the *Configuration Suite*. To aid this process, a sensor editor is provided.

In this example, the closest match to the sensor in use is the VDO 10-180Ω fuel level

Click to edit the 'sensor curve'.

Click *Interpolate* then select two points as prompted to draw a straight line between them.

Click and drag the points on the graphs to change the settings.

Double click the left mouse button to add a point or right click on a point to remove it.

Click to change the range of the X and Y Axes of the graph.

Use the mouse to select the graph point, then enter the value in the box or click up/down to change the value.

Click CANCEL to ignore and lose any changes you have made.

Click SAVE AS, you are prompted to name your curve....

Click OK to save the curve.

Any saved curves become selectable in the *Input Type* selection list.


Click SAVE to accept the changes and return to the configuration editor.

Shows the number of points used in the curve.

Hint: Deleting, renaming or editing custom sensor curves that have been added is performed in the main menu, select *Tools | Curve Manager*.

2.4.4 DIGITAL INPUTS

The *Digital Inputs* section is subdivided into smaller sections. Select the required section with the mouse.



2.4.4.1 DIGITAL INPUTS

Digital Inputs A - C

Digital Input A

Function: Remote Start On Load
Polarity: Close to Activate
Action: [Greyed out]
Arming: [Greyed out]
LCD Display: [Greyed out]
Activation Delay: 0s

Digital Input B

Function: User Configured
Polarity: Open to Activate
Action: Shutdown
Arming: Always
LCD Display: [Text input field]
Activation Delay: 0s

Input function. See section entitled *Input functions* for details of all available functions.

As this example shows a *predefined* function, these parameters are *greyed out* as they are not applicable.

Example of a user configured input.

Close or Open to activate.

Enter the text to be displayed on the module LCD.

Parameters detailed overleaf...

Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input functions</i> for details of all available functions.
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	Select the type of alarm required from the list: Electrical Trip Shutdown Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.
Arming	Refer to the <i>Alarm Arming</i> section elsewhere in this document for more details. Select when the input becomes active: Active From Breaker Closed: The state of the input is only monitored when the generator breaker is closed. Active From Parallel: The state of the input is only monitored during the Closed Transition when both generator and mains breakers are closed. Always: The input state is always monitored Engine Protection Activation: The state of the input is monitored from the low oil pressure alarm activation. From Safety On: The state of the input is monitored from the end of the <i>Safety On Delay</i> timer From Starting: The state of the input is only monitored from engaging the crank Never: The input is disabled Wait For ECU: The state of the input is only monitored if the ECU Startup Delay is enabled and during this timer activation only. When Stationary: The state of the input is only monitored when the engine is at rest.
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.

2.4.5 ANALOGUE INPUTS

Analogue Inputs A - C

Analogue Input A (Digital)

The Analogue Input is not configured as a Digital Input
To reconfigure, use the 'Analogue Input Configuration' page

Analogue Input B (Digital)

Function	User Configured
Polarity	Close to Activate
Action	Shutdown
Arming	Never
LCD Display	
Activation Delay	0s

Analogue Input C (Digital)

The Analogue Input is not configured as a Digital Input
To reconfigure, use the 'Analogue Input Configuration' page

Depending on selection, the configuration of the input is located in different sections in the software.

Example of an analogue input configured as digital.



2.4.6 INPUT FUNCTIONS

Where a digital input is NOT configured as “user configured,” a selection is made from a list of predefined functions. The selections are as follows:

Under the scope of IEEE 37.2, *function numbers are also used to represent functions in microprocessor devices and software programs.* Where the DSE input functions are represented by IEEE 37.2, the function number is listed below.




= Only applicable to DSE7420 MKII AMF Modules

Function	Description
Alarm Mute	This input is used to silence the audible alarm from an external source, such as a remote mute switch.
Alarm Reset	This input is used to reset any latched alarms from a remote location. It is also used to clear any latched warnings which may have occurred (if configured) without having to stop the generator.
Alt Config x Select	These inputs are used to instruct the module to follow the <i>alternative</i> configuration settings instead of the <i>main</i> configuration settings.
 Auto Restore Inhibit IEEE 37.2 - 3 Checking Or Interlocking Relay	In the event of a remote start/mains failure, the generator is instructed to start and take load. On removal of the remote start signal/mains return the module continues to run the generator on load until the <i>Auto Restore Inhibit</i> input is removed. This input allows the controller to be fitted as part of a system where the restoration to mains is controlled remotely or by an automated system.
Auto Start Inhibit IEEE 37.2 - 3 Checking Or Interlocking Relay	This input is used to provide an over-ride function to prevent the controller from starting the generator in the event of a remote start/mains out of limits condition occurring. If this input is active and a remote start signal/mains failure occurs the module does not give a start command to the generator. If this input signal is then removed, the controller operates as if a remote start/mains failure has occurred, starting and loading the generator. This function is used to give an ‘AND’ function so that a generator is only called to start if the mains fails and another condition exists which requires the generator to run. If the ‘Auto start Inhibit’ signal becomes active once more it is ignored until the module has returned the mains supply on load and shutdown. This input does not prevent starting of the engine in MANUAL mode.
 Auxiliary Mains Fail	The module monitors the incoming single or three phase supply for Over voltage, Under Voltage, Over Frequency or Under frequency. It may be required to monitor a different mains supply or some aspect of the incoming mains not monitored by the controller. If the devices providing this additional monitoring are connected to operate this input, the controller operates as if the incoming mains supply has fallen outside of limits, the generator is instructed to start and take the load. Removal of the input signal causes the module to act if the mains has returned to within limits providing that the mains sensing also indicates that the mains is within limits.
Coolant Temperature Switch IEEE 37.2 – 26 Apparatus Thermal Device	This input is used to give a <i>Coolant Temperature High</i> shutdown from a digital normally open or closed switch. It allows coolant temperature protection.




Parameters continued overleaf...

Function	Description
Disable Protections	The system designer provides this switch (not DSE), so its location varies depending upon manufacturer, however it normally takes the form of a key operated switch to prevent inadvertent activation. Depending upon configuration, a warning alarm is generated when the switch is operated. When active, and the module is suitably configured (see section entitled 'Advanced') this prevents the engine being stopped upon critical alarm (Sometimes called Battle-Short Mode, War Mode or Run to Destruction)
DPF Auto Regen Inhibit	This input is used to override the ECU (ECM) function and prevent the automatic regeneration of the diesel particulate filter
DPF Force Regeneration	This input is used to override the ECU (ECM) function and activate the regeneration of the diesel particulate filter
DPF Regeneration Interlock	This input is used to stop a manual regeneration from occurring
Droop Enable	This input is used to switch the engine into droop mode on CAN engines that support this function.
Dual Mutual Standby	This input activates the <i>Dual Mutual Standby</i> functionality. This is described fully in the section entitled <i>Module</i> elsewhere in this manual.
ECU Specific 1,2,3	These inputs are used with some supported engine files only for electronic CAN engines. They are used to instruct the engine file to perform certain function controls on the engine without the need to change a configuration on the module. Activating the relevant input allows the engine file to exercise a special operation on the engine.
EJP1	For the French EJP (Effacement Jours de Pointe) tariff system. This input is functionally identical to <i>Remote Start Off Load</i> . When this input is active, operation is similar to the 'Remote Start on load' function except that the generator is not instructed to take the load. This function is also used where an engine only run is required e.g. for exercise.
EJP2	For the French EJP (Effacement Jours de Pointe) tariff system. This input is functionally identical to <i>Remote Start On Load</i> . In auto mode, the module performs the start sequence and transfers load to the generator. In Manual mode, the load is transferred to the generator if the engine is already running, however in manual mode, this input does not generate start/stop requests of the engine.
Escape Mode	This input function is supported on specific new engines for Maintenance / Regeneration requirements, used when the engine is running off-load. When the Escape Mode input is active, some of the CAN engine alarms are overridden to restore the engine in alarm free mode at no load, to provide a specific maintenance / regeneration type operation to the CAN engine.



Parameters continued overleaf...

Function	Description
External Panel Lock	<p>▲ NOTE: External control sources (i.e. Simulate Start Button) are not affected by the external panel lock input and continue to operate normally.</p> <p>This input is used to provide security to the installation. When the External Panel lock input is active, the module does not respond to operation of the Mode select or Start buttons. This allows the module to be placed into a specific mode (such as Auto) and then secured. The operation of the module is not affected, and the operator is still able to view the various instrumentation pages etc. (<i>Front panel configuration access is still possible while the system lock is active</i>).</p>
Fuel Tank Bund Level High	This input is used to provide protection against fuel leakage, where a level switch is fitted to the fuel tank bund. The action for this alarm is configurable under the <i>Engine Protections</i> page in the module configuration.
Generator Closed Auxiliary IEEE 37.2 - 3 Checking or Interlocking Relay	This input is used to provide feedback to allow the module to give true indication of the contactor or circuit breaker switching status. It must be connected to the generator load switching device auxiliary contact.
Generator Load Inhibit IEEE 37.2 - 52 AC Circuit Breaker	<p>▲ NOTE: This input only operates to control the generator-switching device if the module load switching logic is attempting to load the generator. It does not control the generator switching device when the mains supply is on load.</p> <p>This input is used to prevent the module from loading the generator. If the generator is already on load, activating this input causes the module to unload the generator. Removing the input allows the generator to be loaded again.</p>
Inhibit Scheduled Run IEEE 37.2 - 3 Checking Or Interlocking Relay	This input is used to provide a mean of disabling a scheduled run.
Inhibit SMS Remote Start	This input is used to provide a means of disabling remote starts by SMS
Lamp Test	This input is used to provide a test facility for the front panel indicators fitted to the module. When the input is activated all LEDs illuminate.
Low Fuel Level Switch IEEE 37.2 - 71 Liquid Level Switch	This input is used to allow feedback for low fuel level.
Main Config Select	This input is used to select the <i>Main</i> configuration when <i>Alternative Configurations</i> are enabled.
Mains Closed Auxiliary IEEE 37.2 - 3 Checking or Interlocking Relay 	This input is used to provide feedback to allow the module to give true indication of the contactor or circuit breaker switching status. It is connected to the mains load switching device auxiliary contact. Incorrect application of this signal does not trigger an alarm condition; it is used solely for indication of the load switch status.

Parameters continued overleaf...


Function	Description
Mains Load Inhibit IEEE 37.2 - 3 Checking or Interlocking Relay 	<p>⚠️ NOTE: This input only operates to control the mains switching device if the module load switching logic is attempting to load the mains. It does not control the mains switching device when the generator is on load.</p> <p>This input is used to prevent the module from loading the mains supply. If the mains supply is already on load activating this input causes the module to unload the mains supply. Removing the input allows the mains to be loaded again.</p>
Manual Breaker Mode	When breaker control is set to <i>Active On Input</i> , this input is used to activate the <i>Manual Breaker Control</i> .
Manual Restore Contact IEEE 37.2 - 3 Checking or Interlocking Relay 	Used to 'hold off' transfer back to the mains after a mains failure and keep the generator on load. Transfer back to the mains supply is held off in <i>Auto mode</i> while the input is present. Typically, a key switch provides this input with <i>spring return to closed</i> functionality.
Oil Pressure Switch IEEE 37.2 – 63 Pressure Switch	A digital normally open or closed oil pressure switch gives this input. It allows low oil pressure protection.
Remote Start Off Load	If this input is active, operation is similar to the 'Remote Start on load' function except that the generator is not instructed to take the load. This function is used where an engine only run is required e.g. for exercise.
Remote Start On Load	When in auto mode, the module performs the start sequence and transfer load to the generator. In Manual mode, the load is transferred to the generator if the engine is already running, however in manual mode, this input does not generate start/stop requests of the engine.
Reset Maintenance Alarm 1	Provides an external digital input to reset the maintenance alarm 1
Reset Maintenance Alarm 2	Provides an external digital input to reset the maintenance alarm 2
Reset Maintenance Alarm 3	Provides an external digital input to reset the maintenance alarm 3
Simulate Auto Button	<p>⚠️ NOTE: If a call to start is present when AUTO MODE is entered, the starting sequence begins. Call to Start comes from a number of sources depending upon module type and configuration and includes (but is not limited to) : Remote start input present, Mains failure, Scheduled run, Auxiliary mains failure input present, Telemetry start signal from remote locations.</p> <p>This input mimics the operation of the 'Auto' button and is used to provide a remotely located Auto mode push button.</p>
Simulate Lamp Test Button	This input is used to provide a test facility for the front panel indicators fitted to the module. When the input is activated all LED's illuminate. The input also serves a second function, in that it also provides a mute signal to silence the audible alarm. The input is recognised by the module as though it was the Push button on the module itself being operated.
Simulate Mains Available 	This function is provided to override the module's internal monitoring function. If this input is active, the module does not respond to the state of the incoming AC mains supply.
Simulate Manual Button	This input mimics the operation of the 'Manual' button and is used to provide a remotely located Manual mode push button.
Simulate Start Button	This input mimics the operation of the 'Start' button and is used to provide a remotely located start push button.
Simulate Stop Button	This input mimics the operation of the 'Stop' button and is used to provide a remotely located stop/reset push button.

Parameters continued overleaf...

Function	Description
Simulate Test on Load Button	This input mimics the operation of the 'Test' button and is used to provide a remotely located Test on load mode push button.
Smoke Limiting IEEE 37.2 – 18 Accelerating or Decelerating Device	This input instructs the module to give a <i>run at idle speed</i> command to the engine either via an output configured to <i>smoke limit</i> or by data commands when used with supported electronic engines.
Start in Manual Mode	Combined function input that instructs the module to enter MANUAL MODE and also perform the <i>START</i> function. Once the input is active, the module is placed into manual mode, and the generator starts.
Stop and Panel Lock	Combined function input that instructs the module to enter STOP mode and also perform the <i>Panel Lock</i> function. Once the input is active, the module does not respond to operation of the mode select or start buttons. The operator is still able to view the various instrumentation pages etc. (<i>Front panel configuration access is still possible while the system lock is active</i>).
Transfer To Generator/Open Mains IEEE 37.2 - 52 AC Circuit Breaker 	This input is used to transfer the load to the generator when running in MANUAL MODE
Transfer To Mains/ Open Generator IEEE 37.2-52 AC Circuit Breaker 	This input is used to transfer the load to the mains supply when running in MANUAL MODE
Water in Fuel	Some engines are fitted with water separators, that have a switch indicator for water detection. This input is used to provide protection against high water content in the fuel, where a switch is fitted to the fuel filter. The action for this alarm is configurable under the <i>Engine Protections</i> page in the module configuration.

2.5 OUTPUTS

The *Outputs* section is subdivided into smaller sections. Select the required section with the mouse.



2.5.1 DIGITAL OUTPUTS

These labels match the typical wiring diagram.

As this example shows outputs A and B are *greyed out* as the engine type is selected as *Conventional Diesel*.

Parameter	Description
Source	Select the output source to control the state of the output See section entitled <i>Output Sources</i> for details of all available functions
Polarity	Select the digital output polarity: De-Energise: When the output source is true, the output deactivates. Energise: When the output source is true, the output activates.

2.5.2 VIRTUAL LEDS

The Virtual LEDs provide a configuration of 'status' items. These items are not available for viewing on the module but are seen in the SCADA section of the PC software or read by third party systems (i.e. BMS or PLCs) using the Modbus protocol.

Virtual LEDs

LED Configuration

	Source	Polarity
LED 1	Not Used	Lit
LED 2	Not Used	Lit
LED 3	Not Used	Lit
LED 4	Not Used	Lit
LED 5	Not Used	Lit
LED 6	Not Used	Lit
LED 7	Not Used	Lit
LED 8	Not Used	Lit
LED 9	Not Used	Lit
LED 10	Not Used	Lit
LED 11	Not Used	Lit
LED 12	Not Used	Lit
LED 13	Not Used	Lit
LED 14	Not Used	Lit
LED 15	Not Used	Lit
LED 16	Not Used	Lit
LED 17	Not Used	Lit
LED 18	Not Used	Lit
LED 19	Not Used	Lit
LED 20	Not Used	Lit

Parameter	Description
Source	Select the output source to control the state of the output See section entitled <i>Output Sources</i> for details of all available functions
Polarity	Select the digital input polarity: Lit: When the output source is true, the virtual LED activates Unlit: When the output source is true, the virtual LED deactivates.

2.5.3 OUTPUT SOURCES

The list of output sources available for configuration of the module digital outputs.




Under the scope of IEEE 37.2, *function numbers* is also used to represent functions in microprocessor devices and software programs. Where the DSE output functions is represented by IEEE 37.2, the function number is listed below.

The outputs are in alphabetical order with the *parameter* first. For instance for over frequency output, it's listed as *Generator Over*

 = Only available on DSE7420 MKII AMF Modules

Output Source	Activates...	Is Not Active....
Not Used	The output does not change state (Unused)	
Air Flap Relay	Normally used to control an air flap, this output becomes active upon an Emergency Stop or Over-speed situation.	Inactive when the set has come to rest
Alarm Mute	This input is used to silence the audible alarm from an external source such as a remote mute switch.	
Alarm Reset	This input is used to reset any latched alarms from a remote location. It is also used to clear any latched warnings which may have occurred (if configured) without having to stop the engine.	
Alternative Config 1, 2, 3, 4, 5 Selected	Active when the alternative configuration is selected.	
Analogue Input A,B,C,D,E,F (Digital)	Active when the analogue input A,B,C,D,E,F configured to digital is active.	
Arm Safety On Alarms	Becomes active at the end of the <i>safety delay</i> timer whereupon all alarms configured to 'From Safety On' become active	Inactive when : <ul style="list-style-type: none"> When the set is at rest In the starting sequence before the Safety Delay timer has expired
Audible Alarm IEEE 37.2 – 74 Alarm Relay	Use this output to activate an external sounder or external alarm indicator. Operation of the Mute pushbutton resets this output once activated	Inactive if no alarm condition is active or if the Mute pushbutton was pressed
Auto Restore Inhibit	Active when the <i>Auto Restore Inhibit</i> digital input is active	
Auto Start Inhibit	Active when the <i>Auto-Start Inhibit</i> function is active	
Auxiliary Mains Fail	Active when the <i>Auxiliary Mains Fail</i> input function is active	
AVR Data Fail	Active when the <i>AVR Data Fail</i> alarm is active, indicating communication failure with the CAN AVR.	
AVR Fault	Active when the <i>AVR Fault</i> alarm is active, indicating an alarm detection on the CAN AVR.	
Battery High Voltage IEEE 37.2 – 59 DC Overvoltage Relay	This output indicates that a Battery Over voltage alarm has occurred	Inactive when battery voltage is not High
Battery Low Voltage IEEE 37.2 – 27 DC Undervoltage Relay	This output indicates that a Battery Under Voltage alarm has occurred.	Inactive when battery voltage is not Low
Calling For Scheduled Run	Active during a <i>Scheduled Run</i> request from the inbuilt <i>Scheduler</i> .	

Parameters continued overleaf...

Output Source	Activates...	Is Not Active....
Charge Alternator Failure Shutdown	Active when the charge alternator shutdown alarm is active	
Charge Alternator Failure Warning	Active when the charge alternator warning alarm is active	
Check Sync	Active when the <i>Sync Check</i> is active during the generator to mains transition.	
Clock Pulse	Also called 'heartbeat,' it activates and deactivates every few milliseconds to indicate that the module is powered up. It stops energising during write configuration to the module.	
Close Gen Output IEEE 37.2 – 52 AC Circuit Breaker	Used to control the load switching device. Whenever the module selects the generator to be on load this control source is activated.	Inactive whenever the generator is not required to be on load
Close Gen Output Pulse IEEE 37.2 – 52 AC Circuit Breaker	Used to control the load switching device. Whenever the module selects the generator to be on load this control source is activated for the duration of the Breaker Close Pulse timer, after which it becomes inactive again.	
Close Mains Output IEEE 37.2 – 52 AC Circuit Breaker 	Used to control the load switching device. Whenever the module selects the mains to be on load this control source is activated.	The output is inactive whenever the mains is not required to be on load
Close Mains Output Pulse IEEE 37.2 – 52 AC Circuit Breaker 	Used to control the load switching device. Whenever the module selects the mains to be on load this control source is activated for the duration of the Breaker Close Pulse timer, after which it becomes inactive again.	
Combined Mains Failure 	Active when the mains supply is out of limits OR the input for Auxiliary Mains Failure is active	
Combined Maintenance Alarm	Active when any of the maintenance alarm is active.	
Combined Under and Over Frequency Alarm	Active when an <i>Under-Frequency</i> or <i>Over-Frequency Shutdown</i> alarm is active	
Combined Under and Over Frequency Warning	Active when an <i>Under-Frequency</i> or <i>Over-Frequency Warning</i> alarm is active	
Combined Under and Over Voltage Alarm	Active when an <i>Under-Voltage</i> or <i>Over-Voltage Shutdown</i> alarm is active	
Combined Under and Over Voltage Warning	Active when an <i>Under-Voltage</i> or <i>Over-Voltage Warning</i> alarm is active	
Common Alarm	Active when one or more alarms (of any type) are active	The output is inactive when no alarms are present
Common Electrical Trip	Active when one or more <i>Electrical Trip</i> alarms are active	The output is inactive when no shutdown alarms are present
Common Shutdown	Active when one or more <i>Shutdown</i> alarms are active	The output is inactive when no shutdown alarms are present
Common Warning	Active when one or more <i>Warning</i> alarms are active	The output is inactive when no warning alarms are present
Configurable CAN x Instrument Active	Active when the relevant Configurable CAN Instrument function is active.	
Coolant Cooler Control	Active by the <i>Coolant Cooler Control</i> in conjunction with the Coolant Temperature Sensor	

Parameters continued overleaf...

Output Source	Activates...	Is Not Active....
Coolant Heater Control	Active by the <i>Coolant Heater Control</i> in conjunction with the <i>Coolant Temperature Sensor</i>	
Coolant Temperature Switch IEEE 37.2 – 26 Apparatus Thermal Device	Active when the <i>Coolant Temperature Switch</i> input is active	
Cooling Down	Active when the Cooling timer is in progress	
Data Logging Active	Active when data is being logged	Inactive when: <ul style="list-style-type: none"> • Data logging is disabled. • The engine is at rest and the option <i>Only Log When Engine Is Running</i> is enabled. • The internal memory of the module becomes full, and the option <i>Keep Oldest Data</i> is enabled.
DEF Level Low	Active when <i>DEF Level Low CAN</i> alarm is active.	
DEF Level Low Alarm	Active when <i>DEF Level Low Alarm</i> is active.	
Digital Input A, B, C, D, E, F, G & H	Active when the relevant digital input is active	
Display Heater Fitted and On	Active when the display heater is on	
DPF Forced Regeneration Requested	Active when the <i>DPF Force Regeneration</i> is active	
DPF Non Mission State	Active when the <i>DPF Non-Mission State</i> is active	
DPF Regeneration In Progress	Active when the <i>DPF Regeneration</i> is in progress	
DPF Regeneration Interlock Active	Active when the <i>DPF Regeneration Interlock</i> is active	
DPTC Filter	Active when the diesel particulate filter CAN alarm is active	
Droop Enable	Active when an input configured to <i>Droop Enable</i> is active or if <i>Droop Enable</i> has been activated in the module configuration (CAN engine only)	
Dual Mutual Active	Active when the <i>Dual Mutual Standby</i> is active	
Dual Mutual Input	Active when the <i>Dual Mutual Standby</i> digital input is active	
Dual Mutual On Load	Active when the generator is running due to <i>Dual Mutual Standby</i>	
Dual Mutual Standby	Active when the generator is in standby in <i>Dual Mutual Standby</i>	
Dummy Load Control (1-5)	Becomes active when the engine kW falls below the Dummy Load Control Trip Setting.	Inactive when the engine kW returns to above the Dummy Load Control Return setting.
Earth Fault Trip Alarm IEEE 37.2 – 51G or 51N Generator IDMT Earth Fault Relay	Active when the <i>Earth Fault Protection Alarm</i> is active.	
ECU (ECM) Data Fail	Becomes active when no CAN data is received from the ECU after the safety delay timer has expired	Inactive when: <ul style="list-style-type: none"> • CAN data is being received • The set is at rest During the starting sequence before the safety delay timer has expired
ECU (ECM) Power	Used to switch an external relay to power the CAN ECU (ECM). Exact timing of this output is dependent upon the type of the engine ECU (ECM)	
ECU (ECM) Shutdown	The engine ECU (ECM) has indicated that a Shutdown alarm is present.	Inactive when no Shutdown alarm from the ECU (ECM) is present

Parameters continued overleaf...

Output Source	Activates...	Is Not Active....
ECU (ECM) Stop	Active when the DSE controller is requesting that the CAN ECU (ECM) stops the engine.	
ECU (ECM) Warning	The engine ECU (ECM) has indicated that a Warning alarm is present.	Inactive when no Warning alarm from the ECU (ECM) is present
ECU Pre-Heat	Active when the <i>ECU Pre-Heat</i> is active.	
ECU Specific 1,2,3	Active when the relevant <i>ECU Specific</i> input is active.	
EJP1 / EJP2	Active when an input configured for <i>EJP1</i> or <i>EJP2</i> is active	
Emergency Stop IEEE 37.2 – 5 Stopping Device	Active when the <i>Emergency Stop</i> input has been activated	
Energise To Stop	Normally used to control an <i>Energise to Stop</i> solenoid, this output becomes active when the controller wants the set to stop running.	Becomes inactive a configurable amount of time after the set has stopped. This is the <i>ETS hold time</i> .
Escape Mode	Active when <i>Escape Mode</i> function is active through a digital input or from the module's Running Editor.	
External Panel Lock	Active when the <i>External Panel Lock</i> digital input is active	
Fail to Close Generator IEEE 37.2 – 52B AC Circuit Breaker Position (Contact Open When Breaker Closed)	Active when the <i>Generator Closed Auxiliary</i> input fails to become active after the <i>Close Generator Output</i> or <i>Close Generator Output Pulse</i> becomes active	
Fail to Close Mains IEEE 37.2 – 52B AC Circuit Breaker Position (Contact Open When Breaker Closed)	Active when the <i>Mains Closed Auxiliary</i> input fails to become active after the <i>Close Mains Output</i> or <i>Close Mains Output Pulse</i> becomes active	
Fail To Start IEEE 37.2 - 48 Incomplete Sequence Relay	Becomes active if the set is not seen to be running after the configurable number of start attempts	
Fail To Stop IEEE 37.2 - 48 Incomplete Sequence Relay	If the set is still running a configurable amount of time after it has been given the stop command, the output becomes active. This configurable amount of time is the <i>Fail to Stop Timer</i> .	
Fail To Synchronise	Active when the <i>Fail to Sync Alarm</i> is active	
Fan Control	Energises when the engine becomes available (up to speed and volts). This output is designed to control an external cooling fan. When the engine stops, the cooling fan remains running for the duration of the Fan Overrun Delay.	
Flexible Sensor A, B, C, D, E or F High Alarm	Active when the analogue input value rises above the <i>Flexible Sensor High Alarm</i> set point.	
Flexible Sensor A, B, C, D, E or F High Pre-Alarm	Active when the analogue input value rises above the <i>Flexible Sensor High Pre-Alarm</i> set point.	
Flexible Sensor A, B, C, D, E or F Low Alarm	Active when the analogue input value falls below the <i>Flexible Sensor Low Alarm</i> set point.	
Flexible Sensor A, B, C, D, E or F Low Pre-Alarm	Active when the analogue input value falls below the <i>Flexible Sensor Low Pre-Alarm</i> set point.	
Flexible Sensor A, B, C, D, E or F Open Circuit	Active when the <i>Flexible Sensor Open Circuit</i> alarm becomes active.	
Fuel Level High Alarm	Active when the High Fuel Level Alarm is active.	
Fuel Level High Pre-Alarm	Active when the High Fuel Level Pre-Alarm is active.	
Fuel Level Low Alarm	Active when the Low Fuel Level Alarm is active.	
Fuel Level Low Pre-Alarm	Active when the Low Fuel Level Pre-Alarm is active.	



Parameters continued overleaf...

Output Source	Activates...	Is Not Active....
Fuel Pump Control IEEE 37.2 – 71 Level Switch	Becomes active when the <i>Fuel level</i> falls below the <i>Fuel Pump Control ON</i> setting and is normally used to transfer fuel from the bulk tank to the day tank.	If the output is already active it becomes inactive when the <i>Fuel level</i> is above the <i>Fuel Pump Control OFF</i> settings.
Fuel Relay	Becomes active when the controller requires the governor/fuel system to be active.	Becomes inactive whenever the set is to be stopped, including between crank attempts, upon controlled stops and upon fault shutdowns.
Fuel Sensor Open Circuit	Active when the <i>Fuel Sensor Open Circuit</i> alarm becomes active	
Fuel Tank Bund Level High	Active when the <i>Fuel Bund Level High Alarm</i> input is active.	
Fuel Usage Alarm IEEE 37.2 – 80 Flow Switch	Active when the <i>Fuel Usage</i> alarm becomes active	
Gas Choke On	Becomes active during starting for the duration of the Gas Choke timer. Normally used to choke a gas engine.	Inactive at all other times
Gas Ignition	Becomes active during starting.	Becomes inactive a configurable amount of time after the <i>Fuel Relay</i> becomes inactive. This is the <i>Gas Ignition Off</i> timer.
Generator Loading Frequency Not Reached	Indicates that the generator frequency has not reached the configured <i>Loading Frequency</i> during the starting process.	
Generator Loading Voltage Not Reached	Indicates that the generator voltage has not reached the configured <i>Loading Voltage</i> during the starting process.	
Gen Over Frequency Overshoot Alarm IEEE 37.2 – 81 Frequency Relay	Becomes active when the <i>Over Frequency Overshoot</i> alarm is active	
Gen Over Frequency Overshoot Warning IEEE 37.2 – 81 Frequency Relay	Becomes active when the <i>Over Frequency Overshoot Warning</i> alarm is active	
Generator Available	Becomes active when the generator is available to take load.	Inactive when <ul style="list-style-type: none"> • <i>Loading voltage</i> and <i>loading frequency</i> have not been reached • After <i>electrical trip</i> alarm • During the starting sequence before the end of the warming timer.
Generator Closed Aux	Active when the <i>Generator Closed Auxiliary</i> input is active	
Generator Excite IEEE 37.2 – 31 Separate Excitation Device	Used to control the excitation of the main alternator (AC).	Becomes inactive when the set is stopped.
Generator High Voltage Alarm IEEE 37.2 – 59 AC Overvoltage Relay	Active when the <i>High Voltage Electrical Trip</i> alarm is active	
Generator High Voltage Warning IEEE 37.2 – 59 AC Overvoltage Relay	Active when the <i>High Voltage Warning</i> alarm is active	



Parameters continued overleaf...

Output Source	Activates...	Is Not Active....
Generator High Volts Shutdown IEEE 37.2 – 59 AC Overvoltage Relay	Active when the <i>High Voltage Shutdown</i> alarm is active	
Generator Load Inhibit	Active when the <i>Generator Load Inhibit</i> input is active	
Generator Low Voltage Shutdown/Electrical Trip IEEE 37.2 – 27 AC Undervoltage Relay	Active when the generator voltage falls below the <i>Low Voltage Alarm Trip</i> level	Inactive when <ul style="list-style-type: none"> • The set is stopped • During starting sequence before the safety delay time has expired.
Generator Low Voltage Warning IEEE 37.2 – 27 AC Undervoltage Relay	Active when the generator voltage falls below the <i>Low Voltage Pre-Alarm Trip</i> level	Inactive when <ul style="list-style-type: none"> • The set is stopped • During starting sequence before the safety delay time has expired.
Generator Over Frequency Alarm IEEE 37.2 – 81 Frequency Relay	Active when the generator frequency exceeds the <i>Over Frequency Shutdown Trip</i> level.	
Generator Over Frequency Delayed Alarm IEEE 37.2 – 81 Frequency Relay	Active when the generator frequency exceeds the configured <i>Over Frequency Shutdown Trip</i> level for a duration longer than the set <i>Overshoot Delay</i> timer.	
Generator Over Frequency Delayed Warning IEEE 37.2 – 81 Frequency Relay	Active when the generator frequency exceeds the configured <i>Over Frequency Warning Trip</i> level for a duration longer than the set <i>Overshoot Delay</i> timer.	
Generator Phase Rotation Alarm IEEE 37.2 – 47 Phase Sequence Relay	Active when the detected generator phase sequence is different than the configured <i>Generator Phase Rotation</i>	
Generator Reverse Power IEEE 37.2 – 32 Directional Power Relay	Active when the <i>Generator Reverse Power</i> alarm is active	
HEST Active	Active when the High Exhaust System Temperature CAN alarm is active	
High Coolant Temperature Electrical Trip IEEE 37.2 – 26 Apparatus Thermal Device	Active when the <i>Coolant Temperature</i> exceeds the configured <i>High Coolant Temperature Electrical Trip</i> level	
High Coolant Temperature Shutdown IEEE 37.2 – 26 Apparatus Thermal Device	Active when the <i>Coolant Temperature</i> exceeds the configured <i>High Coolant Temperature Shutdown</i> level	
High Coolant Temperature Warning IEEE 37.2 – 26 Apparatus Thermal Device	Active when the <i>Coolant Temperature</i> exceeds the configured <i>High Coolant Temperature Warning</i> level	
High Inlet Temperature Shutdown	Active when the High Inlet Temperature Shutdown is active on the module.	
High Inlet Temperature Warning	Active when the High Inlet Temperature Warning is active on the module.	

Parameters continued overleaf...

Output Source	Activates...	Is Not Active....
Inhibit Scheduled run	Active when the Inhibit Scheduled run input is active	
Inhibit SMS Start	Active when the input Inhibit SMS Start input is active	
Interlock Override 	This function is used to bypass the generator and mains breakers' electrical interlock during the <i>Closed Transition</i> to allow short term paralleling. This output becomes active when the <i>Synchronisation Delay</i> activates and remains active until the <i>Interlock Override Off</i> timer is terminated.	
kW Overload Alarm	Active when the measured kW are above the setting of the <i>kW overload alarm</i> . Used to give alarms on overload, control a dummy load switch or for load shedding functionality.	
Lamp Test	Active when the lamp test is activated by a digital input or by pressing the <i>Mute/Lamp Test</i> control button	
Load Shedding Control (1-5)	Becomes active when the engine kW exceeds Load Shedding Control Trip Setting.	Inactive when the engine kW returns to below the Load Shedding Control Return setting.
Loading Frequency Not Reached	Active when the generator frequency has not reached the configured <i>Loading Frequency</i> during the starting process.	
Loading Voltage Not Reached	Active when the generator voltage has not reached the configured <i>Loading Voltage</i> during the starting process.	
Loss of Mag Pickup Signal	Active when the controller senses the loss of signal from the magnetic pickup probe	
Louvre Control	Active when the fuel relay becomes active. Normally used to drive ventilation louvres for the generator set	
Low Coolant Temperature IEEE 37.2 – 26 Apparatus Thermal Device	Active when the <i>Coolant Temperature</i> falls below the <i>Low Coolant Temperature alarm</i> setting	
Low Fuel Level IEEE 37.2 – 71 Level Switch	Active when the <i>Low Fuel Level</i> alarm becomes active	
Low Load	Active when the <i>Low Load</i> alarm is active.	
Low Oil Pressure Shutdown IEEE 37.2 - 63 Pressure Switch	Active when the <i>Oil Pressure</i> falls below the <i>Low Oil Pressure Shutdown</i> setting	Inactive when <ul style="list-style-type: none"> • The set is stopped • During starting sequence before the safety delay time has expired.
Low Oil Pressure Warning IEEE 37.2 - 63 Pressure Switch	Active when the <i>Oil Pressure</i> falls below the <i>Low Oil Pressure Warning</i> setting	Inactive when <ul style="list-style-type: none"> • The set is stopped • During starting sequence before the safety delay time has expired.
Main Config Selected	Active when the main configuration is active	
Mains Closed Aux	Active when the <i>Mains Closed Auxiliary</i> input is active	
Mains Failure IEEE 37.2 - 81 Frequency Relay IEEE 37.2 – 27 AC Undervoltage Relay IEEE 37.2 – 59 AC Overvoltage Relay 	The output indicates that one or more of the module's sources of determining mains failure is active.	
Mains High Frequency IEEE 37.2-81 Frequency Relay	Active when the mains frequency exceeds the <i>High Frequency</i> setting	


Parameters continued overleaf...

Output Source	Activates...	Is Not Active....
Mains High Voltage IEEE 37.2 – 59 AC Overvoltage Relay	Active when the mains voltage exceeds the <i>High Voltage</i> setting	
Mains Load Inhibit	Active when the <i>Mains Load Inhibit</i> input is active	
Mains Low Frequency IEEE 37.2 -81 Frequency Relay	Active when the mains frequency falls below the <i>Low Frequency</i> setting	
Mains Low Voltage IEEE 37.2 – 27 AC Undervoltage Relay	Active when the mains voltage falls below the <i>Low Voltage</i> setting	
Mains Phase Rotation Alarm	Active when the detected mains phase sequence is different than the configured <i>Mains Phase Rotation</i>	
Maintenance Alarm 1, 2 or 3 Due	Active when the relevant maintenance alarm is due.	
Manual Restore Contact	Active when the manual restore contact input is active	
MPU Open Circuit	This output indicates that the module has detected an open circuit failure in the Magnetic Pickup transducer circuit.	
MSC Compatibility	Active when the <i>MSC Compatibility</i> alarm is active	
MSC Failure	Active when the <i>MSC Failure</i> alarm is active	
MSC ID Error	Active when the <i>MSC ID Error</i> alarm is active	
MSC Priority Error	Active when the <i>MSC Priority Error</i> alarm is active	
Negative Phase Sequence Alarm	Active when the <i>Negative Phase Sequence</i> alarm is active	
Negative VAr Alarm IEEE 37.2 – 40 Field Under Excitation Relay	Active when the negative VAr falls below the configured Generator <i>Negative VAr Alarm</i> level for a duration longer than the set <i>Delay</i> timer	
Negative VAr Warning IEEE 37.2 – 40 Field Under Excitation Relay	Active when the negative VAr falls below the configured Generator <i>Negative VAr Pre-Alarm</i> level for a duration longer than the set <i>Delay</i> timer	
Oil Pressure Sensor Open Circuit	Active when the <i>Oil Pressure Sensor</i> is detected as being open circuit.	
Oil Pressure Switch	Active when the oil pressure switch input is active	
Open Gen Output IEEE 37.2 – 52 AC Circuit Breaker	Used to control the load switching device. Whenever the module selects the generator to be off load this control source is activated.	Inactive whenever the generator is required to be on load
Open Gen Output Pulse IEEE 37.2 – 52 AC Circuit Breaker	Used to control the load switching device. Whenever the module selects the generator to be off load this control source is activated for the duration of the Breaker Open Pulse timer, after which it becomes inactive again.	
Open Mains Output IEEE 37.2 – 52 AC Circuit Breaker 	Used to control the load switching device. Whenever the module selects the mains to be off load this control source is activated.	The output is inactive whenever the mains is required to be on load
Open Mains Output Pulse IEEE 37.2 – 52 AC Circuit Breaker 	Used to control the load switching device. Whenever the module selects the mains to be off load this control source is activated for the duration of the Breaker Open Pulse timer, after which it becomes inactive again.	
Over Current IDMT Alarm	Active when the <i>Over Current IDMT</i> alarm is active	
Over Current Immediate Warning	Active when the <i>Over Current Immediate Warning</i> alarm is active	

Parameters continued overleaf...


Output Source	Activates...	Is Not Active....
Over Frequency Runaway <i>IEEE 37.2 -81 Frequency Relay</i>	Active when the <i>Over Frequency Runaway</i> alarm is active	
Over Frequency Warning <i>IEEE 37.2 -81 Frequency Relay</i>	Active when the <i>Over Frequency Warning</i> alarm is active	
Over Speed Runaway <i>IEEE 37.2 – 12 Over Speed Device</i>	Active when the <i>Over Speed Runaway</i> alarm is active	
Over Speed Shutdown <i>IEEE 37.2 – 12 Over Speed Device</i>	Active when the <i>Over Speed Shutdown</i> alarm is active	
Over Speed Warning <i>IEEE 37.2 – 12 Over Speed Device</i>	Active when the <i>Over Speed Warning</i> alarm is active	
Overspeed Delayed Alarm <i>IEEE 37.2 – 12 Over Speed Device</i>	Active when the <i>Over Speed Delayed</i> alarm is active	
Overspeed Delayed Warning <i>IEEE 37.2 – 12 Over Speed Device</i>	Active when the <i>Over Speed Delayed Warning</i> alarm is active	
Overspeed Overshoot Alarm <i>IEEE 37.2 – 12 Over Speed Device</i>	Active when the <i>Over Speed Overshoot</i> alarm is active	
Overspeed Overshoot Warning <i>IEEE 37.2 – 12 Over Speed Device</i>	Active when the <i>Over Speed Overshoot Warning</i> alarm is active	
PLC Output Flag 1-100	Active when the <i>PLC Flag</i> is active	
Positive VAr Alarm	Active when the positive VAr exceeds the configured Generator <i>Positive VAr Alarm</i> level for a duration longer than the set <i>Delay</i> timer	
Positive VAr Warning	Active when the positive VAr exceeds the configured Generator <i>Positive VAr Pre-Alarm</i> level for a duration longer than the set <i>Delay</i> timer	
Preheat During Preheat Timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> • The set is stopped • The preheat timer has expired
Preheat Until End Of Cranking	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> • The set is stopped • The set has reached <i>crank disconnect</i> conditions
Preheat Until End Of Safety Timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> • The set is stopped • The set has reached the end of the <i>safety delay</i> timer
Preheat Until End of Warming Timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> • The set is stopped • The set has reached the end of the <i>warming</i> timer
Protections Disabled	Active when protections are turned off (Unticked) in the configuration.	
Remote Control 1-10	A series of output sources that are controlled by remote control in the SCADA section of the software, used to control external circuits.	
Remote Start Off Load	Active when the <i>Remote Start Off Load</i> input is active	
Remote Start On Load	Active when the <i>Remote Start On Load</i> input is active	
Reset Maintenance 1, 2 or 3	Active when the relevant <i>Maintenance Alarm Reset</i> is active	
Scheduled Auto Start Inhibit	Active when the <i>Inhibit Scheduled Run</i> input is active	
SCR Inducement	Active when <i>SCR Inducement CAN Alarm</i> is active	
Screensaver Active	Active when the <i>Screensaver</i> is active on the module.	
Shutdown Blocked	Becomes active when protections are disabled and one of the parameters goes out of limits	
Simulate Auto Button	Active when the <i>Simulate Auto Button</i> digital input is active	
Simulate Close Gen Breaker	Active when the <i>Simulate Close Gen Breaker</i> digital input is active	

Parameters continued overleaf...

Output Source	Activates...	Is Not Active....
Simulate Lamp Test	Active when the <i>Simulate Lamp Test</i> input digital is active	
Simulate Mains Available	Active when the <i>Simulate Mains Available</i> digital input is active	
Simulate Manual Button	Active when the <i>Simulate Manual</i> digital input is active	
Simulate Open Gen Breaker	Active when the <i>Simulate Open Gen Breaker</i> digital input is active	
Simulate Start Button	Active when the <i>Simulate Start Button</i> digital input is active	
Simulate Stop Button	Active when the <i>Simulate Stop Button</i> digital input is active	
Simulate Test On Load Button	Active when the <i>Simulate Test On Load Button</i> digital input is active	
Smoke Limiting	Becomes active when the controller requests that the engine runs at idle speed. As an output, this is used to give a signal to the <i>Idle Speed Input</i> on the engine speed governor (if available)	Becomes inactive when the controller requests that the engine runs at rated speed.
SMS Remote Start Off Load	Active when the set receives an SMS message to start and run off load	
SMS Remote Start On Load	Active when the set receives an SMS message to start and run load	
Start Relay IEEE 37.2 – 54 Turning Gear Engaging Device	Active when the controller requires the cranking of the engine.	
Stop and Panel lock	Active when the <i>Stop And Panel Lock</i> digital input is active	
System in Auto Mode	Active when Auto mode is selected	
System in Manual Mode	Active when Manual mode is selected	
System in Stop Mode	Active when Stop mode is selected	
System in Test Mode	Active when Test On Load mode is selected	
Telemetry Active	Active when the communication port is live and for a short time after transmission stops. Used as a relay or LED source.	
Telemetry Data Active	Active when data is being transmitted. This output changes continuously state (flash) upon data transfer. Normally used as an LED source rather than a relay source as the signal flashes repeatedly. For a similar source more suited to drive a relay, see <i>Telemetry Active</i> .	
Temperature Sensor Open Circuit	Active when the <i>Temperature Sensor Open Circuit</i> alarm is active	
Under Frequency Shutdown \ Electrical Trip	Active when any of the <i>Generator Under Frequency Shutdown</i> or <i>Electrical Trip</i> alarm are active	
Under Frequency Warning	Active when the <i>Generator Under Frequency Warning</i> alarm is active	
Under Speed Shutdown \ Electrical trip	Active when any of the <i>Underspeed Shutdown</i> or <i>Electrical Trip</i> alarms are active	
Under Speed Warning	Active when the <i>Underspeed Warning</i> alarm is active.	
Waiting For Manual Restore 	Becomes active when the generator is on load and the mains supply is healthy, but an input configured to Manual Restore is active. This is used to signal to an operator that action is required before the set transfers back to the mains supply.	
Water in Fuel	Active when the <i>Water in Fuel</i> input is active, or when the module is informed of the <i>Water in Fuel</i> CAN message from the ECU.	


2.6 TIMERS

Many timers are associated with alarms. Where this occurs, the timer for the alarm is located on the same page as the alarm setting. Timers not associated with an alarm are located on the timers page. The *Timers* page is subdivided into smaller sections. Select the required section with the mouse.



2.6.1 START TIMERS


Start Timers



Click and drag to change the setting. Timers increment in steps of 1 second up to one minute, then in steps of 30 seconds up to 30minutes, then in steps of 30 minutes thereafter (where allowed by the limits of the timer).




= Only available on DSE7420 MKII AMF Modules


Timer	Description
Remote Start Off Load	The amount of time delay before starting in AUTO mode. This timer is activated upon the <i>Remote Start Off Load</i> command being issued. Typically this timer is applied to prevent starting upon fleeting start signals.
Remote Start On Load	The amount of time delay before starting in AUTO mode. This timer is activated upon the <i>Remote Start On Load</i> command being issued. Typically this timer is applied to prevent starting upon fleeting start signals.
Mains Fail 	The amount of time delay before starting in AUTO mode. This timer is activated upon a mains failure detection.
Telemetry Start	The amount of time delay before starting in AUTO mode. This timer is activated upon a <i>Remote Start</i> command being received from a MODBUS client. Typically this timer is applied to prevent starting upon fleeting start signals.

Parameter descriptions are continued overleaf...


Start Timers



= Only available on DSE7420 MKII AMF Modules


Timer	Description
Mains Transient Delay 	Used to give a delay between sensing mains failure and acting upon it. This is used to prevent dropouts of the mains load switch and operation of the system due to mains supply transient conditions.
Engage Attempt	<p>NOTE: Only available if using magnetic pick-up and multiple engage attempts</p> <p>The amount of time the module attempts to engage the starter motor during each engage attempt. If the Magnetic Pick-up is not detecting movement of the flywheel when this timer expires, the engage attempt terminates. When the engage fails consecutively for the configured number of <i>Engage Attempts</i>, the <i>Fail to Engage</i> alarm is activated.</p>
Engage Rest	<p>NOTE: Only available if using magnetic pick-up and multiple engage attempts</p> <p>The amount of time the module waits between attempts to engage the starter.</p>
Delay Crank	The amount of time delay between the fuel relay and the crank relay energising. This is typically used to allow fuel systems to prime.
Cranking	The amount of time for each crank attempt
Crank Rest	The amount of time between multiple crank attempts.
Smoke Limit	The amount of time that the engine is requested to run at idle speed upon starting. This is typically used to limit emissions at startup.
Smoke Limit Off	The amount of time that the engine takes to run up to rated speed after removal of the command to run at idle speed. If this time is too short, the engine is stopped due to an <i>Under-speed</i> alarm. If the time is too long, <i>Under speed</i> protection is disabled until the <i>Smoke Limit Time Off</i> time has expired.

Parameter descriptions are continued overleaf...


Timer	Description
Safety On Delay	The amount of time at startup that the controller ignores oil pressure and engine speed and other delayed alarms. This is used to allow the engine to run up to speed before protections are activated.
Warming	The amount of time the engine runs before being allowed to take load. This is used to warm the engine to prevent excessive wear.
ECU (ECM) Override	The amount of time the CAN ECU Power stays energised when the Start button is pressed in Stop mode.
MPU Fail Delay	 NOTE: Only available if using Magnetic pick-up
	The amount of time during which the module must receive a speed signal once cranking has commenced. If no signal is present, the engine is stopped, and a <i>Loss of Magnetic Pickup</i> alarm given.

2.6.2 LOAD / STOPPING TIMERS

Load Timers



= Only available on DSE7420 MKII AMF Modules


Timer	Description
 Transfer Time	The time between one load switch opening and the other closing. Used during transfer to and from the generator.
Breaker Close Pulse	The amount of time that <i>Breaker Close Pulse</i> signal is present when the request to close the load switch is given.
Breaker Trip Pulse	The amount of time that <i>Breaker Open Pulse</i> signal is present when the request to open the load switch is given.

Stopping Timers

Click and drag to change the setting. Timers increment in steps of 1second up to one minute, then in steps of 30seconds up to 30minutes, then in steps of 30minutes thereafter (where allowed by the limits of the timer).

Timer	Description
Return Delay	A delay, used in auto mode only, that allows for short term removal of the request to stop the set before action is taken. This is usually used to ensure the set remains on load before accepting that the start request has been removed.
Cooling	The amount of time that the set is made to run OFF LOAD before being stopped. This is to allow the set to cool down and is particularly important for engines with turbo chargers.
Cooling At Idle	The amount of time that the set is made to run OFF LOAD and at Idle Speed before being stopped.
ETS Solenoid Hold	The amount of time the <i>Energise to stop</i> solenoid is kept energised after the engine has come to rest. This is used to ensure the set has fully stopped before removal of the stop solenoid control signal.
Fail To Stop Delay	If the set is called to stop and is still running after the <i>fail to stop</i> delay, a <i>Fail to Stop</i> alarm is generated.


2.6.3 MODULE TIMERS



Timer	Description
LCD Page timer	If the module is left unattended for the duration of the <i>LCD Page Timer</i> it reverts to show the <i>Status</i> page.
LCD Scroll Timer	The scroll time between parameters on a selected page
Backlight Timer	If the module is left unattended for the duration of the <i>Backlight Timer</i> , the LCD backlight turns off
Sleep Timer	<p>▲NOTE: The Sleep Mode is disabled when the DSE25xx MKII remote display module is connected.</p>
	If the module is left unattended for the duration of the <i>Sleep Timer</i> , it goes into sleep mode to save power.

2.7 GENERATOR


The *Generator* section is subdivided into smaller sections. Select the required section with the mouse.



2.7.1 GENERATOR OPTIONS

Parameter	Description
Alternator Fitted	<input type="checkbox"/> = There is no alternator in the system, it is an <i>engine only</i> application <input checked="" type="checkbox"/> = An alternator is fitted to the engine; it is a generator application.
Poles	The number of poles on the alternator.
VT Fitted	<input type="checkbox"/> = The voltage sensing to the controller is direct from the alternator <input checked="" type="checkbox"/> = The voltage sensing to the controller is via Voltage Transformers (VTs or PTs) This is used to step down the generated voltage to be within the controller voltage specifications. By entering the <i>Primary</i> and <i>Secondary</i> voltages of the transformer, the controller displays the <i>Primary</i> voltage rather than the actual measured voltage. This is typically used to interface the DSE module to high voltage systems (i.e. 11kV) but also used on systems such as 600V ph-ph.


2.7.1.1 BREAKER CONTROL

Parameter	Description
Enable Breaker Alarms	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The <i>Generator Fail To Close Alarm</i> and the <i>Generator Fail To Open Alarm</i> are enabled. During the generator closure process, when the <i>Close Generator</i> output is activated, if the configured <i>Generator Closed Auxiliary</i> digital input does not become active within the <i>Generator Fail To Close Delay</i> timer, the <i>Generator Fail to Close</i> alarm is activated. Or, during the generator opening process, when the <i>Close Generator</i> output is deactivated, if the configured <i>Generator Closed Auxiliary</i> digital input does not become inactive within the <i>Generator Fail To Open Delay</i> timer, the <i>Generator Fail To Open</i> alarm is activated.
Paralleling Time 	This is only applicable if the <i>Check Sync Closed Transition</i> is used. It is the time for the supplies remain in parallel during the <i>Closed Transition</i> .

2.7.1.2 GENERATOR PHASE ROTATION

Parameter	Description
Generator Phase Rotation <i>IEEE 37.2 – 47 Phase Sequence Relay</i>	<input type="checkbox"/> = Generator phase rotation is not checked. <input checked="" type="checkbox"/> = An electrical trip alarm is generated when the measured phase rotation is not as configured.

2.7.1.3 GENERATOR KW RATING



The Generator kW rating must be set in order for the *Generator Power* functions to be correctly utilised.

The Generator kW and kVAr rating must be correctly set.

The values you set here are the kW, kVAr, and Pf, NOT the kVA !

Calculating the VAr rating of a genset

- Most generators are rated for a power factor (W / VA) of 0.8
- From Pythagoras :
 - $\text{Cos } \Phi = W / VA$
 - $\text{Cos } \Phi = 0.8$
 - $\Phi = \text{Cos}^{-1} 0.8 = 36.87^\circ$
- From this we calculate the VAr rating of the typical 0.8 pf rated generator as :
 - $\text{Tan } \Phi = VAr / W$
 - $VAr = \text{Tan } 36.87 \times W$
 - $VAr = 0.75 \times W$
- Or to simplify this, the VAr rating of a 0.8 pf rated generator is $\frac{3}{4}$ of the W rating (kVAr rating = 75% of kW rating)

2.7.2 GENERATOR VOLTAGE

The screenshot shows the 'Generator Voltage' configuration page. It is divided into four sections: Under Voltage Alarms, Loading Voltage, Nominal Voltage, and Over Voltage Alarms. Each section contains various settings like trip values, activation delays, and alarm actions. Three callout boxes provide instructions: 1) 'Select the type of alarm required. For details of these, see the section entitled Alarm Types elsewhere in this document.' pointing to the 'Shutdown' action dropdown. 2) 'Click and drag to change the setting.' pointing to a slider for the 'Pre-alarm Trip' value. 3) 'Type the value or click the up and down arrows to change the settings.' pointing to the 'Loading Voltage' input field.

2.7.2.1 UNDER VOLTAGE ALARMS

Parameter	Description
Generator Under Voltage Alarm IEEE 37.2 - 27AC Undervoltage Relay	<input type="checkbox"/> = Generator Under Volts does NOT give an alarm <input checked="" type="checkbox"/> = Generator Under Volts gives an alarm in the event of the generator output falling below the configured <i>Under Volts Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Under volts Alarm Trip</i> value is adjustable to suit user requirements.
Action	Select the type of alarm required from the list: Shutdown Electrical Trip For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.
Generator Under Voltage Pre-Alarm IEEE 37.2 - 27AC Undervoltage Relay	<input type="checkbox"/> = Generator Under Volts does NOT give a warning alarm <input checked="" type="checkbox"/> = Generator Under Volts gives a warning alarm in the event of the generator output falling below the configured <i>Under Volts Pre-Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Under volts Pre-Alarm Trip</i> value is adjustable to suit user requirements.

2.7.2.2 LOADING VOLTAGE

Parameter	Description
Loading Voltage	This is the minimum voltage the generator must be operating at before the module considers it available to take the load. It is also the voltage above the under-voltage trip that the generator output must return to before the module considers that the supply is back within limits. (i.e. With an under volts trip of 184.0V and a loading voltage of 207.0V, the output voltage must return to 207.0V following an under-voltage event to be considered within limits.)
Enable Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = Upon starting and after the <i>Safety On Delay Timer</i> expires, if the generator output voltage fails to reach the <i>Loading Voltage</i> setpoint, the <i>Loading Voltage Not Reached</i> alarm is activated.

2.7.2.3 NOMINAL VOLTAGE

Parameter	Description
Nominal Voltage	This is used to calculate the percentages of the alarm setpoints.

2.7.2.4 OVER VOLTAGE ALARMS

Parameter	Description
Generator Over Voltage Pre-Alarm IEEE 37.2 – 59 AC Overvoltage Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Generator Over Volts gives a warning alarm in the event of the generator output voltage rising above the configured <i>Over Volts Pre-Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Warning</i> is automatically reset when the generator output voltage falls below the configured <i>Return</i> level. The <i>Over Volts Pre-Alarm Trip</i> value is adjustable to suit user requirements.
Generator Over Voltage IEEE 37.2 – 59 AC Overvoltage Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Generator Over Volts gives a <i>Shutdown</i> alarm in the event of the generator output rising above the configured <i>Over Volts Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Overvolts Alarm Trip</i> value is adjustable to suit user requirements.

2.7.3 GENERATOR FREQUENCY

The screenshot displays the 'Generator Frequency' configuration page, organized into several sections:

- Under Frequency Alarms:** Includes an 'Alarm' checkbox (checked), an 'Action' dropdown set to 'Shutdown', a 'Trip' slider at 40.0 Hz (80.0%), a 'Pre-alarm' checkbox (checked), a 'Pre-alarm Trip' slider at 42.0 Hz (84.0%), and an 'Activation Delay' slider at 0s.
- Loading Frequency:** Includes a 'Loading Frequency' slider at 45.0 Hz (90.0%) and an 'Alarm' checkbox (unchecked) with an 'Action' dropdown set to 'Warning'.
- Nominal Frequency:** Includes a 'Nominal Frequency' slider at 50.0 Hz (100%).
- Over Frequency Alarms:** Includes a 'Pre-alarm' checkbox (checked), a 'Return' slider at 54.0 Hz (110%), a 'Trip' slider at 55.0 Hz (110%), a 'Shutdown' checkbox (checked), a 'Shutdown Trip' slider at 57.0 Hz (114.0%), and an 'Activation Delay' slider at 0s.
- Run Away:** Includes a 'Run Away' checkbox (checked) and a 'Trip' slider at 60.0 Hz (120.0%).
- Over Frequency Options:** Includes 'Over Frequency Overshoot %' set to 0 and 'Overshoot Delay' set to 2.0s.

Callouts provide the following instructions:

- Click and drag to change the setting.
- Click to enable or disable the alarms. The relevant values below appears *greyed out* if the alarm is disabled.
- Type the value or click the up and down arrows to change the settings.

Parameters are detailed overleaf...

2.7.3.1 UNDER FREQUENCY ALARMS

Parameter	Description
Generator Under Frequency Alarm IEEE 37.2 -81 Frequency Relay	<input type="checkbox"/> = Generator Under Frequency does NOT give an alarm <input checked="" type="checkbox"/> = Generator Under Frequency gives an alarm in the event of the generator output frequency falling below the configured <i>Under Frequency Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Underfrequency Alarm Trip</i> value is adjustable to suit user requirements.
Action	Select the type of alarm required from the list: <i>Shutdown</i> <i>Electrical Trip</i> For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.
Generator Under Frequency Pre-Alarm IEEE 37.2 -81 Frequency Relay	<input type="checkbox"/> = Generator Under Frequency does NOT give a warning alarm <input checked="" type="checkbox"/> = Generator Under Frequency gives a warning alarm in the event of the generator output frequency falling below the configured <i>Under Frequency Pre-Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Under Frequency Pre-Alarm Trip</i> value is adjustable to suit user requirements.

2.7.3.2 LOADING FREQUENCY

Parameter	Description
Loading Frequency	This is the minimum frequency the generator must be operating at, before the module considers it available to take the load. It is also the frequency above the under-frequency trip that the generator output must return to before the module considers that the supply is back within limits. (i.e. With an underfrequency trip of 42.0 Hz and a loading frequency of 45.0 Hz, the output frequency must return to 45.0 Hz following an under-frequency event to be considered within limits.)
Enable Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = Upon starting and after the <i>Safety On Delay Timer</i> expires, if the generator output frequency fails to reach the <i>Loading Frequency</i> setpoint, the <i>Loading frequency Not Reached</i> alarm is activated.


2.7.3.3 NOMINAL FREQUENCY

Parameter	Description
Nominal Frequency	This is used to calculate the percentages of the alarm setpoints.

2.7.3.4 OVER FREQUENCY ALARMS

Parameter	Description
Generator Over Frequency Pre-Alarm IEEE 37.2 -81 Frequency Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Generator Over Frequency gives a warning alarm in the event of the generator output frequency rising above the configured <i>Over frequency Pre-Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Warning</i> is automatically reset when the generator output frequency falls below the configured <i>Return</i> level. The <i>Over Frequency Pre-Alarm Trip</i> value is adjustable to suit user requirements.
Generator Over Frequency IEEE 37.2 -81 Frequency Relay	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Generator Over Frequency gives a <i>Shutdown</i> alarm in the event of the generator output rising above the configured <i>Over Frequency Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Over Frequency Alarm Trip</i> value is adjustable to suit user requirements.

2.7.3.5 RUN AWAY

Parameter	Description
Run Away IEEE 37.2 -81 Frequency Relay	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: Only available if using magnetic pick-up or an electronic engine is connected. </div> <input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = In the event of the generator output frequency rising above the configured <i>Trip</i> value, the <i>Run Away Shutdown</i> alarm is immediately triggered. This is used to protect against engine damage due to uncontrolled speed increase, where the engine speed runs away.
Trip	Set the frequency level for the <i>Run Away</i> alarm.

2.7.3.6 OVER FREQUENCY OPTIONS

Parameter	Description
Over Frequency Overshoot % IEEE 37.2 -81 Frequency Relay	To prevent spurious over-frequency alarms at start up, the module includes configurable <i>Over Frequency Overshoot</i> protection. This allows the frequency to 'overshoot' the <i>Over-Frequency Shutdown</i> level during the starting process for a short time.
Overshoot Delay	Rather than 'inhibiting' the <i>Over Frequency</i> alarms, the levels are temporarily raised by the <i>Over Frequency Overshoot %</i> for the duration of the <i>Overshoot Delay</i> from starting.


2.7.4 GENERATOR CURRENT

The *generator* section is subdivided into smaller sections. Select the required section with the mouse.



2.7.4.1 GENERATOR CURRENT OPTIONS

NOTE: It is not possible to write the configuration to the module if the CT Location is set to Load and the AC System in the Generator Options and in the Mains Options are not the same.



Parameter	Description
CT Primary	Primary rating of the three phase Current Transformers
CT Secondary	Secondary rating of the Current Transformers
CT Location	<div style="border: 1px solid black; padding: 5px;"> <p>NOTE: When the <i>CT Location</i> is set to <i>Load</i>, the <i>AC System</i> in the <i>Generator Options</i> and <i>Mains Options</i> must be the same.</p> <p>Gen: The CTs are in the feed from the generator, the module shows only generator load</p> <p>Load: The CTs are in the feed to the load, the module then displays load current, provided by the mains supply or the generator</p> </div>
Full Load Rating	This is the full load current rating of the alternator
Earth CT Primary	Primary rating of the earth fault Current Transformers

2.7.4.2 GENERATOR CURRENT ALARMS

Generator Current Alarms

Overcurrent Alarm

Immediate Warning
 IDMT Alarm
 Trip: % 500 A
 Time Multiplier:
 Action: Electrical Trip

Short Circuit

Enabled
 Action: Electrical Trip
 Trip: % 1000 A
 Time Multiplier:

Negative Phase Sequence

Enable
 Action: Shutdown
 Trip Level: %
 Delay: s

Earth Fault

Enable
 Action: Shutdown
 Trip Level: % 50.0 A
 Time Multiplier:

2.7.4.3 OVERCURRENT ALARM

The overcurrent alarm combines a simple warning trip level combined with a fully functioning IDMT curve for thermal protection.

2.7.4.3.1 IMMEDIATE WARNING

IEEE 37.2 -50 instantaneous overcurrent relay

If the *Immediate Warning* is enabled, the controller generates a *warning alarm* as soon as the *Trip* level is reached. The alarm automatically resets once the generator loading current falls below the *Trip* level (unless *All Warnings are latched* is enabled). For further advice, consult the generator supplier.

2.7.4.3.2 IDMT ALARM

IEEE 37.2 -51 AC time overcurrent relay (shutdown / electrical trip)

If the *Over Current IDMT Alarm* is enabled, the controller begins following the IDMT ‘curve’ when the current on any phase passes the *Trip* setting.

If the *Trip* is surpassed for an excess amount of time, the *IDMT Alarm* triggers (*Shutdown* or *Electrical Trip* as selected in *Action*).

The larger the over circuit fault, the faster the trip. The speed of the trip is dependent upon the fixed formula:

$$T = \frac{t}{\left(\frac{I_A}{I_T} - 1\right)^2}$$

Where:


T is the tripping time in seconds

I_A is the actual measured current of the most highly loaded line (L1, L2 or L3)

I_T is the delayed trip point setting in current

t is the time multiplier setting and also represents the tripping time in seconds at twice full load (when $I_A/I_T = 2$).

The settings shown in the example below are a screen capture of the DSE factory settings, taken from the DSE Configuration Suite PC Software for a brushless alternator.



These settings provide for normal running of the generator up to 100% full load. If full load is surpassed, the *Immediate Warning* alarm is triggered, and the set continues to run.

The effect of an overload on the generator is that the alternator windings begin to overheat; the aim of the *IDMT Alarm* is to prevent the windings being overload (heated) too much. The amount of time that the alternator is safely overloaded is governed by how high the overload condition is.

The default settings as shown above allow for an overload of the alternator to the limits of the *Typical Brushless Alternator* whereby 110% overload is permitted for 1 hour or 200% overload is permitted for 36 seconds.

If the alternator load reduces, the controller then *follows* a cooling curve. This means that a second overload condition may trip soon after the first as the controller *knows* if the windings have not cooled sufficiently.

For further details on the *Thermal Damage Curve* of your alternator, refer to the alternator manufacturer and generator supplier.

2.7.4.3.3 CREATING A SPREADSHEET FOR THE OVER CURRENT IDMT CURVE

The formula used:

$$T = \frac{t}{\left(\frac{I_A}{I_T} - 1\right)^2}$$

Where:

- T is the tripping time in seconds
- I_A is the actual measured current of the most highly loaded line (L1, L2 or L3)
- I_T is the delayed trip point setting in current
- t is the time multiplier setting and represents the tripping time in seconds at twice full load (when $I_A/I_T = 2$).

The equation is simplified for addition into a spreadsheet. This is useful for 'trying out' different values of t (*time multiplier setting*) and viewing the results, without actually testing this on the generator.

	A	B	C	D	E	F
1		1.01	1.02	1.03	1.05	1.06
2	36	360000	90000	40000	14400	10000

t (*time multiplier setting*)


T (*tripping time in seconds*)

I_A/I_T (*multiple of the Trip setting from 1.01 to 3.0 in steps of 0.1*)

The formula for the *Tripping Time* cells is:

```
=A2/POWER((B$1-1),2)
```

Over Current Alarm IDMT Curves



2.7.4.4 SHORT CIRCUIT ALARM

IEEE C37.2 – 51 IDMT Short Circuit Relay

If the *Short Circuit Alarm* is enabled, the controller begins following the IDMT ‘curve’ when the current on any phase passes the *Trip* setting.

If the *Trip* is surpassed for an excess amount of time, the *IDMT Alarm* triggers (*Shutdown* or *Electrical trip* as selected in *Action*).

The larger the short circuit fault, the faster the trip. The speed of the trip is dependent upon the fixed formula:

$$T = \frac{t \times 0.14}{\left(\left(\frac{I_A}{I_T}\right)^{0.02} - 1\right)}$$

Where:

T is the tripping time in seconds (accurate to +/- 5% or +/- 50 ms (whichever is the greater))


I_A is the actual measured current

I_T is the trip point setting in current

t is the time multiplier setting

The settings shown in the example below are a screen capture of the DSE factory settings, taken from the DSE Configuration Suite software.

NOTE: Due to large inrush currents from certain loads, such as motors or transformers, the default settings for the Short Circuit alarm may need adjusting to compensate.



The effect of a short circuit on the generator is that the alternator stator and rotor begin to overheat; the aim of the *IDMT alarm* is to prevent the stator and rotor being overload (heated) too much. The amount of time that the alternator is safely overloaded is governed by how high the short circuit condition is.

For further details on the *Thermal & Magnetic Damage Curve* of your alternator, refer to the alternator manufacturer and generator supplier.

2.7.4.4.1 CREATING A SPREADSHEET FOR THE SHORT CIRCUIT IDMT CURVE

The formula used:

$$T = \frac{t \times 0.14}{\left(\left(\frac{I_A}{I_T}\right)^{0.02} - 1\right)}$$

Where:

T is the tripping time in seconds (accurate to +/- 5% or +/- 50 ms (whichever is the greater))

I_A is the actual measured current

I_T is the trip point setting in current

t is the time multiplier setting

The equation is simplified for addition into a spreadsheet. This is useful for 'trying out' different values of t (*time multiplier setting*) and viewing the results, without actually testing this on the generator.

	A	B	C	D	E	F
1		1.01	1.02	1.03	1.05	1.06
2	0.01	7.034242	25	11.11111	4	2.777778

t (*time multiplier setting*)


T (*tripping time in seconds*)

I_A/I_T (*multiple of the Trip setting from 1.01 to 3.0 in steps of 0.1*)

The formula for the *Tripping Time* cells is:

f_x `=(A2*0.14)/(POWER((B$1),0.02)-1)`

Short Circuit Alarm IDMT Curves



Time Multiplier = 0.01 (Default Setting) Time Multiplier = 0.02 Time Multiplier = 0.04
Time Multiplier = 0.08 Time Multiplier = 0.16

2.7.4.5 NEGATIVE PHASE SEQUENCE

IEEE C37.2 - 46 Phase-Balance Current Relay

Unbalanced loads cause negative sequence current in the alternator stator. These currents cause harmonics which eventually leads to overheating and melting of the rotor. An unbalanced load is, however, permissible within limits.

For recommended settings contact your alternator manufacturer.

2.7.4.6 EARTH FAULT ALARM


When the module is suitably connected using the 'Earth Fault CT.' The module measures Earth Fault and optionally configured to generate an alarm condition (shutdown or electrical trip) when a specified level is surpassed.

If the *Earth Fault Alarm* is enabled, the controller begins following the IDMT 'curve' when the earth fault current passes the *Trip* setting.


If the *Trip* is surpassed for an excess amount of time, the *IDMT Alarm* triggers (*Shutdown* or *Electrical Trip* as selected in *Action*).

The larger the earth fault, the faster the trip.

The settings shown in the example below are a screen capture of the DSE factory settings, taken from the DSE Configuration Suite software.



Earth Fault Alarm IDMT Curves




2.7.4.7 DEFAULT CURRENT PROTECTION TRIPPING CHARACTERISTICS

The graph on the following page shows the default settings for the IDMT tripping curves for the *Over Current*, *Short Circuit* and *Earth Fault* protections.

The default setting for the *Over Current* alarm allows for an overload of an alternator to the limits of the *Typical Brushless Alternator* whereby 110% overload is permitted for 1 hour or 200% overload is permitted for 36 seconds. In an over current situation the alternator begins to overheat. The aim of the *Over Current IDMT Alarm* is to prevent the windings being overloaded (heated) too much. The amount of time that the alternator is safely overloaded is governed by how high the overload condition is.

The default setting for the *Short Circuit* alarm allows for an alternator to supply a high current caused by a genuine short circuit or an inrush current of a motor/transformer. Whereby 300% overload is permitted for 0.17 seconds or 600% overload is permitted for 0.06 seconds. In a short circuit situation the alternator begins to overheat to the point the insulation breaks down, potentially causing a fire. The aim of the *Short Circuit IDMT Alarm* is to prevent the insulation from melting due to excessive heat. The amount of time that the alternator runs safely in a short circuit condition is governed by the alternator's construction.


DSE Default Configuratuion of Over Current, Short Circuit & Earth Fault Alarm IDMT Curves




- Over Circuit IDMT Trip Curve with Time Multiplier = 36, Trip Point = 100% (Default Settings)
- Short Circuit IDMT Trip Curve with Time Multiplier = 0.01, Trip Point = 200% (Default Settings)
- Earth Fault IDMT Trip Curve with Time Multiplier = 0.1, Trip Point = 10% (Default Settings)

2.7.5 GENERATOR POWER

The *Generator Power* section is subdivided into smaller sections. Select the required section with the mouse.




2.7.5.1 OVERLOAD PROTECTION




Parameter	Description
Overload Protection	<input type="checkbox"/> = Overload Protection alarm is disabled. <input checked="" type="checkbox"/> = The <i>kW Overload Alarm</i> activates when the kW level exceeds the <i>Trip</i> setting for longer than the configured <i>Delay</i> time.
Action	Select the action for the <i>kW Overload Alarm</i> : Electrical Trip Indication Shutdown Warning

2.7.5.2 LOAD CONTROL




Parameter	Description
Dummy Load Control	Provides control of configurable outputs set to <i>Dummy Load Control</i> . <input type="checkbox"/> = Dummy Load Control is disabled. <input checked="" type="checkbox"/> = The module monitors the load and controls outputs configured to <i>Dummy Load Control (1-5)</i>
Outputs in Scheme	The amount of Dummy Load Control outputs that are included in the function.
Trip / Trip Delay	When the load level is below the <i>Trip</i> setting for the duration of the <i>Trip Delay</i> , then the 'next' output configured to <i>Dummy Load Control</i> is activated (max 5)
Return / Return Delay	When the load level rises above the <i>Return</i> level for the duration of the <i>Return Delay</i> , then the 'highest numbered' output configured to <i>Dummy Load Control</i> is de-activated, and the timer is reset.
Load Shedding Control	Provides control of configurable outputs set to <i>Load shedding control</i> . <input type="checkbox"/> = Load Shedding Control is disabled. <input checked="" type="checkbox"/> = The module monitors the load and controls any outputs configured to <i>Load Shedding Control (1-5)</i>
Outputs in Scheme	The number of outputs (max 5) that is included in the function.
Outputs at Start	The number of outputs configured to <i>Load Shedding Control 1-5</i> that are energised when the set is required to take load. The <i>Transfer Delay / Load Delay</i> timer begins. At the end of this timer, the generator load switch is closed – The generator is placed on load.
Trip / Trip Delay	When the load level is above the <i>Trip</i> setting for the duration of the <i>Trip Delay</i> , then the 'next' output configured to <i>Load Shedding Control</i> is activated (max 5)
Return / Return Delay	When the load level is below the <i>Return</i> setting for the duration of the <i>Return Delay</i> , then the 'highest numbered' output configured to <i>Load Shedding Control</i> is de-activated, and the timer is reset.
Transfer Time / Load Delay	The time between closing the <i>Load Shedding Control</i> outputs (<i>Outputs at Start</i>) and closing the generator load switching device.

2.7.5.3 REVERSE POWER



Parameter	Description
Reverse Power IEEE 37.2 – 32 Directional Power Relay	<input type="checkbox"/> = Generator Reverse Power Alarm is disabled. <input checked="" type="checkbox"/> = The Generator Reverse Power Alarm activates when the reverse power exceeds the Reverse Power Trip setting longer than the configured Delay time. This is used to protect against back feed from electric motors when mechanically overpowered.
Action	Select the action for the Reverse Power Alarm: Electrical Trip Indication Shutdown Warning

2.7.5.4 LOW LOAD



Parameter	Description
Enabled	<input type="checkbox"/> = Low Load Alarm is disabled. <input checked="" type="checkbox"/> = The Low Load Alarm activates when the generator power drops below the configured Trip setting longer than the configured Delay time. This is used to prevent the engine from running at very low load levels.
Description	Enter the LCD text that shows up on the display when this alarm activates
Action	Select the action for the Low Load Alarm: Electrical Trip Indication Shutdown Warning
Trip	Set the percentage of total power at which the Low Load Alarm is activated
Return	The Return level is only used for the Warning Action. When the load returns to above this percentage level of the total power, the Warning alarm is reset.
Delay	Set the amount of time before the Low Load Alarm activates.

2.7.6 AVR

AVR

Positive VAr

Pre-alarm

Trip %

Return %

Alarm

Action Electrical Trip

Trip %

Delay

Negative VAr

Pre-alarm

Trip %

Return %

Alarm

Action Electrical Trip

Trip %

Delay

Parameter	Description
AVR	<input type="checkbox"/> = Alarms are disabled <input checked="" type="checkbox"/> = The module monitors the Positive & Negative VAr levels and provides an alarm when the level exceeds the <i>Trip</i> setting longer than the configured <i>Delay</i> setting.
Action	Select the action for the <i>Reverse Power Alarm</i> : Electrical Trip Shutdown

2.8 MAINS



= Only available on DSE7420 MKII AMF Modules

The *Mains* section is subdivided into smaller sections.
Select the required section with the mouse.



2.8.1 MAINS OPTIONS

Mains Options

Mains Options

Mains Failure Detection

Immediate Mains Dropout

AC System 3 Phase, 4 Wire





When three phase loads are present, it is usually desirable to set this parameter to to enable *Immediate Mains*

38, 39, 40, 41, L1, L2, L3, N

VT fitted

Primary 111 Secondary 110

Parameters are detailed overleaf...

Parameter	Description
Mains Failure Detection 	<input type="checkbox"/> = The module ignores the status of the mains supply. <input checked="" type="checkbox"/> = The module monitors the mains supply and use this status for automatically starting and stopping the set in auto mode.
Immediate Mains Dropout 	<input type="checkbox"/> = Upon mains failure, the mains load switch is kept closed until the generator is up to speed and volts. <input checked="" type="checkbox"/> = Upon mains failure, the mains load switch is opened immediately, subject to the setting of the <i>mains transient</i> timer.
AC System 	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>⚠ NOTE: It is not possible to write the configuration to the module if the Closed Transition option is enabled and the AC Systems are not the same in the Generator and Mains Options.</p> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>⚠ NOTE: It is not possible to write the configuration to the module if the CT Location is set to Load and the AC System in the Generator Options and in the Mains Options are not the same.</p> </div> <p>The AC System of the mains is fixed to the same setting as the generator. These settings are used to detail the type of AC system to which the module is connected:</p> <ul style="list-style-type: none"> 2 Phase, 3 Wire L1 - L2 2 Phase, 3 Wire L1 - L3 3 Phase, 3 Wire 3 Phase, 4 Wire 3 Phase, 4 Wire Delta L1 - N - L2 3 Phase, 4 Wire Delta L1 - N - L3 3 Phase, 4 Wire Delta L2 - N - L3 Single Phase, 2 Wire Single Phase, 3 Wire L1 - L2 Single Phase, 3 Wire L1 - L3
VTs 	<input type="checkbox"/> = The voltage sensing to the controller is direct from the Mains <input checked="" type="checkbox"/> = The voltage sensing to the controller is via Voltage Transformers (VTs or PTs)
	<p>This is used to step down the generated voltage to be within the controller voltage specifications. By entering the <i>Primary</i> and <i>Secondary</i> voltages of the transformer, the controller displays the <i>Primary</i> voltage rather than the actual measured voltage.</p> <p>This is typically used to interface the DSE module to high voltage systems (i.e. 11 kV)</p>

Mains Phase Rotation Alarm

Parameter	Description
Mains Phase Rotation <i>IEEE 37.2 – 47 Phase Sequence Relay</i>	<input type="checkbox"/> = Mains phase rotation is not checked. <input checked="" type="checkbox"/> = A mains failure is detected when the measured phase rotation is not as configured.





Breaker Control

Parameter	Description
Enable Breaker Alarms	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = The <i>Mains Fail To Close Alarm</i> and the <i>Mains Fail To Open Alarm</i> are enabled. During the mains closure process, when the <i>Close Mains</i> output is activated, if the configured <i>Mains Closed Auxiliary</i> digital input does not become active within the <i>Mains Fail To Close Delay</i> timer, the <i>Mains Fail to Close</i> alarm is activated. Or, during the mains opening process, when the <i>Close Mains</i> output is deactivated, if the configured <i>Mains Closed Auxiliary</i> digital input does not become inactive within the <i>Mains Fail To Open Delay</i> timer, the <i>Mains Fail To Open</i> alarm is activated.

Mains Rating

Parameter	Description
Mains Rating	The Mains Rating is utilised to show the Mains load percentage in the DSE Scada Suite. The Mains kW and kVA rating must be correctly set. The values you set here are the kW, and kVA, NOT the kVA, or PF !

2.8.2 MAINS ALARMS

Alarm	IEEE designation
Mains Under Voltage IEEE 37.2 – 27 AC Undervoltage Relay 	<input type="checkbox"/> = Mains Under Voltage detection is disabled <input checked="" type="checkbox"/> = Mains Under Voltage gives an alarm in the event of the mains voltage falling below the configured <i>Under Voltage Trip</i> value. The <i>Under Voltage Trip</i> value is adjustable to suit the application. The alarm is reset, and the mains is considered within limits when the mains voltage rises above the configured <i>Under Voltage Return</i> level.
Mains Over Voltage IEEE 37.2 – 59 AC Overvoltage Relay 	<input type="checkbox"/> = Mains Over Voltage detection is disabled <input checked="" type="checkbox"/> = Mains Over Voltage gives an alarm in the event of the mains voltage rising above the configured <i>Over Voltage Trip</i> value. The <i>Over Voltage Trip</i> value is adjustable to suit the application. The alarm is reset, and the mains is considered within limits when the mains voltage falls below the configured <i>Over Voltage Return</i> level.
Mains Under Frequency IEEE 37.2 – 81 Frequency Relay 	<input type="checkbox"/> = Mains Under Frequency detection is disabled <input checked="" type="checkbox"/> = Mains Under Frequency gives an alarm in the event of the mains frequency falling below the configured <i>Under Frequency Trip</i> value. The <i>Under Frequency Trip</i> value is adjustable to suit the application. The alarm is reset, and the mains is considered within limits when the mains frequency rises above the configured <i>Under Frequency Return</i> level.
Mains Over Frequency IEEE 37.2 – 81 Frequency Relay 	<input type="checkbox"/> = Mains Over Frequency detection is disabled <input checked="" type="checkbox"/> = Mains Over Frequency gives an alarm in the event of the mains frequency rising above the configured <i>Over Frequency Trip</i> value. The <i>Over Frequency Trip</i> value is adjustable to suit the application. The alarm is reset, and the mains is considered within limits when the mains frequency falls below the configured <i>Over Frequency Return</i> level.

2.8.3 MAINS CURRENT

NOTE: Mains Current Alarms are provided on DSE7420 MKII modules only when the Current Transformers are fitted into the 'load leg'.

NOTE: These alarms are described fully in the section entitled *Generator Current Alarms* elsewhere in this manual.

The screenshot displays the 'Mains Current' configuration interface, organized into four main sections:

- Mains Current Options:** Contains three settings, each with a numeric input field and a slider. 'CT Primary (L1,L2,L3,N)' is set to 600 A. 'Full Load Rating' is set to 500 A. 'Earth CT Primary' is set to 500 A.
- Overcurrent Alarm:** Includes a checked 'Immediate Warning' checkbox, a checked 'IDMT Alarm' checkbox, a 'Trip' slider set to 100% (with a 500 A marker), a 'Time Multiplier' set to 36, and an 'Action' dropdown menu set to 'Electrical Trip'.
- Short Circuit:** Includes a checked 'Enabled' checkbox, an 'Action' dropdown menu set to 'Electrical Trip', a 'Trip' slider set to 200% (with a 1000 A marker), and a 'Time Multiplier' set to 0.01.
- Earth Fault:** Includes an unchecked 'Enable' checkbox, an 'Action' dropdown menu set to 'Shutdown', a 'Trip Level' slider set to 10% (with a 50.0 A marker), and a 'Time Multiplier' set to 0.1.


2.9 ENGINE

The *Engine* section is subdivided into smaller sections. Select the required section with the mouse.



2.9.1 ENGINE OPTIONS


ECU (ECM) Options



Parameter	Description
Disable ECM Speed Control	Disables speed control by the DSE module. Useful when an external device (i.e. remote speed potentiometer) is used to control engine speed.


Miscellaneous Options

NOTE: For a full list of the J1939-75 alarms and instrumentation, refer to DSE Publication: 057-263 DSE7410 MKII & DSE7420 MKII Operator Manual which is found on our website: www.deepseeelectronics.com



Parameter	Description
J1939-75 Instrumentation Enable	Allows the DSE module to be interrogated by another CAN device and transfer the generator set instrumentation over J1939 link.
J1939-75 Alarms Enable	Allows the DSE module to be interrogated by another CAN device and transfer the alarms over J1939 link.
CAN Source Address (Instrumentation)	Set the <i>CAN Source Address</i> for the DSE module over which other CANbus devices read the generator set instrumentation.

Startup Options




Parameter	Description
Start Attempts	<p>The number of starting attempts the module makes.</p> <p>If the module does not detect that the engine has fired before the end of the <i>Cranking Time</i>, then the current start attempt is cancelled, and the <i>Crank Rest</i> time takes place before the next crank attempt begins.</p> <p>If, after all configured <i>start attempts</i>, the engine is not detected as running, the <i>Fail to Start</i> shutdown alarm is generated.</p> <p>The engine is detected as running by checking all methods of <i>Crank Disconnect</i>. For further details, see the section entitled <i>Crank Disconnect</i> elsewhere in this document.</p>

Pre-Heat

NOTE: For this feature to have effect, configure a digital output for Pre-Heat.

NOTE: Depending on Engine Type configuration, this is controlled direct by the ECU (ECM).




Parameter	Description
Enabled	<input type="checkbox"/> = Pre-heat is disabled. <input checked="" type="checkbox"/> = When the <i>Coolant Temperature</i> is below the configured <i>On</i> level, the <i>Pre-Heat</i> digital output is activated for the set <i>Duration</i> of time before cranking.
On	Set the coolant temperature below which the pre-heat is activated.
Duration	Set the time delay during which the <i>Pre-Heat</i> digital output remains active before cranking

2.9.1.1 POST-HEAT

NOTE: For this feature to have effect, configure a digital output for Pre-Heat.


NOTE: Depending on Engine Type configuration, this is controlled direct by the ECU (ECM).



Parameter	Description
Enabled	<input type="checkbox"/> = Post-heat is disabled. <input checked="" type="checkbox"/> = When the <i>Coolant Temperature</i> is below the configured <i>On</i> level, the <i>Pre-Heat</i> digital output is activated for the set <i>Duration</i> of time after cranking and before the set is considered available.
On	Set the coolant temperature below which the pre-heat is activated.
Duration	Set the time delay during which the <i>Pre-Heat</i> digital output remains active after cranking and before the engine is considered available.


2.9.2 ECU (ECM)

The *ECU (ECM)* section is subdivided into smaller sections. Select the required section with the mouse.




2.9.2.1 ECU (ECM) OPTIONS

Engine Hours



Parameter	Description
Module to Record Engine Hours	When enabled, DSE module counts Engine Run Hours. When disabled, Engine ECU (ECM) provides Run Hours.

DPF Regeneration Control



Parameter	Description
DPF Regeneration Control	Available for ECUs (ECM) which require the engine speed to drop during a manual regeneration cycle. During this time, the generator is not available to supply power and the under speed and under frequency alarms are not active.

Speed Switch

NOTE: Depending on the Engine Type selected, the Speed Switch options vary to indicate certain speed switch methods such as disabling the speed switch.

Speed Switch

Enable Default Dataset ECU ▾

Parameter	Description
Speed Switch	<p>Defines the method of speed control over CANbus when supported by the ECU (ECM). Selection needs to match the ECU (ECM) calibration for the speed control method.</p> <p>Available speed control methods to choose from:</p> <p>0: CAN Open Increase Decrease</p> <p>1: CAN Open Speed Demand</p> <p>2: Default Dataset ECU</p> <p>3: ECU Analogue Absolute</p> <p>4: ECU Analogue Relative</p> <p>5: ECU CAN Open Analogue</p> <p>6: ECU Frequency Input</p> <p>7: ECU Increase Decrease Input</p>

Example:


For some Volvo Engine Types, the Speed Switch indicates specific options as shown below.

Speed Switch

Enable Always ▾


Parameter	Description
Speed Switch Enable	<p>Defines the method of speed control over CANbus when supported by the Volvo ECU (ECM). Selection needs to match the ECU (ECM) calibration for the speed control method.</p> <p>Available speed control methods to choose from:</p> <p>Always</p> <p>Never</p> <p>On Change</p>

ECU Wakeup




Parameter	Description
ECU Wakeup Enable	<input type="checkbox"/> = Option is disabled. <input checked="" type="checkbox"/> = When the engine is stopped, the DSE module sends a wakeup signal to the ECU (ECM) and keeps it powered up for the <i>ECU Override</i> time (configured in <i>Start Timers</i>) to read the ECU (ECM) parameters. This is periodically repeated depending on the configured <i>Periodic Wakeup Time</i> .
Coolant Measurement Persistence	<div style="border: 1px solid black; padding: 5px;"> <p>NOTE: Available only when ECU Wakeup is enabled.</p> </div> <input type="checkbox"/> = Option is disabled. <input checked="" type="checkbox"/> = The <i>Coolant Temperature</i> measurement is used for the <i>Coolant Temperature Control</i> .

ECU (ECM) Startup Delay



Parameter	Description
ECU StartUp Delay	<input type="checkbox"/> = Option is disabled. <input checked="" type="checkbox"/> = When the engine has to start, the DSE module sends the wakeup signal to the ECU (ECM) before activating the <i>Fuel Relay</i> , <i>Start Relay</i> outputs, or sending the start signal by CAN message, and waits for the ECU to respond before sending the start request. If the ECU (ECM) doesn't respond within the <i>Delay</i> time, the module activates the <i>ECU Start Fail</i> alarm.

Droop



Parameter	Description
Droop	<div style="border: 1px solid black; padding: 5px;"> <p>NOTE: Droop options are only available where supported by the Engine ECU (ECM) over the CAN or MODBUS datalink. Contact the engine manufacturer for further details.</p> </div> <input type="checkbox"/> = Engine droop is not enabled. <input checked="" type="checkbox"/> = Where supported by the electronic engine ECU (ECM), the module enables droop in the engine ECU (ECM) governor at the configured percentage.

SPN Ignore List

SPN Ignore List			
	SPN	FMI	
1 <input checked="" type="checkbox"/>	8	Any	6 <input type="checkbox"/>
2 <input checked="" type="checkbox"/>	12	Any	7 <input type="checkbox"/>
3 <input checked="" type="checkbox"/>	52	Any	8 <input type="checkbox"/>
4 <input type="checkbox"/>			9 <input type="checkbox"/>
5 <input type="checkbox"/>			10 <input type="checkbox"/>

Parameter	Description
SPN Ignore List	<p>Choose the specific SPN for the module to ignore. The module allows the engine to keep running when the ignored SPN occurs; however, depending on the severity, the engine shuts down based on the ECU (ECM) calibration.</p> <p>This is used to mask certain indications or warnings on the ECU (ECM) and not display them on the DSE module.</p>

Miscellaneous


Miscellaneous
CAN source address (engine messages) 220

Parameter	Description
CAN Source Address (Engine Messages)	<p>Set the <i>CAN Source Address</i> the DSE module uses to communicate with the engine's ECU over the CANbus connection.</p> <p>When an ECU <i>Engine Type</i> is selected in the <i>Application</i> section, the <i>CAN Source Address</i> is automatically configured to suit the engine ECU's default requirement. However in some cases a change is required depending on the ECU's configuration, contact the engine manufacturer for further details.</p>

2.9.2.2 ECU (ECM) ALARMS

NOTE: This section is only available when the module is connected to an ECU.

The *ECU (ECM) Alarms* section is subdivided into smaller sections. Select the required section with the mouse.



2.9.2.2.1 ECU (ECM) DATA FAIL



Parameter	Description
ECU (ECM) Data Fail	Provides protection against failure of the ECU (ECM) CAN data link. The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information: None Electrical Trip Shutdown Warning
Arming	Select when the <i>CAN ECU (ECM) Data Fail</i> alarm is active. Options are as follows: Always: The alarm is active at any time the CAN Link is lost Engine Protection Activation: The alarm is monitored after the engine is running and the oil pressure engine protection is in a 'healthy' state, until the engine stops. From Safety On: Active only after the <i>Safety On</i> delay timer From Starting: Active only after the <i>Crank Relay</i> is energised Loading Alarms Activation: The alarm is monitored when the generator voltage and frequency are above their <i>Loading</i> levels. Never: Alarm is disabled When Stationary: Active only when the engine is not running
Activation Delay	The amount of time before the module activates the <i>CAN ECU (ECM) Data Fail</i> after a failure.

2.9.2.2.2 DM1 SIGNALS

NOTE: Configuration of parameters in this section only has effect when the ECU (ECM) supports these features.

NOTE: Configuration of the *Alarm Action* in this section defines the DSE module response to the CAN message; however, the ECU (ECM) still shuts down the engine depending on the alarm severity.

DM1 signals are messages from the CAN (ECM) ECU. The following parameters allows configuration of how the DSE module responds to these messages.

ECU Amber

The screenshot shows a configuration window titled "ECU Amber". It contains three settings:

- Action:** A dropdown menu currently set to "Warning".
- Arming:** A dropdown menu currently set to "Always".
- Activation Delay:** A slider control set to "0s".

Parameter	Description
ECU Amber Action	The action the DSE module takes when receiving and ECU Amber fault condition. The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information: None Electrical Trip Shutdown Warning
Arming	Select when the DSE module activates it <i>ECU Amber</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document: Always Engine Protection Activation From Safety On From Starting Loading Alarms Activation Never When Stationary
Activation Delay	The amount of time before the module activates the <i>ECU Amber</i> alarm after a receiving an ECU Amber fault condition from the ECU.

ECU Red

The screenshot shows a configuration window titled "ECU Red". It contains three settings:

- Action:** A dropdown menu currently showing "Shutdown".
- Arming:** A dropdown menu currently showing "From Safety On".
- Activation Delay:** A slider control set to "0s".

Parameter	Description
ECU Red Action	The action the DSE module takes when receiving an ECU Red fault condition. The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information: None Electrical Trip Shutdown Warning
Arming	Select when the DSE module activates its <i>ECU Red</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document: Always Engine Protection Activation From Safety On From Starting Loading Alarms Activation Never When Stationary
Activation Delay	The amount of time before the module activates the <i>ECU Red</i> alarm after receiving an ECU Red fault condition from the ECU.

ECU Malfunction

The screenshot shows a configuration window titled "ECU Malfunction". It contains three settings:

- Action:** A dropdown menu currently set to "Warning".
- Arming:** A dropdown menu currently set to "Always".
- Activation Delay:** A slider control set to "0s".

Parameter	Description
ECU Malfunction Action	The action the DSE module takes when receiving an ECU Malfunction fault condition. The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information: None Electrical Trip Shutdown Warning
Arming	Select when the DSE module activates its <i>ECU Malfunction</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document: Always Engine Protection Activation From Safety On From Starting Loading Alarms Activation Never When Stationary
Activation Delay	The amount of time before the module activates the <i>ECU Malfunction</i> alarm after receiving an ECU Malfunction fault condition from the ECU.

ECU Protect


The screenshot shows a configuration window titled "ECU Protect". It contains three settings:

- Action:** A dropdown menu currently showing "Warning".
- Arming:** A dropdown menu currently showing "From Safety On".
- Activation Delay:** A slider control set to "0s".

Parameter	Description
ECU Protect Action	The action the DSE module takes when receiving an ECU Protect fault condition. The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information: None Electrical Trip Shutdown Warning
Arming	Select when the DSE module activates its <i>ECU Protect</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document: Always Engine Protection Activation From Safety On From Starting Loading Alarms Activation Never When Stationary
Activation Delay	The amount of time before the module activates the <i>ECU Protect</i> alarm after receiving an ECU Protect fault condition from the ECU.

2.9.2.2.3 INLET TEMPERATURE

Provides inlet temperature alarms when the module is used in conjunction with electronic (ECU) engines that support the reading of inlet temperature.



Parameter	Description
Inlet Temperature Alarm	<p>NOTE: The feature is only available when an electronic engine is selected.</p> <p><input type="checkbox"/> = Disable the alarm <input checked="" type="checkbox"/> = <i>Inlet Temperature Alarm</i> is activated when the <i>Inlet Temperature</i> sent from the ECU rise above the <i>Trip</i> level.</p>
Action	<p>Select the type of alarm required from the list:</p> <p>Electrical Trip Shutdown</p> <p>For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p>
Inlet Temperature Pre-Alarm	<p><input type="checkbox"/> = The alarm is disabled. <input checked="" type="checkbox"/> = <i>Inlet Temperature Pre-Alarm</i> is activated when the <i>Inlet Temperature</i> sent from the ECU is above the configured <i>Trip</i> level The Pre-Alarm is deactivated when the <i>Inlet Temperature</i> falls below the <i>Return</i> level.</p>

2.9.2.2.4 ADVANCED

NOTE: Configuration of parameters in this section only has effect when the ECU (ECM) supports the features.

Allows configuration of selected additional CAN messages from the engine ECU (ECM).

DPTC Filter

DPTC Filter

Enabled

Action Warning

Arming From Safety On

Parameter	Description
DPTC Filter Enabled	<p><input type="checkbox"/> = The DSE module's <i>DPTC Filter</i> alarm is disabled, it does not act upon any DPTC Filter fault conditions from the ECU.</p> <p><input checked="" type="checkbox"/> = The DSE module's <i>DPTC Filter</i> alarm is enabled. The action the DSE module takes when receiving a DPTC Filter fault condition from the ECU. The alarm action list is as follows, see section entitled <i>Alarm Types</i> The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>Electrical Trip Indication Shutdown Warning</p>
Arming	<p>Select when the DSE module activates its <i>DPTC Filter</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document:</p> <p>Always Engine Protection Activation From Safety On From Starting Loading Alarms Activation When Stationary</p>

HEST Active

HEST Active

Enabled

Action Warning


Arming From Safety On

Parameter	Description
HEST Active Enabled	<p><input type="checkbox"/> = The DSE module's <i>HEST</i> alarm is disabled, it does not act upon any HEST fault conditions from the ECU.</p> <p><input checked="" type="checkbox"/> = The DSE module's <i>HEST</i> alarm is enabled. The action the DSE module takes when receiving a HEST fault condition from the ECU.</p> <p>The alarm action list is as follows, see section entitled <i>Alarm Types</i> The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>Indication</p> <p>Warning</p>
Arming	<p>Select when the DSE module activates its <i>HEST</i> alarm.</p> <p>Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document:</p> <p>Always</p> <p>Engine Protection Activation</p> <p>From Safety On</p> <p>From Starting</p> <p>Loading Alarms Activation</p> <p>When Stationary</p>

DEF Level

Parameter	Description
DEF Level Enabled	<p><input type="checkbox"/> = The DSE module's <i>DEF Level</i> alarm is disabled; it does not act upon any DEF Level fault conditions from the ECU.</p> <p><input checked="" type="checkbox"/> = The DSE module's <i>DEF Level</i> alarm is enabled. The action the DSE module takes when receiving a DEF Level fault condition from the ECU. The alarm action list is as follows, see section entitled <i>Alarm Types</i> The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>Electrical Trip Shutdown Warning</p>
Arming	<p>Select when the DSE module activates its <i>DEF Level</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document:</p> <p>Always Engine Protection Activation From Safety On From Starting Loading Alarms Activation When Stationary</p>
Activation Delay	<p>The amount of time before the module activates the <i>DEF Level</i> alarm after a receiving a DEF Level fault condition from the ECU.</p>

SCR Inducement




Parameter	Description
SCR Inducement Enabled	<p><input type="checkbox"/> = The DSE module's <i>SCR Inducement</i> alarm is disabled; it does not act upon any SCR Inducement fault conditions from the ECU.</p> <p><input checked="" type="checkbox"/> = The DSE module's <i>SCR Inducement</i> alarm is enabled. The action the DSE module takes when receiving a SCR Inducement fault condition from the ECU.</p> <p>The alarm action list is as follows, see section entitled <i>Alarm Types</i> The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>Electrical Trip Shutdown Warning</p>
Arming	<p>Select when the DSE module activates its <i>SCR Inducement</i> alarm. Options are as follows, see the section entitled <i>Alarm Arming</i> elsewhere in this document:</p> <p>Always Engine Protection Activation From Safety On From Starting Loading Alarms Activation When Stationary</p>
Activation Delay	<p>The amount of time before the module activates the <i>SCR Inducement</i> alarm after a receiving a SCR Inducement fault condition from the ECU.</p>

2.9.3 OIL PRESSURE


NOTE: The DSE module reads oil pressure from the ECU (ECM) if the selected Engine Application supports it. In these cases, Analogue Input A is configured as Flexible Analogue or Digital Input. Configuration of Flexible Analogue Inputs and Digital Inputs is detailed elsewhere in this document.

Input Type



Parameter	Description
Input Type	Select the sensor type and curve from a pre-defined list or create a user-defined curve Resistive: for sensors with maximum range of 0 Ω to 480 Ω Current: for sensors with maximum range of 0 mA to 20 mA Voltage: for sensors with maximum range of 0 V to 10 V

Sensor Open Circuit Alarm



Parameter	Description
Enable Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Oil Pressure Open Circuit Alarm</i> is active when the module detects an open circuit when the sensor is disconnected.

Low Oil Pressure Alarms



Parameter	Description
Low Oil Pressure Shutdown	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Oil Pressure Shutdown Alarm</i> is active when the measured oil pressure drops below the configured <i>Trip</i> level.
Low Oil Pressure Pre-Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Oil Pressure Warning Alarm</i> is active when the measured oil pressure drops below the configured <i>Trip</i> level. The warning is automatically reset when the oil pressure increases above the configured <i>Return</i> level.

2.9.4 COOLANT TEMPERATURE

The *Coolant Temperature* page is subdivided into smaller sections. Select the required section with the mouse.

Coolant Temperature

[Coolant Temperature Alarms](#)

[Coolant Temperature Control](#)

2.9.4.1 COOLANT TEMPERATURE ALARM

NOTE: The DSE module reads oil pressure from the ECU (ECM) if the selected Engine Application supports it. In these cases, Analogue Input B is configured as Flexible Analogue or Digital Input. Configuration of Flexible Analogue Inputs and Digital Inputs is detailed elsewhere in this document.

Input Type

Input Type

VDO 120 °C Edit

Click to edit the sensor curve. See section entitled *Editing The Sensor Curve*.

Parameter	Description
Input Type	Select the sensor type and curve from a pre-defined list or create a user-defined curve Resistive: for sensors with maximum range of 0 Ω to 480 Ω Current: for sensors with maximum range of 0 mA to 20 mA Voltage: for sensors with maximum range of 0 V to 10 V

Sensor Open Circuit Alarm

Sensor Open Circuit Alarm

Enable Alarm

Parameter	Description
Enable Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Coolant Temperature Open Circuit Alarm</i> is active when the module detects an open circuit when the sensor is disconnected

Low Coolant Temperature Alarms

Parameter	Description
Low Coolant Temperature Pre-Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Coolant Temperature Warning Alarm</i> is active when the measured coolant temperature falls below the configured <i>Trip</i> level. The <i>Warning</i> is automatically reset when the coolant temperature rises above the configured <i>Return</i> level.

High Coolant Temperature Alarms

Parameter	Description
High Coolant Temperature Pre-Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The High Coolant Temperature Warning Alarm is active when the measured coolant temperature rises above the configured Trip level. The Warning is automatically reset when the coolant temperature falls below the configured Return level.
High Coolant Temperature Electrical Trip	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The High Coolant Temperature Controlled Shutdown Alarm is active when the measured coolant temperature rises above the configured Trip level.
High Coolant Temperature Shutdown	The High Coolant Temperature Shutdown Alarm is active when the measured coolant temperature rises above the configured Trip level.

2.9.4.2 COOLANT TEMPERATURE CONTROL

Coolant Heater Control

Parameter	Description
Coolant Heater Control	<input type="checkbox"/> = Coolant Heater Control function is disabled <input checked="" type="checkbox"/> = The digital output configured to <i>Coolant Heater Control</i> is energised when the engine coolant temperature falls below the configured <i>On</i> level. This is designed to control an external engine heater. When the coolant temperature rises above the configured <i>Off</i> level, the digital output is de-energised.

Coolant Cooler Control

Parameter	Description
Coolant Cooler Control Enable	<input type="checkbox"/> = Coolant Cooler Control function is disabled <input checked="" type="checkbox"/> = The digital output configured to <i>Coolant Cooler Control</i> is energised when the engine coolant temperature exceeds the configured <i>On</i> level. This is designed to control an external engine cooling system, for instance an additional cooling fan. When the coolant temperature falls below the configured <i>Off</i> level, the digital output is then de-energised.
Disable When Set Not Available	<input type="checkbox"/> = The <i>Coolant Cooler Control</i> operates as normal. <input checked="" type="checkbox"/> = The <i>Coolant Cooler Control</i> operates only when the generator is running.

Fan Control

Parameter	Description
Fan Control	An output configured to <i>Fan Control</i> energises when the engine becomes available (up to speed). This output is designed to control an external cooling fan. When the engine stops, the cooling fan remains running for the duration of the <i>Fan Overrun Delay</i> .


2.9.5 FUEL OPTIONS

The *Fuel Level* page is subdivided into smaller sections. Select the required section with the mouse.




2.9.5.1 FUEL CONTROL AND MONITORING

Input Type




Parameter	Description
Input Type	Select the sensor type and curve from a pre-defined list or create a user-defined curve

In the case of a parallel sided fuel tank, an accurate measure of the fuel level is easily made, however this is not the case with non-parallel sided fuel tanks. Alteration to the fuel level sensor curve is required for non-parallel sided to attain more accurate level indication. This is because a fuel level sensor measures the distance between the top of the tank and the fuel level.




Fuel Pump Control



Parameter	Description
Fuel Pump Control Enable	<p><input type="checkbox"/> = Fuel Pump Control is disabled.</p> <p><input checked="" type="checkbox"/> = Allows the module to control an external fuel pump to transfer fuel from a bulk tank to the day tank.</p> <p>A digital output configured for <i>Fuel Pump Control</i> energises when the fuel level falls below the configured <i>On</i> setting and de-energises when the fuel level exceeds the configured <i>Off</i> setting.</p>

Fuel Monitoring




NOTE: Sending events by SMS is only available when the module is configured to communicate to a supported modem by RS232. Refer to section entitled RS232 Port elsewhere in this document for further details.

Parameter	Description
Fuel Tank Size	Select the tank size and the units for the module's display: Imperial Gallons Litres US Gallons
Logging Interval	The interval at which the fuel level is stored in the event log.
Dial Out on Logging	<p><input type="checkbox"/> = Dial Out on Logging is disabled.</p> <p><input checked="" type="checkbox"/> = Dial Out on Logging is enabled. When the <i>Fuel Level</i> is recorded in the module's event log, the module dials the pre-configured number of a PC.</p>
SMS Enabled	<p><input type="checkbox"/> = <i>Fuel Level Values</i> are not sent by SMS message.</p> <p><input checked="" type="checkbox"/> = The value of the <i>Fuel Level</i> is sent by SMS message at the configured <i>SMS Interval</i> based on the <i>Logging Interval</i>.</p>
Stable Timer	<p>The controller maintains a rolling record of the fuel level percentage for the duration of the <i>Stable Timer</i>.</p> <p>When the rolling record of the fuel level percentage indicates that the fuel level has increased more than the <i>Change Indicating Filling</i> during the <i>Stable Timer</i>, the controller records a <i>Fuel Filling Start</i> event in its event log.</p> <p>When the rolling record of the fuel level indicates that the fuel level has not changed more than the <i>Change Indicating Stable</i> during the <i>Stable Timer</i>, the controller records a <i>Fuel Filling Stop</i> event in its event log.</p>

Parameter descriptions are continued overleaf...

Parameter	Description
Change Indicating Filling	<p>When the fuel level increases at a rate higher than</p> <p><u>Change Indicating Filling</u> <i>Stable Timer</i></p> <p>Then a fuel fill start event is recorded into the event log. Depending on configuration this generates a dial out or SMS message.</p> <p>Example <i>Stable Timer</i> = 1 minute <i>Change Indicating Filling</i> = 3 %</p> <p>When the fuel level increases by more than 3% in 1 minute, a fuel fill event is recorded.</p>
Change Indicating Stable	<p>During filling, if the fuel level increases at a rate less than</p> <p><u>Change Indicating Stable</u> <i>Stable Timer</i></p> <p>then a fuel fill end event is recorded into the event log. Depending on configuration this generates a dial out or SMS message.</p> <p>Example: <i>Stable Timer</i> = 1 minute <i>Change Indicating Stable</i> = 2 %</p> <p>When the fuel level increases by less than 2% in 1 minute, a fuel fill end event is recorded.</p>

Fuel Usage Alarm



Parameter	Description
Fuel Usage Alarm	<p>Provides an alarm to monitor the usage of the fuel.</p> <p>The alarm activates when the fuel level drops at a higher rate than the configured <i>Running Rate</i> while the engine is running. Or if the fuel level drops at a higher rate than the configured <i>Stopped Rate</i> while the engine is stopped. This alarm is provided to check for fuel leakage problems or potential fuel theft.</p>
Mode	<p>Standard Mode: The fuel usage alarm activates when the fuel level decreases at a higher rate per hour than the configured <i>Running Rate</i> while the engine is running or <i>Stopped Rate</i> while the engine is stopped.</p> <p>Sampling Window: The fuel usage alarm activates when the fuel level decreases at a higher rate per <i>Sampling Window</i> than the configured <i>Running Rate</i> while the engine is running or <i>Stopped Rate</i> while the engine is stopped.</p>

2.9.5.2 FUEL LEVEL ALARMS

Sensor Open Circuit Alarm

Sensor Open Circuit Alarm

Enable Alarm

Parameter	Description
Sensor Open Circuit Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Fuel Level Open Circuit Alarm</i> is active when the module detects an open circuit when the sensor is disconnected

Low Fuel Level Alarms

Low Fuel Level Alarms

Alarm

Action Shutdown

Trip 25 %

Delay 0s

Pre-Alarm

Trip 30 %

Return 40 %

Delay 0s

Parameter	Description
Low Fuel Level Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Fuel Level Alarm</i> activates with the configured <i>Action</i> when the measured fuel level drops below the <i>Trip</i> setting for the configured <i>Delay</i> time.
Action	<div style="border: 3px double black; padding: 5px;"> <p>NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p> </div> <p>Select the type of alarm required from the list:</p> <p>Electrical Trip</p> <p>Shutdown</p>
Low Fuel Level Pre-Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Fuel Level Pre-Alarm</i> activates with the configured <i>Action</i> when the measured fuel level drops below the <i>Low Pre-Alarm Trip</i> setting for the configured <i>Delay</i> time. The pre-alarm is automatically reset when the fuel level exceeds the configured <i>Low Pre-Alarm Return</i> setting.

High Fuel Level Alarms

Parameter	Description
High Fuel Level Pre-Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Fuel Level Pre-Alarm</i> activates with the configured <i>Action</i> when the measured fuel level rises above the <i>High Pre-Alarm Trip</i> setting for the configured <i>Delay</i> time. The pre-alarm is automatically reset when the fuel level drops below the configured <i>High Pre-Alarm Return</i> setting.
High Fuel Level Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Fuel Level Alarm</i> activates with the configured <i>Action</i> when the measured fuel level raises above the <i>Trip</i> setting for the configured <i>Delay</i> time.
Action	<div style="border: 1px solid black; padding: 5px;"> <p>▲ NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p> </div> <p>Select the type of alarm required from the list: <i>Electrical Trip</i> <i>Shutdown</i></p>

2.9.5.3 ADVANCED ALARMS

Water in Fuel

The screenshot shows a configuration window titled "Water In Fuel". It contains three settings:

- Action:** A dropdown menu currently set to "Warning".
- Arming:** A dropdown menu currently set to "Always".
- Activation Delay:** A slider control set to "0s".

Parameter	Description
Action	<p>The alarm activates when a <i>Water in Fuel</i> alarm is received from the engine ECU, or if a digital input configured for <i>Water in Fuel</i> activates for longer than the configured <i>Activation Delay</i> timer.</p> <p>The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>None Electrical Trip Shutdown Warning</p>
Arming	<p>Select when the alarm is active, see section entitled <i>Alarm Arming</i> for more information:</p> <p>Always Engine Protection Activation From Safety On From Starting Loading Alarms Activation Never When Stationary</p>

Fuel Tank Bund

Fuel Tank Bund

Action Warning

Arming Always

Activation Delay 0s

Parameter	Description
Action	<p>The alarm goes active when a digital input configured for <i>Fuel Tank Bund Level High</i> activates for longer than the configured <i>Activation Delay</i> timer.</p> <p>The input is designed to connect to a level switch within the tank bund (sometimes known as the Fuel Retention Tank). This is used to detect fuel leaks and/or overflows.</p> <p>The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information:</p> <p>None Electrical Trip Shutdown Warning</p>
Arming	<p>Select when the alarm is active, see section entitled <i>Alarm Arming</i> for more information:</p> <p>Always Engine Protection Activation From Safety On From Starting Loading Alarms Activation Never When Stationary</p>

2.9.5.4 FUEL USE AND EFFICIENCY

Engine Efficiency Curve

Parameter	Description
Engine Type	Select the engine type from a pre-defined list or create a user-defined curve.
Specific Gravity	The relative fuel density of the fuel (usually given as kg/m ³) being consumed by the generator.

Instrumentation Sources

Parameter	Description
Instantaneous Fuel Consumption	Not Used: <i>Instantaneous Fuel Consumption</i> is not displayed. Efficiency Curve: The DSE module calculates the <i>Instantaneous Fuel Consumption</i> as Litre/hour from <i>Generator Total kW Percentage</i> using the <i>Efficiency Curve</i> and <i>Specific Gravity</i> . Engine ECU: The DSE module reads the <i>Instantaneous Fuel Consumption</i> as Litre/hour from the engine ECU.
Trip Average Fuel Consumption	Not Used: <i>Trip Average Fuel Consumption</i> is not displayed. Efficiency Curve: The DSE module calculates the <i>Trip Average Fuel Consumption</i> as litre/hour over the current or last run from <i>Generator Total kW Percentage</i> using the <i>Efficiency Curve</i> and <i>Specific Gravity</i> . Engine ECU: The DSE module reads the <i>Trip Average Fuel Consumption</i> as litre/hour over the current or last run from the engine ECU. Module Sensor: The DSE module calculates the <i>Trip Average Fuel Consumption</i> as litre/hour over the current or last run from the change in fuel tank level using the <i>Fuel Tank Size</i> .
Trip Fuel Usage	Not Used: <i>Trip Fuel Usage</i> is not displayed. Efficiency Curve: The DSE module calculates the <i>Trip Fuel Usage</i> as litres over the current or last run from <i>Generator Total kW Percentage</i> using the <i>Efficiency Curve</i> and <i>Specific Gravity</i> . Engine ECU: The DSE module reads the <i>Trip Fuel Usage</i> as litres over the current or last run from the engine ECU. Module Sensor: The DSE module calculates the <i>Trip Fuel Usage</i> as litres over the current or last run from the change in fuel tank level using the <i>Fuel Tank Size</i> .

Parameter descriptions are continued overleaf...

Parameter	Description
Accumulated Fuel Usage	<p>Not Used: <i>Accumulated Fuel Usage</i> is not displayed.</p> <p>Efficiency Curve: The DSE module calculates the <i>Accumulated Fuel Usage</i> as litres over the entire run time from <i>Generator Total kW Percentage</i> using the <i>Efficiency Curve</i> and <i>Specific Gravity</i>.</p> <p>Engine ECU: The DSE module reads the <i>Accumulated Fuel Usage</i> as litres over the entire run time from the engine ECU.</p> <p>Module Sensor: The DSE module calculates the <i>Accumulated Fuel Usage</i> as litres over the entire run time from the change in fuel tank level using the <i>Fuel Tank Size</i>.</p>
Instantaneous Efficiency	<p>Not Used: <i>Instantaneous Efficiency</i> is not displayed.</p> <p>Efficiency Curve: The DSE module calculates the <i>Instantaneous Efficiency</i> as kWh/litre from <i>Generator Total kW Percentage</i> using the <i>Efficiency Curve</i> and <i>Specific Gravity</i>.</p> <p>Engine ECU: The DSE module reads the <i>Instantaneous Fuel Consumption</i> as Litre/hour from the engine ECU and calculates the <i>Instantaneous Efficiency</i> as kWh/litre using the <i>Generator Total kW Percentage</i>.</p>
Trip Average Efficiency	<p>Not Used: <i>Trip Average Efficiency</i> is not displayed.</p> <p>Efficiency Curve: The DSE module calculates the <i>Trip Average Efficiency</i> as kWh/litre over the current or last run from <i>Generator Total kW Percentage</i> using the <i>Efficiency Curve</i> and <i>Specific Gravity</i>.</p> <p>Engine ECU: The DSE module reads the <i>Trip Average Fuel Consumption</i> as Litre/hour from the engine ECU over the current or last run and calculates the <i>Trip Average Efficiency</i> as kWh/litre using the <i>Generator Total kW Percentage</i>.</p> <p>Module Sensor: The DSE module calculates the <i>Trip Average Efficiency</i> as kWh/litre over the current or last run from the change in fuel tank level using the <i>Fuel Tank Size</i> and <i>Generator Total kW Percentage</i>.</p>
Estimate Run Time to Empty	<p>Not Used: <i>Estimate Run Time to Empty</i> is not displayed.</p> <p>Engine ECU: The DSE module reads the <i>Instantaneous Fuel Consumption</i> as Litre/hour from the engine ECU and <i>Estimates Run Time to Empty</i> using the <i>Fuel Tank Size</i>.</p> <p>Module Sensor: The DSE module <i>Estimates Run Time to Empty</i> using the <i>Run Time Until Empty</i> parameters.</p>

Run Time Until Empty

Run Time Until Empty

Fuel Tank Run Time: 480 m

Fuel Tank Run Time Load Level Percentage: 100 %


Parameter	Description
Fuel Tank Run Time	The time in minutes how long the generator's fuel tank last when running at the <i>Fuel Tank Run Time Load Level Percentage</i> .
Fuel Tank Run Time Load Level Percentage	The percentage of full load kW the generator which is used to calculate how long the fuel in the tank lasts.

2.9.6 DEF LEVEL

NOTE: Configuration of alarms in this section only has effect when the ECU (ECM) supports DEF Level.


NOTE: Configuration of the *Alarm Action* in this section defines the DSE module response to the CANbus message; however, the ECU (ECM) still shuts down the engine depending on the alarm severity.

DEF Level is a CANbus message from the ECU (ECM). The following parameters allow configuration of how the DSE module responds to the DEF Level.



Parameter	Description
DEF Level Low Alarm	<input type="checkbox"/> = Disable the alarm <input checked="" type="checkbox"/> = <i>DEF Low Alarm</i> activates when the <i>DEF Level</i> sent from the ECU is below the configured <i>Trip</i> level for longer than the configured <i>Delay</i> time.
Action	Select the type of alarm required from the list: Shutdown Electrical Trip For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.
DEF Level Low Pre-Alarm	<input type="checkbox"/> = The Pre-alarm is disabled. <input checked="" type="checkbox"/> = <i>DEF Low Pre-Alarm</i> activates when the <i>DEF Level</i> sent from the ECU is below the configured <i>Trip</i> level for longer than the configured <i>Delay</i> time. The Pre-Alarm is deactivated when the <i>DEF Level</i> rises above the <i>Return</i> level.

2.9.7 GAS ENGINE OPTIONS




Parameter	Description
Choke Timer	Controls the amount of time that the Gas Choke output is active during the starting sequence.
Gas On Delay	Controls the amount of time between energising the Gas Ignition and energising the Fuel output. Used in the starting sequence to purge old gas from the engine.
Ignition Off Delay	Controls the amount of time between de-energising the Fuel output and de-energising the Gas Ignition output. Used in the stopping sequence to purge unburnt gas from the engine before it is stopped.

2.9.8 CRANKING

Crank disconnect settings are used to detect when the set fires during the starting sequence. As the set is cranked, the first parameter that passes it's *crank disconnect* setting results in the cessation of the cranking signal.

Having more than one *crank disconnect* source allows for a much faster crank disconnect response leading to less wear on the engine and starter components and provides added safety in case one source is lost, by a blown or tripped fuse for example.


Options



When *Check Oil Pressure Prior to Starting* is enabled, the cranking is not allowed if the oil pressure is not seen as being low. This is used as a *double check* that the engine is stopped before the starter is engaged.


Parameter	Description
Crank Disconnect on Oil Pressure	<input type="checkbox"/> = The DSE module does not use oil pressure to decide when to disengage the starter motor. <input checked="" type="checkbox"/> = The DSE module does uses oil pressure to decide when to disengage the starter motor in addition to the enabled methods.
Check Oil Pressure Prior to Starting	<input type="checkbox"/> = The DSE module does not use oil pressure as an indication if the engine is running. This is disabled for large engines that have an electrical oil pump which is used to maintain oil pressure even when the engine is stationary. <input checked="" type="checkbox"/> = The DSE module uses oil pressure as an indication if the engine is running.

Crank Disconnect



Parameter	Description
Generator Frequency	The DSE module disengages the starter motor when the generator frequency rises above the configured level.
Engine Speed	The DSE module disengages the starter motor when the engine speed rises above the configured level.
Oil Pressure	The DSE module disengages the starter motor when the engine oil pressure rises above the configured level for longer than the <i>Oil Pressure Delay time</i> .
Charge Alternator	<input type="checkbox"/> = The DSE module does not use charge alternator voltage to decide when to disengage the starter motor. <input checked="" type="checkbox"/> = The DSE module disengages the starter motor when the charge alternator voltage rises above the configured level.
Generator Voltage	<input type="checkbox"/> = The DSE module does not use the generator voltage to decide when to disengage the starter motor. <input checked="" type="checkbox"/> = The DSE module disengages the starter motor when the generator voltage rises above the configured level.

Manual Crank



Parameter	Description
Hold Start Button To Crank	<input type="checkbox"/> = Manual Crank is disabled. <input checked="" type="checkbox"/> = Press and hold the <i>Start</i> button to crank in <i>Manual</i> mode, releasing the <i>Start</i> button during a manual start disconnects the crank.
Manual Crank Limit Timer	Manual Crank Limit protects the engine from being cranked too long in case of a start failure. This is the maximum time to crank the engine when the <i>Start</i> button is kept pressed.

2.9.9 SPEED SENSING

Options

Disable ECM Speed Sensing

Magnetic Pickup Fitted Engine speed is read from the ECU (ECM)

Flywheel Teeth

Enable Multiple Engage Attempts

Engage Attempts

Loss of Sensing Signal


Disable under speed alarms if sensor fails

Magnetic pickup open circuit

Parameter	Description
Disable ECM Speed Sensing	<input type="checkbox"/> = An ECM is connected to the DSE module and being used for speed sensing. <input checked="" type="checkbox"/> = An ECM is connected to the DSE module but another form of speed sensing fitted to the DSE module is being used.
Magnetic Pickup Fitted	<div style="border: 2px solid black; padding: 5px;"> <p>NOTE: For specifications of the magnetic pickup input, refer to DSE Publication: 057-263 DSE7410 MKII & DSE7420 MKII Operator Manual which is found on our website: www.deepseaelectronics.com</p> </div> <input type="checkbox"/> = Magnetic pickup device is not connected to the DSE module. <input checked="" type="checkbox"/> = A low impedance magnetic pickup device is connected to the DSE module to measure engine speed.
Flywheel Teeth	Define the number of pulses which are counted by the speed sensing device in each engine revolution.
Enable Multiple Engage Attempts	<input type="checkbox"/> = No engage attempt is given. If no speed sensing is detected during cranking, the <i>Fail To Start</i> alarm is active. <input checked="" type="checkbox"/> = If no magnetic pickup pulses are detected during cranking, it is assumed that the starter has not engaged to turn the engine. The starter is withdrawn and re-energised for the configured number of <i>Engage Attempts</i> .
Loss of Sensing Signal	If the speed sensing signal is lost during engine running (or not present during cranking when <i>Multiple Engage Attempts</i> is enabled), an alarm is generated: <i>Shutdown:</i> The engine is removed from load and is immediately stopped. <i>Warning:</i> The engine continues to run, however a warning alarm is raised.
Disable Under Speed Alarms If Sensor Fails	<input type="checkbox"/> = Under speed alarms activate even if speed sensor has failed. <input checked="" type="checkbox"/> = Under speed alarms are disabled when the speed sensor fails.
Magnetic Pickup Open Circuit	If the magnetic pickup device is not detected, an alarm is generated: <i>Shutdown:</i> The engine is removed from load and is immediately stopped. <i>Warning Always Latched:</i> The engine continues to run, however a latched warning alarm is raised even if the magnetic pickup signal returns to normal.


2.9.10 SPEED SETTINGS

Under Speed




Parameter	Description
Under Speed Alarm	<input type="checkbox"/> = <i>Under Speed</i> alarm is disabled <input checked="" type="checkbox"/> = Under Speed gives an alarm in the event of the engine speed falling below the configured <i>Under Speed Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Underspeed Alarm Trip</i> value is adjustable to suit user requirements.
Action	Select the type of alarm required from the list: Shutdown Electrical Trip For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.
Under Speed Pre-Alarm	<input type="checkbox"/> = <i>Under Speed Warning</i> alarm is disabled <input checked="" type="checkbox"/> = Under Speed gives a warning alarm in the event of the engine speed falling below the configured <i>Under Speed Pre-Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Under Speed Pre-Alarm Trip</i> value is adjustable to suit user requirements.

Over Speed




Parameter	Description
Over Speed Pre-Alarm	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Over Speed gives a warning alarm in the event of the engine speed rising above the configured <i>Over Speed Pre-Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Warning</i> is automatically reset when the engine speed falls below the configured <i>Return</i> level. The <i>Over Speed Pre-Alarm Trip</i> value is adjustable to suit user requirements.
Over Speed Alarm	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Over Speed gives a <i>Shutdown</i> alarm in the event of the engine speed rising above the configured <i>Over Speed Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Over Speed Alarm Trip</i> value is adjustable to suit user requirements.

Run Away



Parameter	Description
Run Away	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = In the event of the engine speed rising above the configured <i>Trip</i> value the <i>Run Away Shutdown</i> alarm is immediately triggered. This is used to protect against engine damage due to uncontrolled speed increase, where the engine speed runs away.
Trip	Set the speed level for the <i>Run Away</i> alarm.


Overspeed Options



Parameter	Description
Overspeed Overshoot %	To prevent spurious overspeed alarms at engine start up, the module includes configurable <i>Overspeed Overshoot</i> protection. This allows the engine speed to 'overshoot' the Overspeed setting during the starting process for a short time.
Overshoot Delay	Rather than 'inhibiting' the Overspeed alarms, the levels are temporarily raised by the <i>Overspeed Overshoot %</i> for the duration of the <i>Overspeed Overshoot</i> delay from starting.


2.9.11 PLANT BATTERY

Voltage Alarms



Parameter	Description
Plant Battery Under Voltage IEEE 37.2 -27 DC Undervoltage Relay	The alarm activates when the battery voltage drops below the configured <i>Pre-Alarm</i> level for the configured <i>Delay</i> time. When the battery voltage rises above the configured <i>Return</i> level, the alarm is de-activated.
Plant Battery Over Voltage IEEE 37.2 -59 DC Overvoltage Relay	The alarm activates when the battery voltage rises above the configured <i>Pre-Alarm</i> level for the configured <i>Delay</i> time. When the battery voltage drops below the configured <i>Return</i> level, the alarm is de-activated.

Charge Alternator Alarm



Parameter	Description
Use Module For Charge Alternator	<p>NOTE: The feature is only available when an electronic engine is selected.</p> <p>When enabled, DSE module measures the charge alternator voltage. When disabled, Engine ECU (ECM) provides charge alternator voltage.</p>
Charge Alternator Shutdown Alarm	The alarm activates when the charge alternator voltage falls below the configured <i>Trip</i> level for the configured <i>Delay</i> time.
Charge Alternator Warning Alarm	The alarm activates when the charge alternator voltage falls below the configured <i>Trip</i> level for the configured <i>Delay</i> time.

2.9.12 ENGINE ICON DISPLAYS

This section is used with Electronic Engines, it allows to create or define a CAN Lamp icon and how to be displayed when the configured alarm or message is active, such as flashing the CAN icon rapidly or slowly. The first screen is enabled by default, and it cannot be disabled, the second and third screens are configurable to be enabled or disabled through this section to allow the user create more CAN Icon Displays. The CAN icon instrument is activated based on a DTC message sent from the ECU or according to GenComm instrumentation conditions.


2.9.12.1 TITLE INSTRUMENTATION


Select the display form of the DEF Tank Level instrument in the relevant screen.










Title Instrumentation	Display
Not Used	The <i>DEF Tank Level</i> is not displayed in the title of the screen.
DEF Tank Level (Gauge)	<p>The <i>DEF Tank Level</i> is displayed in form of bar gauge meter </p> <p>The DEF Tank Level (gauge) display is flashed slowly or rapidly on the screen if the conditions and values are configured and the instrument readings are satisfied.</p>
DEF Tank Level (numeric)	The <i>DEF Tank Level</i> is displayed in numeric form

2.9.12.2 ICON INSTRUMENTATION

Displays

Select the required Lamp Icon from the screen to configure or click on the  tab to create a new Lamp Icon.




Display tab tools	Description
	Click on the Plus tab to create a new Lamp Icon within the selected screen.
	Click on the delete tab to delete the selected Lamp Icon from the screen.
	Click on the right or left tab to select the next Lamp Icon in the screen.
	Click to hide the instruments from the screens.
	Click to show all the instruments in the screens.
	This tool is for flashing demonstration. Click to flash all the instruments slowly.
	This tool is for flashing demonstration. Click to flash all the instruments rapidly.
	Click to import a saved <i>Engine Icon Displays</i> .
	Click to export the configured <i>Engine Icon Displays</i> .

Icon Bitmaps

Configure the Icon Bitmaps of the selected instrument from the screen, to show the Lamp Icon when it active or inactive












Indicates the selected Icon to show when the instrument is active and the module is flashing it on.

Click on  to delete the icon.

Click to select the Lamp Icon. The available icons are listed in the below table.

Icon Bitmaps	Description
Flash On (On)	Select the icon to show when the instrument is active and the module has flashed on the <i>Engine Icons</i> on the screen.
Flash Off	Select the icon to show when the instrument is active and the module has flashed off the <i>Engine Icons</i> on the screen.
Off	Select the icon to show when the instrument is not active on the screen.
Position X, Y	Configure the instrument positions for X & Y coordinates on the screen.


Continued Overleaf...

Lamp Icons	Display
	DEF On Large
	DEF On
	DPF Active
	DPF Inhibit
	DPF Stop
	DPF Warning
	ECU Red Alarm
	ECU Yellow Alarm
	HEST On
	SCR Active Large
	SCR Active

Icon Instrumentation


Configure the Type of the Instrumentation to read from the DTC or from a GenComm register, and on what condition(s) the selected instrument to be On or flashing.

Icon Instrumentation DTC Type





Icon Instrumentation	Description
On DTC	Configure the DTC code to activate the instrument when <i>On DTC</i> satisfied.
Slow DTC	Configure the DTC code to flash the instrument slowly when <i>Slow DTC</i> satisfied.
Fast DTC	Configure the DTC code to flash the instrument rapidly when <i>Fast DTC</i> satisfied.

Icon Instrumentation GenComm Type




Parameters detailed overleaf...

Icon Instrumentation	Description
Instrumentation	Select the instrument to monitor. This could be a flag condition or an instrumentation value.
Flag type of GenComm Icon Instrument	<p>Select the required Condition to activate the Instrumentation Icon, or to Slow Flash, or to Fast Flash based on the options below:</p> <p><i>Not Used</i> <i>When Inactive</i> <i>When Active</i></p> 
Instrumentation type of GenComm Icon Instrument	<p>Configure the required Condition to activate the Instrumentation Icon, or to Slow Flash, or to Fast Flash.</p> 


2.10 COMMUNICATIONS

The *Communications* page is subdivided into smaller sections. Select the required section with the mouse.



2.10.1 COMMUNICATION OPTIONS

Provides a means of giving the controller an identity. This is used in the SCADA section to allow the operator to see the site name and engine identity that it is currently connected to. This feature is used when a remote module is connected over modem or Ethernet.




Free text entries to identify the engine. This text is displayed on the SCADA screen when the module is connected to the PC.

Parameter	Description
Site Identity	A free entry boxes to allow the user to give the DSE module a description of where the site is located. This text is not shown on the module's display and is only seen when performing remote communication. This aids the user in knowing where the generator is located.
Genset Identity	A free entry boxes to allow the user to give the DSE module a description of which generator it is connected to. This text is not shown on the module's display and is only seen when performing remote communication. This aids the user in knowing which generator on a specific site is being monitored.


2.10.2 RS232 PORT


The *RS232 Port* section is subdivided into smaller sections. Select the required section with the mouse.



2.10.2.1 BASIC

Serial Port Configuration

 **NOTE:** Connecting a modem directly to the module's RS232 for is legacy support only. When a new installation requires remote communication using the cellular network, refer to DSE products DSE890, DSE891 and DSEWebNet on the DSE website: www.deepseaelectronics.com.



Parameter	Description
Server ID	Select the server ID of the DSE module's RS232 port.
Baud Rate	Select the Baud Rate (speed of communication) of the DSE module's RS232 port. Every device on the RS232 link must have the same Baud Rate. 1200 2400 4800 9600 14400 19200 28800 38400 57600 115200
Port Usage	<p>No Modem: RS232 ports is used for direct RS232 connection to PLC, BMS etc</p> <p>Incoming Modem Calls: RS232 port connected to modem, used to accept incoming calls from a PC only.</p> <p>Incoming And Outgoing Modem (Sequence): RS232 port connected to modem used to accept incoming calls from a PC and make calls upon events. When multiple <i>Alarm Numbers</i> are configured, the module attempts to dial each number. When the dial out call fails to one of the configured numbers, the module attempts to call that number for the configured number of <i>Retries</i>, before it carries on to the next number.</p> <p>Incoming And Outgoing Modem (Cyclic): RS232 port connected to modem used to accept incoming calls from a PC and make calls upon events. When multiple <i>Alarm Numbers</i> are configured, the module attempts to dial each number. When the dial out call fails to one of the configured numbers, the module completes the cycle and re-attempts to call those numbers for the configured number of <i>Retries</i>.</p> <p>Outgoing Modem Alarms (Sequence): RS232 port connected to modem, used to make calls upon events. When multiple <i>Alarm Numbers</i> are configured, the module attempts to dial each number. When the dial out call fails to one of the configured numbers, the module attempts to call that number for the configured number of <i>Retries</i>, before it carries on to the next number.</p> <p>Outgoing Modem Alarms (Cyclic): RS232 port connected to modem, used to make calls upon events. When multiple <i>Alarm Numbers</i> are configured, the module attempts to dial each number. When the dial out call fails to one of the configured numbers, the module completes the cycle and re-attempts to call those numbers for the configured number of <i>Retries</i>.</p>

Modem Settings

NOTE: Connecting a modem directly to the module's RS232 for is legacy support only. When a new installation requires remote communication using the cellular network, refer to DSE products DSE890, DSE891 and DSEWebNet on the DSE website: www.deepseaelectronics.com.

The screenshot shows a 'Modem Settings' window with the following elements:

- Alarm numbers:** Three empty text input fields.
- GSM Modem:** A checkbox that is checked.
- SMS Message centre number:** One empty text input field.
- SMS Recipient numbers:** Three empty text input fields.
- Send extended instrumentation:** An unchecked checkbox.
- Send as flash message:** An unchecked checkbox.

Parameter	Description
Alarm Numbers	The phone number that the module dials upon an event. This number must be connected to a PC modem on a PC running the DSE Configuration Suite Software. Leave this field empty when dial-out to a PC is not required.
GSM Modem	<input type="checkbox"/> = The connected modem is a fixed line telephone modem <input checked="" type="checkbox"/> = The connected modem is a GSM (cellular) modem. The GSM signal strength meter and GSM operator are shown on the module display.
SMS Message Centre Number	The Message centre used to send SMS messages. This number is obtained from the GSM operator.
SMS Recipient Numbers	Numbers of the cell phones to send SMS messages to. Leave blank if SMS function is not required.
Send Extended Instrumentation	<input type="checkbox"/> = The SMS message that is sent only contains information about the event. <input checked="" type="checkbox"/> = When the module sends an SMS message for an event, it also contains information about the generator (such as oil pressure) at the time the event occurred.
Send as Flash Message	<input type="checkbox"/> = The type of SMS message that is sent is standard. <input checked="" type="checkbox"/> = The type of SMS message that is sent is a flash message. A flash SMS is a type of message that without user action appears directly and full screen on the phone.

2.10.2.2 ADVANCED

NOTE: Connecting a modem directly to the module's RS232 for is legacy support only. When a new installation requires remote communication using the cellular network, refer to DSE products DSE890, DSE891 and DSEWebNet on the DSE website: www.deepseaelectronics.com.

Initialisation Strings

Initialisation Strings	
Init (not auto answer)	E0S7=60S0=0&S0&C1&D3
Init (auto answer)	E0S7=60S0=2&S0&C1&D3
Hangup	H0

The initialisation strings are commands that are sent to the modem upon powering up the DSE module and additionally at regular intervals subsequently, whenever the DSE module *Initialises* (resets) the modem.

Factory Set Initialisation Strings

Parameter	Description
E0	Echo off
S7=60	Wait for carrier time 60s
S0=0 (not auto answer)	Do not answer
S0=2 (auto answer)	Answer after two rings
&S0	DSR always on
&C1	DCD is active if modem is online
&D3	Reset (ATZ) on DTR-drop
H0	Hang up (disconnect)

Silent Operation

The modem connected to the DSE controller usually makes dialling noises and 'squeal' in the initial stages of making a data call. To control this noise, add the following command to the end of the initialisation string:

Parameter	Description
M0	Silent operation
M1	Sounds during the initial stages of making a data call
M2	Sounds always when connected (not recommended for troubleshooting)

Sierra/Wavecom Fastrak Supreme GSM Modem Initialisation Strings

When connected to the Wavecom Fastrak Supreme GSM modem, the initialisation strings must be altered by changing the factory set &D3 to &D2.

Initialisation Strings	
Init (not auto answer)	E057=6050=0&S0&C1&D2
Init (auto answer)	E057=6050=2&S0&C1&D2
Hangup	H0

Parameter	Description
&D2 (required for Sierra / Wavecom Fastrak Supreme)	Hang up on DTR-drop
&D3 (DSE module factory settings)	Reset on DTR-drop

Other Modems

When using modems not recommended by DSE, first try either of the options shown above. If problems are still encountered, contact your modem supplier for further advice.


Connection Settings

Connection Settings	
Master inactivity timeout	5s
Connect delay	60s
Retries	4
Retry delay	5s
Repeat cycle delay	10s
Inter-frame delay	0 ms

Parameter	Description
Client Inactivity Timeout	The module monitors by default the USB port for communications. When activity is detected on the RS232 port, the module monitors the port for further data. If no data activity is detected on the port for the duration of the client <i>Inactivity Timer</i> , it reverts to looking at the USB port. This needs to be set longer than the time between Modbus polls from the client.
Connect Delay	The amount of time that is allowed to elapse between the alarm being registered and the controller dialling out with the fault.
Retries	The number of times the module attempts to contact the remote PC by modem.
Retry Delay	The amount of time between retries
Repeat Cycle Delay	The amount of time between the cycle repeats when dialling out calls to multiple <i>Alarm Numbers</i> fails.
Inter-frame Delay	Set the time delay between the DSE module receiving a MODBUS RTU request and the DSE module's response.


2.10.2.3 SMS CONTROL

NOTE: Connecting a modem directly to the module's RS232 for is legacy support only. When a new installation requires remote communication using the cellular network, refer to DSE products DSE890, DSE891 and DSEWebNet on the DSE website: www.deepseaelectronics.com.



Parameter	Description
Require PIN	<input type="checkbox"/> = A control code sent by SMS does not require a PIN code entered before the code. <input checked="" type="checkbox"/> = For security, the configured <i>PIN Prefix</i> must be entered in the SMS prior to the control code.
Start Off Load (Code 1)	<input type="checkbox"/> = Sending code 1 to the module via SMS does not issue a <i>Start Off Load</i> command. <input checked="" type="checkbox"/> = When in Auto mode, the module performs the start sequence, but the engine is not instructed to take the load when code 1 is sent via SMS. This function is used where an engine only run is required e.g. for exercise.
Start On Load (Code 2)	<input type="checkbox"/> = Sending code 2 to the module via SMS does not issue a <i>Start On Load</i> command. <input checked="" type="checkbox"/> = When in auto mode, the module performs the start sequence and transfer load to the engine when code 2 is sent via SMS.
Cancel (Code 3)	<input type="checkbox"/> = Sending code 3 to the module via SMS does not issue a cancel the start command issued by code 1 or 2. <input checked="" type="checkbox"/> = Sending code 3 to the module via SMS cancels the start command issued by code 1 or 2.
Stop Mode (Code 4)	<input type="checkbox"/> = Sending code 4 to the module via SMS does not issue place the unit into its <i>Stop Mode</i> . <input checked="" type="checkbox"/> = Sending code 4 to the module via SMS mimics the operation of the 'Stop' button and is used to provide a remote SMS stop command.
Auto Mode (Code 5)	<input type="checkbox"/> = Sending code 5 to the module via SMS does not issue place the unit into its <i>Auto Mode</i> . <input checked="" type="checkbox"/> = Sending code 5 to the module via SMS mimics the operation of the Auto button.

2.10.2.4 TROUBLESHOOTING MODEM COMMUNICATIONS

 **NOTE:** Connecting a modem directly to the module's RS232 for is legacy support only. When a new installation requires remote communication using the cellular network, refer to DSE products DSE890, DSE891 and DSEWebNet on the DSE website: www.deepseaelectronics.com.

2.10.2.4.1 MODEM COMMUNICATION SPEED SETTING

First ensure the modem is set to communication with the DSE module at 9600 baud – Modems supplied by DSE are factory adjusted to operate with the DSE module. Only modems purchased from a third party may require adjustment.

To change the modems RS232 baud rate you need a command line terminal program (HyperTerminal by Microsoft is a workable solution). Operation of this terminal program is not supported by DSE; contact your terminal program supplier.

Connect the modem RS232 port to your PCs RS232 port. You may need an additional card in your PC to provide this facility.

Use HyperTerminal (or similar) to connect to the modem at its current baud rate. You may need to contact your modem supplier to obtain this detail. If this is not possible, use 'trial and error' methods. Select a baud rate, attempt connection, press <ENTER> a few times. If the modem responds with **OK>** then you are connected at the correct baud rate. Any other response (including nothing) means you are not connected so select another baud rate.

When connected, enter the following command:

AT+IPR=9600 and press <ENTER>
This sets the modem to 9600 baud.

Close the HyperTerminal connection (**do not** remove power from the modem) then open a new connection to the modem at 9600 baud.

Enter the following command:

AT&W and press <ENTER>

This saves the new setting in the modem. Power is now removed. The next time power is applied, the modem starts with the new settings (Baud rate = 9600), suitable to communicate with the DSE module.

2.10.2.4.2 GSM MODEM CONNECTION

Most GSM modems have a *Status* LED. The Wavecom Fastrack Supreme as recommended and previously supplied by DSE has a RED Status LED, operating as follows.

LED State	Description
Off	Modem is not powered
On Continuous	Not connected to GSM network
Flashing Slow (approximately once every two seconds)	Connected to GSM network
Flashing Fast (approximately twice per second)	Connected to GSM network data transmission in progress

2.10.3 RS485 PORT

RS485 Port 1


Basic

Server ID	▲	10	▼	
Baud Rate		115200	▼	
Port Usage		Modbus Server ▼		

Parameter	Description
Server ID	Select the server ID of the DSE module's RS485 port. Every device on the RS485 link must have an individual server ID.
Baud Rate	Select the Baud Rate (speed of communication) of the DSE module's RS485 port. Every device on the RS485 link must have the same Baud Rate. 1200 2400 4800 9600 14400 19200 28800 38400 57600 115200


Advanced

Advanced

Client inactivity timeout 5s 

Parameter	Description
Client Inactivity Timeout	Set the time delay between a MODBUS RTU request and the receipt of a response. The module monitors by default the USB port for communications. When activity is detected on the RS485 port, the module monitors the port for further data. If no data activity is detected on the port for the duration of the client <i>Inactivity Timer</i> , it reverts to looking at the USB port. This needs to be set longer than the time between MODBUS polls from the client.

Modbus



Parameter	Description
Inter-frame Delay	Set the time delay between the DSE module receiving a MODBUS RTU request and the DSE module's response.
Stop Bits	Select the <i>Stop Bits</i> of the RS485 network as required by the MODBUS client device or software. Options are: 1 2
Parity checking	<div style="border: 1px solid black; padding: 5px;"> <p>▲ NOTE: Selecting the <i>Parity</i> is only possible if the <i>Stop Bit</i> is set to 1.</p> </div> <p>Select the required Parity to match the RS485 network as required by the MODBUS client device or software. Options are: <i>Even Parity</i> <i>No Parity</i> <i>Odd Parity</i></p>

2.10.4 REMOTE DISPLAY

NOTE: This feature allows the module to be connected to one DSE25xx MKII remote display module. For further details on the DSE2510 MKII or DSE2520 MKII module operation and configuration, refer to DSE Publication: 057-278 DSE2510 MKII & DSE2520 MKII Operators Manual, and 057-279 DSE2510 MKII & DSE2520MKII Software Manual.

NOTE: DSE25xx MKII and DSE25xx modules cannot be used at the same time. Enabling the DSE25xx MKII through the *Remote Display* in the configuration disables the *2510/2520 Display Module* in the Expansion section. And enabling the *2510/2520 Display Module* in the Expansion section causes the DSE25xx MKII's Remote Display section to be greyed out.

NOTE: DSE25xx expansion modules are only supported on certain software versions of the module, for more details refer to section entitled *2510/2520 Display Module* section elsewhere in this document.

Function	Description
Display Enable	<input type="checkbox"/> = The Remote Display is disabled. <input checked="" type="checkbox"/> = This feature allows the module to be connected to one DSE25xx MKII remote display module.
Link Lost Alarm Action	Select the action for the <i>Link Lost Alarm</i> . Electrical Trip Shutdown Warning This alarm acts if the remote display DSE25xx MKII module is not detected by the host module.
Connection Port	<p>NOTE: The selected port's Baud Rate is fixed to 115200, the relevant port's server ID is configured in the Communications section.</p> <p>Select the port to be used for the Remote Display.</p>

2.10.5 ETHERNET PORT

NOTE: Consult the network administrator of the host network before changing these settings. Incorrect settings cause network errors in the existing local area network. These settings must only be changed by qualified network administrators.

Dynamic Host Configuration Protocol

Dynamic Host Configuration Protocol

Obtain IP Address Automatically

Parameter	Description
Obtain IP Address Automatically	<input type="checkbox"/> = The Dynamic Host Configuration Protocol (DHCP) is disabled and the unit has a fixed IP address as configured in the <i>IP Address</i> section. <input checked="" type="checkbox"/> = The Dynamic Host Configuration Protocol (DHCP) is enabled, and the unit automatically attains an IP address from the network it is connected to if it has DHCP enabled.

Names

Names

Domain Name	DSE Module
Host Name	Company
Vendor Name	Deep Sea Electronics

Parameter	Description
Domain Name	The hostname of the device which is used for DHCP requests and acknowledgements. Consult the network IT manager for suitable naming
Host Name	Additional description string for DHCP
Vendor Name	Additional description string for DHCP

IP Address

IP Addresses				
IP address	192	168	1	100
Subnet Mask	255	255	255	0
Gateway Address	0	0	0	0
DNS Address	0	0	0	0
Preferred Connection Address	0	0	0	0

Parameter	Description
IP Address	The static IP address of the module.
Subnet Mask	The subnet mask is to determine whether the module is on the local subnet or on a remote network.
Gateway Address	IP address of the internet router that module is connected to.
DNS Address	IP address of the Domain Name Service (DNS). Usually this is the same as the module's IP address.
Preferred Connection Address	The module allows up to five MODBUS clients to connect to it. The <i>Preferred Connection Address</i> enables the unit to reserve one of the five connections for a specific IP address, such as for a remote display module to ensure it always connects.

MODBUS

Modbus	
Modbus Port Number	502

Parameter	Description
MODBUS Port Number	The port number which the module serves MODBUS traffic on.

Firewall configuration for internet access

As modem/routers differ enormously in their configuration, it is not possible for DSE to give a complete guide to their use with the DSE module. However it is possible to give a description of the requirements in generic terms. For details of how to achieve the connection to your modem/router you are referred to the supplier of your modem/router equipment.

The DSE module makes its data available to a configurable TCP port number. You must configure your modem/router to allow inbound traffic on this port. For more information you are referred to your WAN interface device (modem/router) manufacturer.

Incoming traffic (virtual server)

Network Address and Port Translation (NAPT) allows a single device, such as the modem/router gateway, to act as an agent between the Internet (or "public external network") and a local (or "internal private") network. This means that only a single, unique IP address is required to represent an entire group of computers.

For our DSE module application, this means that the WAN IP address of the modem/router is the IP address we need to access the site from an external (internet) location.

When requests reach the modem/router, we want this passed to a 'virtual server' for handling, in our case this is the DSE module.

Example:

Virtual Servers		
Filter Name	Source Port	Destination (LAN) Address
DSE74xx MKII	1003	192.168.1.45

User provided name for the Port Forwarding rule.

Port number of the communications (must match the configuration of the DSE controller).


IP Address of the DSE controller connected to the LAN.

Result : Traffic arriving from the WAN (internet) on port 1003 is automatically sent to IP address 192.168.1.45 on the LAN (DSE module) for handling.

2.10.5.1 EMBEDDED WEB BROWSER

NOTE: For more details on the WebScada Interface, please refer to DSE Publication: 057-263 DSE7410 MKII & DSE7420 MKII Operator Manual.

NOTE: The module's default factory setting configuration does not include the WebScada. When the WebScada is enabled in the configuration, it takes a number of minutes to transfer the graphics and all necessary files to the module over a USB connection during a configuration write procedure.



This feature provides a Web SCADA Interface to the module to monitor its instruments, mimic control, and access to its Ethernet & SNMP configuration over a supported web browser using its IP address when enabled. The Web SCADA Interface allows the user to monitor all the module's instruments and mimic its control buttons, similar to the DSE Configuration Suite's Scada.

Parameter	Description
Embedded Web Server	<input type="checkbox"/> = The module's Web Server is disabled. <input checked="" type="checkbox"/> = The module's WebScada is enabled, and the user is able to connect to it using a supported web browser.
Port	The port number that the module's WebScada pages are served on. Care must be taken with this setting when connecting to an existing network in case other devices are already using port 80 to serve webpages.

NOTE: The same port has to be configured on the modules if the router has port forwarding rules and it sends the same port number to all its connected devices.

2.10.5.1.1 WEBSCAD A PORT

A Web Browser always uses port 80 as its default port number, hence there is no need to indicate this port number in the Web Browser if the module's *Port* was configured 80, however if the *Port* was different than 80 then this must be provided in the Web Browser's URL.

The module's IP address is 192.168.1.100 and its WebScada Port is 8080.
 Type in the Web Browser's URL field: <http://192.168.1.100:8080>

The module's IP address is 192.168.1.100 and its WebScada Port is 80.
 Type in the Web Browser's URL field: <http://192.168.1.100>
 The port number is not visible here as it is 80 and there is no need to indicate it in the Web Browser.

When both the PC Web Browser and the module are connected to a router, both have different (fixed) LAN IP addresses as well as the router. There are port forwarding rules in the router when trying to access the module's WebScada on a PC Web Browser, to send all port 80 traffic that comes in to the routers fixed WAN IP address to the PC Web Browser. Another port forwarding rule is needed in the router to access the module's WebScada by the same fixed WAN IP address, however port 80 is already diverted to the PC Web Browser, therefore setting the module's Port to a different number (8080 for example) and add a new rule in the router to forward 8080 traffic to the module, then the module's WebScada is accessed using <http://aaa.bbb.ccc.ddd:8080> from the PC Web Browser, where the aaa.bbb.ccc.ddd is the router's fixed WAN IP address.

2.10.6 CAN PORTS

CAN Ports


CAN Port 2

Baud Rate

Parameter	Description
CAN Port 2 Baud Rate	Baud rate adjustable from 10000-1000000

2.10.7 SNMP

The section is subdivided into smaller sections.
Select the required section with the mouse.



2.10.7.1 SNMP SETTINGS

NOTE: The MIB file is available to download from the DSE Website. This generic MIB file is conformed to SNMPV2c standards.

The module supports SNMPv2c with GetRequest, SetRequest, GetNextRequest, GetBulkRequest and Response. The module allows two SNMP managers at a time on different addresses.

A fixed **MIB file** is available for the module for use by external SNMP managers. The MIB file is a file used by the SNMP manager to give context to the information held within the module (SNMP Agent).

A screenshot of the 'SNMP Settings' configuration form. The form has a light blue background and a title bar. It contains several fields and checkboxes:


- Enable:** A checkbox that is checked.
- Include Device Name (SysName OID) in Trap Messages:** A checkbox that is unchecked.
- Device Name:** A text input field.
- Manager 1 Address:** A text input field.
- Manager 2 Address:** A text input field.
- Manager Port:** A dropdown menu with '161' selected.
- Notification Port:** A dropdown menu with '162' selected.
- Read Community String:** A text input field with 'public' entered.
- Write Community String:** A text input field with 'private' entered.

Parameters detailed overleaf...

Parameter	Description
SNMP Enable	<input type="checkbox"/> = SNMP is disabled <input checked="" type="checkbox"/> = SNMP is enabled, and the module communicates with the SMTP server through its Ethernet port.
Include Device Name (SysName OID) in Trap Messages	<input type="checkbox"/> = <i>Device Name</i> is not sent as part of the TRAP message to the device manager. <input checked="" type="checkbox"/> = The module sends the <i>Device Name</i> as part of the TRAP message to the SNMP manager.
Device Name	The device name of the module (for SNMP only).
Manager 1 Address	The IPV4 Network location of the SNMP manager 1.
Manager 2 Address	The IPV4 Network location of the SNMP manager 2.
Manager Port	The SNMP port used for GET, GET Next, Get Bulk, Get Subtree, Walk and SET messages.
Notification Port	Port Number that SNMP TRAP messages are sent to.
Read Community String	The SNMP <i>Read Community</i> String. (Factory setting <i>public</i>)
Write Community String	The SNMP <i>Write Community</i> String. (Factory setting <i>private</i>)

2.10.7.2 NOTIFICATIONS


The user is able to enable Module and Instrumentation Events to be transmitted to SNMP Trap devices.




Parameter	Description
Named Alarms	<input type="checkbox"/> = No SNMP TRAPs are sent when a <i>Named Alarm</i> activates. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when a <i>Named Alarm</i> activates. A <i>Named Alarm</i> is a protection with a pre-set name, e.g. Generator Over Voltage.
Unnamed Alarms	<input type="checkbox"/> = No SNMP TRAPs are sent when an <i>Unnamed Alarm</i> activates. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when an <i>Unnamed Alarm</i> activates. An <i>Unnamed Alarm</i> is a protection with a user configured name, e.g. a digital input configured for <i>User Configured</i> .
Mode Change	<input type="checkbox"/> = No SNMP TRAPs are sent when the module changes operating mode. <input checked="" type="checkbox"/> = An SNMP TRAP is sent to indicate the operating mode has changed and what it has changed to.
Power Up	<input type="checkbox"/> = No SNMP TRAPs are sent when the module powers up. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the module powers up.
Engine Starts	<input type="checkbox"/> = No SNMP TRAPs are sent when the engine starts. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the engine starts.
Engine Stops	<input type="checkbox"/> = No SNMP TRAPs are sent when the engine stops. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the engine stops.
Mains Fail	<input type="checkbox"/> = No SNMP TRAPs are sent when the mains fails. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the mains fails
Mains Return	<input type="checkbox"/> = No SNMP TRAPs are sent when the mains returns. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the mains returns
ECU Lamps	<input type="checkbox"/> = No SNMP TRAPs are sent when the electronic engine generates an alarm. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when the electronic engine generates an alarm or indicates an action.
Fuel Level Monitoring	<input type="checkbox"/> = No SNMP TRAPs are sent when a <i>Fuel Level Monitoring</i> event is logged within the module's event log. <input checked="" type="checkbox"/> = An SNMP TRAP is sent when a <i>Fuel Level Monitoring</i> event is logged within the module's event log.

2.11 SCHEDULER

The section is subdivided into smaller sections.



2.11.1 SCHEDULER OPTIONS



Function	Description
Enable Exercise Scheduler	<input type="checkbox"/> = The scheduler is disabled. <input checked="" type="checkbox"/> = The scheduler is enabled, Bank 1 and Bank 2 become editable.

2.11.2 BANK 1 / BANK 2

Each Bank of the Exercise Scheduler is used to give up to 8 scheduled runs per bank, 16 in total. This run schedule is configurable to repeat every 7 days (weekly) or every 28 days (monthly). The run is *On Load*, *Off Load* or *Auto Start Inhibit*.

Each scheduler bank configured differently either to weekly or monthly based exercises.

Function	Description
Schedule Period	Determines the repeat interval for the scheduled run. Options available are: Weekly: The schedule events occur every week. Monthly: The schedule events occur every month on the week selected.
Week	Specifies the week of the month, on which the scheduled run takes place
Day	Specifies the day of week, on which the scheduled run takes place
Run Mode	Determines the loading state mode of the generator when running on schedule Auto Start Inhibit: The generator is prevented from running in <i>Auto</i> mode. Off Load: The module runs the generator on schedule with the load switch open On Load: The module runs the generator on schedule and closes the load switch
Start Time	Determines at what time of day the scheduled run starts
Duration	Determines the time duration in hours for the scheduled run
Clear	Resets the values for the Day, Start Time, and Duration to defaults

2.12 MAINTENANCE ALARM

Maintenance Alarm 1

Enable

Description Maintenance Alarm

Action Warning

Engine Run Hours 10 hrs

Enable Alarm On Due Date

Maintenance Interval 1 months

There are two ways to reset the maintenance alarm:


- 1) Activate a digital input configured to "Maintenance Reset Alarm".
- 2) Use the SCADA | Maintenance | Maintenance Alarm section of this PC Software.
- 3) Through the Front Panel Editor of the module

Maintenance Alarm 1 to 3

Function	Description
Enable	<input type="checkbox"/> = The maintenance alarm is disabled. <input checked="" type="checkbox"/> = The maintenance alarm is activated with the configured <i>Action</i> when the engine hours increases more than the <i>Engine Run Hours</i> or when the date increase more than the <i>Maintenance Interval</i> settings.
Description	The text that is displayed on the module's LCD when the maintenance alarm activates.
Action	<div style="border: 2px solid black; padding: 5px;"> <p>NOTE: For details of these, see the section entitled Alarm Types elsewhere in this document.</p> </div> <p>Select the type of alarm required from the list: Electrical Trip Shutdown Warning</p>
Engine Run Hours	The value the engine hours must increase by to trigger the maintenance alarm.
Enable Alarm on Due Date	<input type="checkbox"/> = The maintenance alarm only activates on the engine hours increasing <input checked="" type="checkbox"/> = The maintenance alarm activates on the engine hours increasing or the date increasing, whichever occurs first.
Maintenance Interval	The value the date must increase by to trigger the maintenance alarm.

2.13 CONFIGURABLE CAN INSTRUMENTATION

The *Configurable CAN Instrumentation* section is subdivided into smaller sections. Select the required section with the mouse.



2.13.1 RECEIVED INSTRUMENTATION (1-30)

This feature allows for up to ten custom engine CAN instrumentation items to be decoded from CAN messages on the connected ECU or CAN port.

Received Instrumentation																		
Instrumentation Configuration																		
Enabled	Module	CAN Port	Message ID	Bits	CAN ID	Enable	Timeout (ms)	Byte	Bit	Length	Signed	D. Places	Suffix	Smallest	Largest	Smallest	Largest	Fn
<input checked="" type="checkbox"/>	CAN	ECU	Configurable CAN 1	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input checked="" type="checkbox"/>	CAN	ECU	Configurable CAN 2	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input checked="" type="checkbox"/>	0		-1	0	0	100	Fn
<input checked="" type="checkbox"/>	CAN	ECU	Configurable CAN 3	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input checked="" type="checkbox"/>	0		-1	0	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 4	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 5	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 6	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 7	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 8	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 9	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 10	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 11	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 12	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 13	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 14	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 15	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 16	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 17	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 18	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn
<input type="checkbox"/>	CAN	ECU	Configurable CAN 19	29	0x0	<input checked="" type="checkbox"/>	5000	1	0	1	<input type="checkbox"/>	0		0	1	0	100	Fn


Export/Import

This feature is used to import/export the *Configurable CAN Instrumentation* settings.

Parameter	Description
Export	This allows to export the configuration settings of the CAN Received Instrumentation or Transmitted Instrumentation into *.canrx file.
Import	This allows to import an existing configuration settings of the Legacy CAN Export File (*.xml) or Transmitted (*.canrx) file.

2.13.1.1 INSTRUMENT CONFIGURATION

Module

Parameter	Description
Enabled	<p> NOTE: The CAN instrumentation must already be available on the CANbus. There is no request for a non-standard instrumentation.</p> <p><input type="checkbox"/> = The CAN instrumentation is disabled. <input checked="" type="checkbox"/> = The CAN instrumentation is enabled. Reading depends upon the message availability on the bus.</p>
View	<p>The options are as follows:</p> <p>CAN: The value is shown under CAN page on the module display screen. Disabled: The value is not shown on the module display screen. Engine: The value is shown under Engine page on the module display screen.</p>

Message ID

Parameter	Description
Description	Provide a description for the CAN instrumentation. This description is shown in the Scada, and module display screen.
Bits	<p>The options are:</p> <p>29: A 29 bit identifier (extended format) allows a total of 229 (= 536+ million) messages. 11: An 11 bit identifier (standard format) allows a total of 211 (= 2048) different messages.</p>
CAN ID	<p>29-bit CAN Message Identifier to receive. CAN ID must match exactly the full ID of the message to be received in the standard J1939 29-bit (Extended) format.</p>

Timeout

Parameter	Description
Enable	<p><input type="checkbox"/> = Timeout is disabled <input checked="" type="checkbox"/> = Timeout is enabled</p>
(ms)	It indicates how often the messages are expected to be seen on the CANbus in milliseconds. If no new instrumentation is seen beyond the timeout period, the calculated instrumentation value changes to a 'bad data' sentinel value.

Data Structure


Parameter	Description
Byte	Set the start position Byte
Bit	Set the start position Bit
Length (Bits)	Data length 1-32 bits
Signed	<p><input type="checkbox"/> = Unsigned value <input checked="" type="checkbox"/> = Signed value</p>

Display

NOTE: If the received CAN instrument is outside the configured raw values, the module displays sentinel value.

Parameter	Description
Decimal Places	Display the decimal point. 0 represents 0 scaling factor, 1 represents 0.1 scaling factor, -1 represents 10 multiplier.
Suffix	Unit display (example: m ³ /hr)

Bus Value

Parameter	Description																								
Smallest	This is the smallest value (up to the Largest Bus Value setting) which can be sent over the CANbus.																								
Largest	<p>This is the largest value (up to the maximum <i>Data Structure-Length</i> setting) which can be sent over the CANbus.</p> <p>For Example:</p> <p>If the un-signed <i>Data Structure- Length</i> value is 4 then the <i>Largest Bus Value</i> will be 15.</p> <div style="text-align: center;">  <table border="1" style="margin: 0 auto;"> <thead> <tr> <th colspan="4">Data Structure</th> <th colspan="2">Display</th> <th colspan="2">Bus Value</th> </tr> <tr> <th>Byte</th> <th>Bit</th> <th>Length</th> <th>Signed</th> <th>D. Places</th> <th>Suffix</th> <th>Smallest</th> <th>Largest</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>0</td> <td>4</td> <td><input type="checkbox"/></td> <td>0</td> <td></td> <td>0</td> <td>15</td> </tr> </tbody> </table> </div>	Data Structure				Display		Bus Value		Byte	Bit	Length	Signed	D. Places	Suffix	Smallest	Largest	1	0	4	<input type="checkbox"/>	0		0	15
Data Structure				Display		Bus Value																			
Byte	Bit	Length	Signed	D. Places	Suffix	Smallest	Largest																		
1	0	4	<input type="checkbox"/>	0		0	15																		

Mapped Value

Parameter	Description
Mapped Value Smallest	Details how the Displayed Values relate to the received <i>Bus Values</i> . For example: <i>Bus Value</i> 10 to 100
Mapped Value Largest	<i>Mapped Value</i> 20 to 200. This configures the device to display 20 when the value 10 is received and to display 200 when the value 100 is received. Values in between are linearly interpolated.

Test

Test


Test Value

Output Value 0

Parameter	Description
Test Raw Value	<p>▲ NOTE: The Test Raw Value is not saved in the configuration, this is only to check the displayed value.</p> <p>This is a test case to check the representation of the <i>Raw Value</i> when they are complicated. <i>Test Raw Value</i> is the value read from the CANbus before the transformation</p>
Displayed Value	The <i>Test Raw Values'</i> represented value as to be shown on the module's screen, or in the Scada.

Function

The Function is only available for the Received Instrumentation (1-10), it allows to configure a User Configured alarm by monitoring the relevant *Configurable CAN Instrumentation*.



Parameter	Description
Function	<p>Select a digital input function to activate according to the CAN value received.</p> <p>NOTE: Refer to the <i>Digital Inputs</i> section elsewhere in this document for the list of descriptions of the functions list.</p> <p>NOTE: <i>Crank Disconnect</i> function has been added in this list to instruct the DSE74xx MKII module to crank disconnect when the value sent over the CAN line is under or over the configured Trip level.</p>
Action	<p>NOTE: <i>Action</i> is only adjustable when <i>Function</i> is set to <i>User Configured</i>.</p> <p>Select the type of alarm to activate the <i>Function</i> after the <i>Activation Delay</i> time.</p> <p>Electrical Trip Indication Shutdown Warning</p>
Arming	<p>NOTE: <i>Arming</i> is only adjustable when <i>Function</i> is set to <i>User Configured</i>.</p> <p>Select when the <i>Trip</i> level is monitored. Options are as follows: Always: The protection is always active on the controller. This is used to constantly monitor status of the <i>CAN Instrumentation</i>. From Safety On: Active only after the <i>Safety On</i> delay timer When Stationary: Active only when the engine is not running</p>
Activation Delay	<p>The amount of time before the module activates the selected <i>Function</i> upon the <i>Configurable CAN Instrumentation</i> reaching the <i>Trip</i> level.</p>

Parameters are continued overleaf...

Parameter	Description
Type	Select the required option to monitor the <i>Configurable CAN Instrumentation</i> when to trip. Over: The <i>Function</i> is active when the <i>Configurable CAN Instrumentation</i> raises above the Trip level for longer than the <i>Activation Delay</i> timer. Under: The <i>Function</i> is active when the <i>Configurable CAN Instrumentation</i> lowers below the Trip level for longer than the <i>Activation Delay</i> timer.
Return	The <i>Function</i> is removed when the <i>Configurable CAN Instrumentation</i> value rises above the <i>Return</i> level if <i>Type</i> is <i>Under</i> . The <i>Function</i> is removed when the <i>Configurable CAN Instrumentation</i> value is reduced below the <i>Return</i> level if <i>Type</i> is <i>Over</i> .

2.13.2 TRANSMITTED INSTRUMENTATION

The module allows transmitting up to 10 instruments over the CANbus on the ECU port by specifying the source address (message ID) of the selected Instrument.

Transmitted Instrumentation

Instrumentation Configuration

Enabled	Message ID				Data Structure				Source Value			Bus Value	
	CAN Port	Bits	CAN ID	Rate (ms)	Byte	Bit	Length	Signed	Source	Smallest	Largest	Smallest	Largest
<input checked="" type="checkbox"/>	ECU	29	0x0	100	1	0	1	<input type="checkbox"/>	<Not Used>	0	100	0	1
<input checked="" type="checkbox"/>	ECU	29	0x0	100	1	0	1	<input type="checkbox"/>	<Not Used>	0	100	0	1
<input checked="" type="checkbox"/>	ECU	29	0x0	100	1	0	1	<input type="checkbox"/>	<Not Used>	0	100	0	1
<input type="checkbox"/>	ECU	29	0x0	100	1	0	1	<input type="checkbox"/>	<Not Used>	0	100	0	1
<input type="checkbox"/>	ECU	29	0x0	100	1	0	1	<input type="checkbox"/>	<Not Used>	0	100	0	1
<input type="checkbox"/>	ECU	29	0x0	100	1	0	1	<input type="checkbox"/>	<Not Used>	0	100	0	1
<input type="checkbox"/>	ECU	29	0x0	100	1	0	1	<input type="checkbox"/>	<Not Used>	0	100	0	1
<input type="checkbox"/>	ECU	29	0x0	100	1	0	1	<input type="checkbox"/>	<Not Used>	0	100	0	1
<input type="checkbox"/>	ECU	29	0x0	100	1	0	1	<input type="checkbox"/>	<Not Used>	0	100	0	1

Export/Import

This feature is used to import/export the *Configurable CAN Instrumentation* settings.

Parameter	Description
Export	This allows to export the configuration settings of the CAN Received Instrumentation or Transmitted Instrumentation into *.cantx file.
Import	This allows to import an existing configuration settings of the Legacy CAN Export File (*.xml) or Transmitted (*.cantx) file.

2.13.2.1 INSTRUMENT CONFIGURATION

Message ID

Parameter	Description
Enabled	<input type="checkbox"/> = The Transmit CAN instrumentation is disabled. <input checked="" type="checkbox"/> = The Transmit CAN instrumentation is enabled.
CAN Port	The options are: ECU: CAN:
Bits	The options are: 29: A 29 bit identifier (extended format) allows a total of 229 (= 536+ million) messages. 11: An 11 bit identifier (standard format) allows a total of 211 (= 2048) different messages.
CAN ID	29-bit CAN Message Identifier to transmit. <i>CAN ID</i> must match exactly the full ID of the message to be received in the standard J1939 29-bit (Extended) format.
Rate (ms)	The rate at which the <i>CAN Instrument</i> is transmitted over the CANbus.

Data Structure

Parameter	Description
Offset Byte	Set the start position Byte
Offset Bit	Set the start position Bit
Length (Bits)	Data length 1-32 bits
Signed Value	<input type="checkbox"/> = Transmit unsigned value <input checked="" type="checkbox"/> = Transmit signed value

Source Value

Parameter	Description
Source	Select the source of the data to be transmitted over the CANbus. Alarms Control Instrumentation Status See section entitled Output Sources for details of all available functions
Smallest Source Value	The smallest instrument value before being sent over the CANbus.
Largest Source Value	The largest instrument value before being sent over the CANbus.

Bus Value

Parameter	Description
Smallest	The smallest data sent over the CANbus before the transformations (decimal places).
Largest	The largest data sent over the CANbus before the transformations (decimal places).

Test

Test

Test Value

Output Value 0


Parameter	Description
Test Raw Value	<p>▲ NOTE: The Test Raw Value is not saved in the configuration, this is only to check the displayed value.</p> <p>This is a test case to check the representation of the <i>Raw Value</i> when they are complicated. <i>Test Raw Value</i> is the value read from the CANbus before the transformation</p>
Displayed Value	The <i>Test Raw Values</i> ' represented value as to be shown on the module's screen, or in the Scada.

2.14 ALTERNATIVE CONFIGURATIONS


An Alternative Configuration is provided to allow the system designer to cater for different AC requirements utilising the same generator system. Typically this feature is used by Rental Set Manufacturers where the set is capable of being operated at (for instance) 120V 50Hz and 240V 50Hz using a selector switch.

The Alternative Configuration is selected using either:

- Configuration Suite Software (Selection for 'Default Configuration')
- Module Front Panel Editor
- Via external signal to the module input configured to "Alternative Configuration" select.




2.14.1 ALTERNATIVE CONFIGURATION OPTIONS



Parameter	Description
Default Configuration	Select the 'default' configuration that is used when there is no instruction to use an 'alternative configuration.'
Main Configuration Name	Free entry box to allow the user to give the Main Configuration name. This is shown on the module's display when the configuration is selected.


2.14.2 ALTERNATIVE CONFIGURATION 1 TO 5

The Alternative Configurations Editor allows for editing of the parameters that are to be changed when an Alternative Configuration is selected.



2.14.2.1 CONFIGURATION OPTIONS


Enable Alternative Configuration



Parameter	Description
Enable Configuration	<input type="checkbox"/> = <i>Alternative Configuration</i> is disabled. <input checked="" type="checkbox"/> = <i>Alternative Configuration</i> is enabled. The configuration is enabled by changing the <i>Default Configuration</i> , activating a digital input or through the module's <i>Front Panel Editor</i> .

2.14.2.2 GENERATOR / MAINS / ENGINE


Alternative configuration options contain a subset of the main configuration. The adjustable parameters are not discussed here as they are identical to the main configuration options:



Configuration menus for the *Alternative Configuration*. For information about the configuration items within this section, refer to their description in the 'main' configuration.

2.15 EXPANSION


The *Expansion* page is subdivided into smaller sections. Select the required section with the mouse.



See overleaf for description of the different expansion modules.


2.15.1 2130 INPUT MODULES

Select the DSENet ID of the input expansion to be configured. The ID of the expansion module is set by rotary decimal switch accessible under the removable cover of the device.



The following options are then shown:


2130 Expansion Enable



Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

2130 Expansion Inputs

The *Expansion Unit* page is then subdivided into smaller sections. Select the required section with the mouse.



2.15.1.1 ANALOGUE INPUT CONFIGURATION

The screenshot shows a window titled "Input Configuration" with four rows of settings:

Analogue Input E	Flexible Analogue
Analogue Input F	Not Used
Analogue Input G	Digital Input
Analogue Input H	Flexible Analogue

Input Configuration

Parameter	Description
Analogue Input E to H	Select what the analogue input is to be used for: Not Used: The analogue input is disabled Digital Input: Configured on the 2130/Digital Inputs pages Flexible Analogue: Configured on the 2130/Analogue Inputs pages

2.15.1.2 ANALOGUE INPUTS

NOTE: An analogue input is only configurable as a flexible sensor if it has been configured as Flexible Analogue, refer to section entitled Analogue Input Configuration elsewhere in this document for further details.

Sensor Description

The screenshot shows a window titled "Sensor Description" with a text input field for "Sensor Name" containing the text "2130 ID0 Flexible Sensor E".

Parameter	Description
Sensor Name	Enter the <i>Sensor Name</i> , this text is shown on the module display when viewing the instrument.

Input Type

The screenshot shows a window titled "Input Type" with a dropdown menu set to "VDO Ohm range (10-180)" and an "Edit..." button.


Parameter	Description
Input Type	Select the sensor type and curve from a pre-defined list or create a user-defined curve. Available sensor types: Resistive: for sensors with maximum range of 0 Ω to 480 Ω Available parameters to be measured: Pressure: The input is configured as a pressure sensor Percentage: The input is configured as a percentage sensor Temperature: The input is configured as a temperature sensor

Parameter descriptions are continued overleaf...

Sensor Alarms


Parameter	Description
Alarm Arming	<p>NOTE: For details of these, see the section entitled Alarm Arming elsewhere in this document.</p> <p>Select when the alarm generated by the analogue input becomes active: Always From Safety On From Starting</p>
Low Alarm Enable	<p><input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Alarm</i> activates when the measured quantity drops below the <i>Low Alarm</i> setting.</p>
Low Alarm Action	<p>NOTE: For details of these, see the section entitled Alarm Types elsewhere in this document.</p> <p>Select the type of alarm required from the list: Electrical Trip Shutdown</p>
Low Pre-Alarm Enable	<p><input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Pre-Alarm</i> is active when the measured quantity drops below the <i>Low Pre-Alarm Trip</i> setting. The <i>Low Pre-Alarm</i> is automatically reset when the measured quantity rises above the configured <i>Low Pre-Alarm Return</i> level.</p>
Low Alarm String	<p>The text that is displayed on the module's LCD when the <i>Low Alarm</i> or <i>Low Pre-Alarm</i> activates.</p>

Parameter descriptions are continued overleaf...


Parameter	Description
High Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Pre-Alarm</i> is active when the measured quantity rises above the <i>High Pre-Alarm Trip</i> setting. The <i>High Pre-Alarm</i> is automatically reset when the measured quantity falls below the configured <i>High Pre-Alarm Return</i> level.
High Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Alarm</i> is active when the measured quantity rises above the <i>High Alarm</i> setting.
High Alarm Action	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. </div> <p>Select the type of alarm required from the list: <i>Electrical Trip</i> <i>Shutdown</i></p>
High Alarm String	The text that is displayed on the module's LCD when the <i>High Alarm</i> or <i>High Pre-Alarm</i> activates.

2.15.1.3 DIGITAL INPUTS

The *Digital Inputs* section is subdivided into smaller sections. Select the required section with the mouse.



2.15.1.3.1 DIGITAL INPUTS



Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	<p>⚠ NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p> <p>Select the type of alarm required from the list: Electrical Trip Indication Shutdown Warning</p>
Arming	<p>⚠ NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document.</p> <p>Select when the input becomes active: Active from Mains Parallel Always From Safety On From Starting Never</p>
LCD Display	The text that is displayed on the module's LCD when the input activates and generates an alarm.
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.

2.15.1.3.2 ANALOGUE INPUTS

NOTE: An analogue input is only configurable as a digital input if it has been configured as Digital Input, refer to section entitled Analogue Input Configuration elsewhere in this document for further details.

Analogue Inputs E - H

Analogue Input E (Digital)

Function	User Configured
Polarity	Close to Activate
Action	Warning
Arming	Always
LCD Display	2130 ID0 Analogue E (Digital)
Activation Delay 0s	<input type="range"/>

Analogue Input F (Digital)

The Analogue Input is not configured as a Digital Input
To reconfigure, use the 'Analogue Input Configuration' page

Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	<div style="border: 3px double black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p> </div> <p>Select the type of alarm required from the list: Electrical Trip Indication Shutdown Warning</p>
Arming	<div style="border: 3px double black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document.</p> </div> <p>Select when the input becomes active: Active from Mains Parallel Always From Safety On From Starting Never</p>
LCD Display	The text that is displayed on the module's LCD when the input activates and generates an alarm.
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.


2.15.2 DSE2131 INPUT MODULES

Select the DSENet ID of the input expansion to be configured. The ID of the expansion module is set by rotary decimal switch accessible under the removable cover of the device.



The following options are then shown:


2131 Expansion Enable



Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

2131 Expansion Inputs

The *Expansion Unit* page is then subdivided into smaller sections. Select the required section with the mouse.



2.15.2.1 ANALOGUE INPUT CONFIGURATION

Input Configuration

Analogue Input A	Flexible Analogue ▾
Analogue Input B	Flexible Analogue ▾
Analogue Input C	Not Used ▾
Analogue Input D	Flexible Analogue ▾
Analogue Input E	Digital Input ▾
Analogue Input F	Digital Input ▾
Analogue Input G	Digital Input ▾
Analogue Input H	Flexible Analogue ▾
Analogue Input I	Digital Input ▾
Analogue Input J	Not Used ▾

Input Configuration

Parameter	Description
Analogue Input A to J	Select what the analogue input is to be used for: Not Used: The analogue input is disabled Digital Input: Configured on the <i>2131/Digital Inputs</i> pages Flexible Analogue: Configured on the <i>2131/Analogue Inputs</i> pages

2.15.2.2 ANALOGUE INPUTS

NOTE: An analogue input is only configurable as a flexible sensor if it has been configured as Flexible Analogue, refer to section entitled Analogue Input Configuration elsewhere in this document for further details.

Sensor Description

Sensor Description

Sensor Name

Parameter	Description
Sensor Name	Enter the <i>Sensor Name</i> , this text is shown on the module display when viewing the instrument.

Input Type

Input Type

VDO Ohm range (10-180)


Parameter	Description
Input Type	<p>Select the sensor type and curve from a pre-defined list or create a user-defined curve.</p> <p>Available sensor types: Current: for sensors with maximum range of 0 mA to 20 mA Resistive: for sensors with maximum range of 0 Ω to 1920 Ω Voltage: for sensors with maximum range of 0 V to 10 V</p> <p>Available parameters to be measured: Pressure: The input is configured as a pressure sensor Percentage: The input is configured as a percentage sensor Temperature: The input is configured as a temperature sensor</p>

Parameter descriptions are continued overleaf...

Sensor Alarms

Parameter	Description
Alarm Arming	<p>NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document.</p> <p>Select when the alarm generated by the analogue input becomes active: Always From Safety On From Starting</p>
Low Alarm Enable	<p><input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Alarm</i> activates when the measured quantity drops below the <i>Low Alarm</i> setting.</p>
Low Alarm Action	<p>NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p> <p>Select the type of alarm required from the list: Electrical Trip Shutdown</p>
Low Pre-Alarm Enable	<p><input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Pre-Alarm</i> is active when the measured quantity drops below the <i>Low Pre-Alarm Trip</i> setting. The <i>Low Pre-Alarm</i> is automatically reset when the measured quantity rises above the configured <i>Low Pre-Alarm Return</i> level.</p>
Low Alarm String	The text that is displayed on the module's LCD when the <i>Low Alarm</i> or <i>Low Pre-Alarm</i> activates.

Parameter descriptions are continued overleaf...

Parameter	Description
High Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Pre-Alarm</i> is active when the measured quantity rises above the <i>High Pre-Alarm Trip</i> setting. The <i>High Pre-Alarm</i> is automatically reset when the measured quantity falls below the configured <i>High Pre-Alarm Return</i> level.
High Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Alarm</i> is active when the measured quantity rises above the <i>High Alarm</i> setting.
High Alarm Action	<div style="border: 3px double black; padding: 5px;">  NOTE: For details of these, see the section entitled Alarm Types elsewhere in this document. </div> <p>Select the type of alarm required from the list: <i>Electrical Trip</i> <i>Shutdown</i></p>
High Alarm String	The text that is displayed on the module's LCD when the <i>High Alarm</i> or <i>High Pre-Alarm</i> activates.

2.15.2.3 DIGITAL INPUTS

NOTE: An analogue input is only configurable as a digital input if it has been configured as Digital Input, refer to section entitled Analogue Input Configuration elsewhere in this document for further details.

Analogue Inputs A - C

Analogue Input A (Digital)

Function	Alarm Mute
Polarity	Close to Activate
Action	
Arming	
LCD Display	2131 ID0 Flexible Sensor A
Activation Delay	0s

Analogue Input B (Digital)



Function	User Configured
Polarity	Close to Activate
Action	Warning
Arming	Always
LCD Display	2131 ID0 Flexible Sensor B
Activation Delay	0s

Analogue Input C (Digital)

The Analogue Input is not configured as a Digital Input
To reconfigure, use the 'Analogue Input Configuration' page


As this example shows a *predefined* function, these parameters are *greyed out* as they are not applicable.

Parameter descriptions are overleaf...

Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input Functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: The input function is activated when the relevant terminal is connected. Open to Activate: The input function is activated when the relevant terminal is disconnected.
Action	<div style="border: 1px solid black; padding: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. </div> Select the type of alarm required from the list: Electrical Trip Indication Shutdown Warning
Arming	<div style="border: 1px solid black; padding: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document. </div> Select when the input becomes active: Active from Mains Parallel Always From Safety On From Starting Never
LCD Display	The text that is displayed on the module's LCD when the input activates and generates an alarm.
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.

2.15.3 DSE2133 INPUT MODULES

Select the DSENet ID of the input expansion to be configured. The ID of the expansion module is set by rotary decimal switch accessible under the removable cover of the device.



The following options are then shown:

2133 Expansion Enable

2133 Expansion Enable

Expansion Enabled

Link Lost Alarm Action Shutdown ▾

Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

2133 Expansion Inputs

The *Expansion Unit* page is then subdivided into smaller sections. Select the required section with the mouse.

2133 Expansion Inputs

[Inputs A - H](#)

2.15.3.1 ANALOGUE INPUTS

NOTE: An analogue input is only configurable as a flexible sensor if it has been configured as Flexible Analogue, refer to section entitled Analogue Input Configuration elsewhere in this document for further details.

Sensor Description

Sensor Description

Sensor Name

Parameter	Description
Sensor Name	Enter the <i>Sensor Name</i> , this text is shown on the module display when viewing the instrument.

Input Type

Input Type


Parameter	Description
Input Type	Select the sensor type from the pre-defined list: 2 Wire PT100 3 Wire PT100 <i>Type J (Thermocouple)</i> <i>Type K (Thermocouple)</i>

Parameter descriptions are continued overleaf...

Sensor Alarms


Parameter	Description
Alarm Arming	<p>NOTE: For details of these, see the section entitled <i>Alarm Arming</i> elsewhere in this document.</p> <p>Select when the alarm generated by the analogue input becomes active: Always From Safety On From Starting</p>
Low Alarm Enable	<p><input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Alarm</i> activates when the measured quantity drops below the <i>Low Alarm</i> setting.</p>
Low Alarm Action	<p>NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.</p> <p>Select the type of alarm required from the list: Electrical Trip Shutdown</p>
Low Pre-Alarm Enable	<p><input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Pre-Alarm</i> is active when the measured quantity drops below the <i>Low Pre-Alarm Trip</i> setting. The <i>Low Pre-Alarm</i> is automatically reset when the measured quantity rises above the configured <i>Low Pre-Alarm Return</i> level.</p>
Low Alarm String	<p>The text that is displayed on the module's LCD when the <i>Low Alarm</i> or <i>Low Pre-Alarm</i> activates.</p>

Parameter descriptions are continued overleaf...

Parameter	Description
High Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Pre-Alarm</i> is active when the measured quantity rises above the <i>High Pre-Alarm Trip</i> setting. The <i>High Pre-Alarm</i> is automatically reset when the measured quantity falls below the configured <i>High Pre-Alarm Return</i> level.
High Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Alarm</i> is active when the measured quantity rises above the <i>High Alarm</i> setting.
High Alarm Action	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">  NOTE: For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document. </div> <p>Select the type of alarm required from the list: <i>Electrical Trip</i> <i>Shutdown</i></p>
High Alarm String	The text that is displayed on the module's LCD when the <i>High Alarm</i> or <i>High Pre-Alarm</i> activates.

2.15.4 DSE2152 OUTPUT MODULES

Select the DSENet ID of the output expansion to be configured. The ID of the expansion input module is set by rotary decimal switch accessible under the removable cover of the device.



The following options are then shown:

2152 Expansion Enable

2152 Expansion Enable

Expansion Enabled

Link Lost Alarm Action Shutdown ▼

Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

2152 Expansion Outputs

The *Expansion Unit* page is then subdivided into smaller sections. Select the required section with the mouse.

2152 Expansion Outputs

[Outputs A - F](#)

2.15.4.1 ANALOGUE OUTPUTS

Analogue Output A

Output Configuration

Output Type

Source	Curve	
Generator Power Total ▾	0kW to 100kW = 0V to 10V ▾	<input type="button" value="Edit..."/>

Output Configuration

Output Configuration

Parameter	Description
Output Name	Enter the <i>Output Name</i> , this text is shown on in the SCADA section when viewing the output.

Output Type

Output Type


Source	Curve	
Generator Power Total ▾	0kW to 100kW = 0V to 10V ▾	<input type="button" value="Edit..."/>

Click to edit the 'output curve'. See section entitled *Editing the Output Curve*.


Parameter	Description
Source	Select the parameter that is to be mapped to the analogue output.
Curve	Select the output type and curve from a pre-defined list or create a user-defined curve Current: for sensors with maximum range of 0 mA to 20 mA Voltage: for sensors with maximum range of 0 V to 10 V

2.15.4.2 CREATING / EDITING THE OUTPUT CURVE

While the *DSE Configuration Suite* holds specifications for the most used output ranges, occasionally it is required that the expansion module's output be connected to a nonstandard device. To aid this process, a curve editor is provided.




When creating a new sensor curve the measurement quantity and measured parameter are required.



Parameter	Description
Y-Axis (Source)	The parameter measured by the DSE module that is to be mapped to the output.
X-Axis (Output)	Select the electrical quantity that the sensor outputs. Current (mA): For an output current within a range 0 mA to 20 mA Voltage (Volt): For an output voltage within a range of 0 V to 10 V

Curve creation / editor descriptions are continued overleaf...



Click *Interpolate* then select two points as prompted to draw a straight line between them.

Click to change the range of the X and Y Axes of the graph and the level of open circuit detection.

Click SAVE AS, a prompt to name the curve...

New Curve Name

Enter a name for the new curve

OK Cancel

Click OK to save the curve.


Any saved curves become selectable in the *Output Type* selection list.

Click OK to accept the changes or CANCEL to ignore and lose the changes

Hint: Deleting, renaming or editing custom curves that have been added is performed in the main menu, select *Tools | Curve Manager*.


2.15.5 DSE2157 RELAY MODULES

Select the DSENet ID of the output expansion to be configured. The ID of the expansion module is set by rotary decimal switch accessible under the removable cover of the device.




The following options are then shown:

2152 Expansion Enable



Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

Relay Outputs (Normally Open / Changeover)




Parameter	Description
Source	Select the output source to control the state of the output. See section entitled <i>Output Sources</i> for details of all available functions
Polarity	Select the digital input polarity: Energise: When the output source is true, the output activates. De-Energise: When the output source is true, the output deactivates.

2.15.6 2510/2520 DISPLAY MODULE

Available on module version 1.1.x, 2.x.x, and V4.x.x.

NOTE: DSE25xx and DSE25xx MKII modules cannot be used at the same time. Enabling the DSE25xx MKII through the *Remote Display* in the configuration disables the *2510/2520 Display Module* in the Expansion section. And enabling the *2510/2520 Display Module* in the Expansion section causes the DSE25xx MKII's *Remote Display* section to be greyed out.

Select the DSENet ID of the Display expansion you wish to configure.



The following is then shown:

DSENet ID 0

2510/2520 Expansion Enable

Expansion Enabled

Link Lost Alarm Action Shutdown

Control Buttons

Control Buttons Enable

Sounder Configuration

Sounder Enable

Follow main unit

Auto Mute Timer Enable

Auto Mute Timer 1m

= The display is for instrumentation only – the mode change buttons are disabled.

= The display acts as a complete mimic/control of the host module.

= If the *mute / lamp test* button is pressed, other DSE2548 modules and the host module will not respond to this.

= If the *mute / lamp test* button is pressed, other DSE2548 modules configured to *Follow main unit*, and the host module will also lamp test / mute their alarm and vice-versa.

= *Auto Mute* is disabled.

= The internal sounder will sound for the duration of the *Auto Mute Timer* after which it will automatically stop. Pressing the *MUTE* button during the timer will also silence the sounder.

2.15.7 2510/2520 MKII DISPLAY MODULES

DSE25xx MKII Display Module option in the Expansion section allows to add two 25xxMKII Remote Display modules at the same time, one being added from the Communications section and the other from the Expansion. This is only available on module version 5.x.x and later.

NOTE: Enabling the DSE25xx MKII from the Expansion section reduces the total number of the expansion units from twenty down to five expansion modules in total, with only a single Battery Charger unit.



The following is then shown:

DSENet ID 0

2510/2520 MKII Display Enable

Expansion Enabled

Link Lost Alarm Action Shutdown

Control Buttons

Control Buttons Enable

Sounder Configuration

Sounder Enable

Follow main unit

Auto Mute Timer Enable

Auto Mute Timer 1m

Click to enable or disable the option. The relevant values below will appear *greyed out* if the alarm is disabled.

Select the alarm type of the *link lost alarm*. This alarm will act if the expansion module is not detected by the host module.

= The display is for instrumentation only – the mode change buttons are disabled.
 = The display acts as a complete mimic/control of the host module.

Enable or disable the expansion module's internal sounder.

= If the *mute / lamp test* button is pressed, other DSE2548 modules and the host module will not respond to this.
 = If the *mute / lamp test* button is pressed, other DSE2548 modules configured to *Follow main unit*, and the host module will also lamp test / mute their alarm and vice-versa.

= *Auto Mute* is disabled.
 = The internal sounder will sound for the duration of the *Auto Mute Timer* after which it will automatically stop. Pressing the *MUTE* button during the timer will also silence the sounder.


2.15.8 2548 ANNUNCIATOR MODULES

Select the DSENet ID of the LED expansion to be configured. The ID of the expansion input module is set by rotary decimal switch accessible on the rear of the device.




The following options are then shown:

2548 Expansion Enable



Parameter	Description
Expansion Enabled	<input type="checkbox"/> = The expansion module with the selected ID is not enabled. <input checked="" type="checkbox"/> = The expansion module with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.

Sounder Configuration



Parameter	Description
Follow Main Unit	<input type="checkbox"/> = If the <i>mute / lamp test</i> button is pressed, other DSE2548 modules and the host module does not respond to this. <input checked="" type="checkbox"/> = If the <i>mute / lamp test</i> button is pressed, other DSE2548 modules configured to <i>Follow main unit</i> , and the host module also lamp test / mute their alarm and vice-versa.
Sounder Enabled	<input type="checkbox"/> = The DSE2548 internal sounder does not annunciate on a fault condition becoming active. <input checked="" type="checkbox"/> = The DSE2548 internal sounder annunciates on a fault condition becoming active.

Parameter descriptions are continued overleaf...

LED Indicators

LED Label	Source	Polarity
A	System In Auto Mode	Unlit
B	Generator Load Inhibited	Lit
C	Combined Remote Start Request	Lit
D	Common Alarm	Lit
E	Not Used	Lit
F	Not Used	Lit
G	Not Used	Lit
H	Not Used	Lit

Annunciator Insert Card

Parameter	Description
Source	Select the output source to control the state of the output. See section entitled <i>Output Sources</i> for details of all available functions.
Polarity	Select the digital input polarity: Energise: When the output source is true, the output activates. De-Energise: When the output source is true, the output deactivates.
Annunciator Insert Card	Allows the user to create and print the custom text insert cards for the LEDs.

2.15.9 BATTERY CHARGERS

Select the DSENet ID of the battery charger to be configured. The ID of the expansion module is set by configuration of the device.



The following options are then shown:

DSENet ID

DSENet ID 0

Enable

Link Lost Alarm Action Shutdown

Modbus Slave ID 11

Display Instrumentation

Charger Name Charger ID0

Parameter	Description
Enable	<input type="checkbox"/> = The battery charger with the selected ID is not enabled. <input checked="" type="checkbox"/> = The battery charger with the selected ID is enabled. If the expansion module is not connected / detected by the module, the module generates an <i>Exp. Unit Failure</i> alarm with the configured <i>Link Lost Alarm Action</i> severity.
Modbus Server ID	The server ID used to address the battery charger via the host module's RS485 when using the host module as a MODBUS RTU pass through.
Display Instrumentation	<input type="checkbox"/> = The battery chargers' information is not shown on the host module's display. <input checked="" type="checkbox"/> = The battery charger information is shown on the host module's display.
Charger Name	Enter the <i>Charger Name</i> , this text is shown on the module display when viewing the battery charger instrumentation


2.16 ADVANCED


The *Advanced* page is subdivided into smaller sections. Select the required section with the mouse.




2.16.1 ADVANCED OPTIONS

2.16.1.1 PROTECTIONS

 **WARNING!** - Enabling this feature prevents the set being stopped upon critical alarm conditions. All shutdown alarms are disabled with the exception of EMERGENCY STOP which continues to operate.



This feature is provided to assist the system designer in meeting specifications for “Warning only,” “Protections Disabled,” “Run to Destruction,” “Battleshort Mode” or other similar wording.

Parameter	Description
Disable	<p> NOTE: Writing a configuration to the controller that has “Protections Disabled” configured, results in a warning message appearing on the PC screen for the user to acknowledge before the controller’s configuration is changed. This prevents inadvertent activation of the feature.</p> <p><input type="checkbox"/> = The module operates as normal and provide engine shutdown if required. <input checked="" type="checkbox"/> = <i>Protections disabled</i> function is activated. Operation depends upon the following configuration.</p>
Protections are disabled	<p>Never: The protections are not disabled Always: Protections are always overridden by the DSE controller. On Input: Protections are disabled whenever a configurable input set to <i>Protections Disabled</i> is activated</p>

Parameter descriptions are continued overleaf...


Parameter	Description
Protections Disabled Alarm Action	<p>If <i>Disable All Protections</i> is set to <i>On Input</i>, this selection allows configuration of an alarm to highlight that the protections have been disabled on the engine.</p> <p>Indication: Any output or LCD display indicator configured to <i>Protections Disabled</i> is made active; however the internal alarm sound does not operate.</p> <p>Warning: Any output or LCD display indicator configured to <i>Protections Disabled</i> is made active, and the internal alarm sound operates.</p> <p>When protections are disabled, <i>Protections Disabled</i> appears on the module display to inform the operator of this status.</p>
Coolant Level Protection Override	<p><input type="checkbox"/> = When a CANbus engine is selected, the <i>Coolant Level Protection</i> is provided when supported by the ECU (ECM).</p> <p><input checked="" type="checkbox"/> = The <i>Coolant Level Protection</i> is overridden and does not activate an alarm on the module</p>

2.16.1.2 ESCAPE MODE

The *Escape Mode* is used to instruct the CAN Engine to disable some of its specific ECU alarms to perform a special Maintenance / Regeneration operation while running off-load. The *Escape Mode* is activated through a Digital Input or through the control module's *Running Editor*. This feature is only supported on some electronic CAN engines.


NOTE: Activating *Escape Mode* does not disable the protections by the module.

NOTE: Refer to DSE Publication: 057-263 *DSE7410 MKII & DSE7420 MKII Operator Manual* for details on how to activate the *Escape Mode* through the control module's *Running Editor*, available on our website: www.deepseaelectronics.com



Parameter	Description
Enable	<p>Select the required method to activate <i>Escape Mode</i>. Options are as follows:</p> <p>Any: The <i>Escape Mode</i> is activated when the <i>Escape Mode</i> input function is active or <i>Escape Mode</i> option on the module <i>Running Editor</i> is activated.</p> <p>Disabled: The <i>Escape Mode</i> is disabled, activating the <i>Escape Mode</i> input doesn't activate <i>Escape Mode</i>, and the <i>Escape Mode</i> parameter is hided on the module's <i>Running Editor</i></p> <p>On Input: The <i>Escape Mode</i> is activated when the <i>Escape Mode</i> input function is active. With this option <i>Escape Mode</i> parameter is hided on the module's <i>Running Editor</i></p> <p>Running Editor: The <i>Escape Mode</i> is activated when the <i>Escape Mode</i> option on the module <i>Running Editor</i> is activated. The module does not respond to the <i>Escape Mode</i> input when active.</p>
Action	<p>Select the action when the <i>Escape Mode</i> is activated through a digital input or from the module's <i>Running Editor</i>. Options are:</p> <p>Indication</p> <p>Warning</p>
Duration	<p>The time duration for the <i>Escape Mode</i> remains active when activated from the module's <i>Running Editor</i> or from the input. Upon termination of this timer the <i>Escape Mode</i> deactivates.</p>

2.16.1.3 SYNCHRONISING TIMERS



Parameter	Description
Synchronising Delay	This timer starts when a breaker closure is requested in manual mode, either by pressing the <i>Generator Close Button</i> or the <i>Mains Close Button</i> , or upon a Mains Return, it waits for the configured time before it starts the <i>Check Sync</i> process.
Interlock Override Off	This timer activates when the <i>Generator Closed Auxiliary</i> becomes inactive after the <i>Closed Transition</i> , it is used to keep the <i>Interlock Override</i> output active after that the generator breaker has opened to make sure that the breaker has responded correctly.


2.16.1.4 AVR OPTIONS

This feature allows the module to communicate with a supported CAN AVR through its ECU port.

NOTE: At the time of writing, only the DSEA108 and DSEA109 AVRs are supported. For further details, refer to DSE Publication: *057-281 DSEA108 Operator Manual* or *057-295 DSEA109 Operator Manual* available on our website: www.deepseaelectronics.com

NOTE: The module's ECU Port's baud rate is defined by the engine file selected in the *Application* section. Most engines' ECU baud rates are set to be 250 kb/s, ensure the baud rate of the AVR matches the engine ECU's baud rate.

NOTE: When connecting the AVR to the module's CAN Port, ensure the correct baud rate is configured in order to match the AVR's baud rate. Refer to the section entitled *CAN Port* elsewhere in this document for further details.




Parameter	Description
Enable AVR CAN Communications	<input type="checkbox"/> = Communications with the CAN AVR is disabled <input checked="" type="checkbox"/> = Enables communication with the CAN AVR through the ECU port.
CAN Port	Select the CAN port through which to communicate with the AVR. ECU: The module communicates with the AVR through its <i>ECU Port</i> terminals. CAN: The module communicates with the AVR through its <i>CAN Port</i> terminals.
AVR Source Address	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: For a full list of the AVR CAN message and instrumentation, refer to DSE Publication: <i>057-281 DSEA108 Operator Manual</i> or <i>057-295 DSEA109 Operator Manual</i> which is found on our website: www.deepseaelectronics.com</p> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: For further details on how to configure the DSEA108 or DSEA109 CAN Source address, refer to DSE Publication: <i>057-283 DSEA108 Software Manual</i> or <i>057-294 DSEA109 Software Manual</i> which is found on our website: www.deepseaelectronics.com</p> </div> <p>Set the AVR's <i>CAN Source Address</i> to communicate through.</p>
Module CAN Address	The CAN Source address used by the module when sending CAN messages to the AVR.

Descriptions continued overleaf...

Parameter	Description
Match AVR Alternative Configuration to Controller	<p>NOTE: For further details on how to configure the DSEA108 alternative configurations, refer to DSE Publication: 057-283 DSEA108 Software Manual or 057-294 DSEA109 Software Manual which is found on our website: www.deepseaelectronics.com</p> <p>This feature is used to send the module's Alternative Configurations Nominal Voltage and Nominal Frequency levels to the CAN AVR, to match the CAN AVR's Alternative Configurations with the module's Alternative Configurations.</p> <p><input type="checkbox"/> = The module does not send its Alternative Configurations settings to the CAN AVR. <input checked="" type="checkbox"/> = The sends its <i>Alternative Configurations' Nominal Voltage and Nominal Frequency</i> levels to the CAN AVR's to match its Alternative Configurations' Voltage Set Point and Frequency select.</p>

2.16.1.5 AVR DATA FAIL

Indicates CAN communication failure between the module and the CAN AVR.



Parameter	Description
Action	Select the action to take when the module detects a communication failure with the CAN AVR. The options are: Electrical Trip Indication Shutdown Warning
Arming	Select when the <i>AVR Data Fail</i> is monitored. Options are as follows: Always: The alarm is active at any time the CAN Link is lost From Safety On: Active only after the <i>Safety On</i> delay timer From Starting: Active only after the <i>Crank Relay</i> is energised Never: Alarm is disabled Loading Alarms Activation: The alarm is monitored after the generator is running, and the voltage and frequency are above their <i>Loading</i> levels, until the generator stops.
Activation Delay	The time delay for the module to wait before activating <i>AVR Data Fail</i> alarm when detected.


2.16.1.6 AVR FAULT

Parameter	Description
Action	Select the action to take after the <i>Activation Delay</i> timer, when the CAN AVR activates an alarm. The options are: Electrical Trip Indication Shutdown Warning
Arming	Select when the <i>AVR Fault</i> is monitored. Options are as follows: Always: The alarm is active at any time the CAN Link is lost From Safety On: Active only after the <i>Safety On</i> delay timer From Starting: Active only after the <i>Crank Relay</i> is energised
Activation Delay	The time delay for the module to wait before activating <i>AVR Fault</i> alarm when detected.


2.16.2 PLC

NOTE: For further details and instructions on the PLC Editor, refer to DSE Publication: 057-314 Advanced PLC Software Manual which is found on our website: www.deepseaelectronics.com

NOTE: For the earlier software versions pre-V5 of the module, refer to DSE Publication: 057-175 PLC Programming Guide which is found on our website: www.deepseaelectronics.com




Click to open the *PLC Editor*, then the *PLC Editor* opens as shown below.




2.16.2.1 MODULE DISPLAY

The *Module Display* shows a combination of Counters, Timers, Registers and Stores on the module's PLC screen page when configured. A maximum of eight instruments can be configured in the *Module Display*.



2.16.3 CONFIGURABLE GENCOMM PAGES



Configurable Gencomm pages are available for advanced MODBUS applications on the controller. The intention is to allow the user to create personal collections of data in subsequent registers to minimise the number of MODBUS reads required by the client and hence speed up data collection.

All configurable Gencomm registers are 32-bit unsigned format.

The



Configurable MODBUS pages are:

Page	Hex address	Decimal address
166	A600	42496
167	A700	42752
168	A800	43008
169	A900	43264

Example of Gencomm page configuration:

Page 166	
Register	Value
0-1	Engine At Rest
2-3	Engine Speed
4-5	Fuel Temperature
6-7	Oil Pressure

The register address is obtained from the formula:

$register_address = page_number * 256 + register_offset$.

To read the *Engine Speed* from the above register, the MODBUS client device needs to read the data in two registers and then combine the data from the Most Significant Bit and the Least Significant Bit.


MSB address in Decimal = $(166 * 256) + 2 = 42498$

LSB address in Decimal = $(166 * 256) + 3 = 42499$


3 SCADA

SCADA stands for **S**upervisory **C**ontrol **A**nd **D**ata **A**cquisition and is provided both as a service tool and also as a means of monitoring / controlling the generator set.

As a service tool, the SCADA pages are to check the operation of the controller's inputs and outputs as well as checking the generators operating parameters.



The SCADA page is subdivided into smaller sections. Select the required section with the mouse.



3.1 GENERATOR IDENTITY

Shows the module's current settings for *Site ID* and *Genset ID*



3.2 MIMIC


This screen provides a mimic of the control module and allows the operator to change the control mode of the module.



Hint : Buttons may not operate if this has been locked out by the *Access Permissions* security feature of the Configuration Suite software. Refer to the system supplier for details.

Click the mimic buttons to control the module remotely.

3.3 DIGITAL INPUTS



3.4 DIGITAL OUTPUTS

Digital Outputs			
Digital Outputs (Supplied From Emergency Stop Input)			
		Active	Open / Closed
A	Fuel Relay	<input checked="" type="checkbox"/>	<input type="checkbox"/>
B	Start Relay	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Digital Outputs (Volts Free)			
		Active	Open / Closed
C	Not Used	<input checked="" type="checkbox"/>	<input type="checkbox"/>
D	Inhibit Scheduled Run	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Digital Outputs (DC Supply Out)			
		Active	Open / Closed
E	Preheat During Preheat Timer	<input checked="" type="checkbox"/>	<input type="checkbox"/>
F	Combined Remote Start Output	<input checked="" type="checkbox"/>	<input type="checkbox"/>
G	Lamp Test	<input checked="" type="checkbox"/>	<input type="checkbox"/>
H	System In Manual Mode	<input checked="" type="checkbox"/>	<input type="checkbox"/>
I	Not Used	<input type="checkbox"/>	<input type="checkbox"/>
J	Not Used	<input type="checkbox"/>	<input type="checkbox"/>

Shows if the output channel is active or not. This output is *closed* and is active. The output is configured to be *System in Manual Mode Energise*. As the module is in Manual mode, the output is *energised*.

State of the output (open or closed)

3.5 VIRTUAL LEDS

Shows the state of the *Virtual LEDs*. These LEDs are not fitted to the module or expansion modules; they are not physical LEDs. They are provided to show status and appear only in the SCADA section of the configuration suite or read by third party PLC or Building Management Systems (for example) using the MODBUS RTU protocol.

The screenshot displays a window titled "Virtual LEDs" with a sub-header "LED Status". It contains a table with 20 rows, each representing an LED. The first column lists the LED number (LED 1 to LED 20), and the second column lists the LED's function or name. To the right of the names is a vertical column of green circles, each representing the active status of the corresponding LED. The word "Active" is positioned above this column. Two callout boxes provide additional information: one points to the green circles, stating "Shows if the Virtual LED is active or not.", and another points to the LED names, stating "Shows what the Virtual LED is configured for (shows the LED number if not configured)."


LED Number	LED Name	Active Status
LED 1	Combined Remote Start Output	Active
LED 2	Fuel Relay	Active
LED 3	Start Relay	Active
LED 4	Common Alarm	Active
LED 5	Not Used	Active
LED 6	Common Warning	Active
LED 7	Common Shutdown	Active
LED 8	Not Used	Active
LED 9	Not Used	Active
LED 10	Not Used	Active
LED 11	Not Used	Active
LED 12	Not Used	Active
LED 13	Not Used	Active
LED 14	Not Used	Active
LED 15	Not Used	Active
LED 16	Not Used	Active
LED 17	Not Used	Active
LED 18	Not Used	Active
LED 19	Not Used	Active
LED 20	Not Used	Active

3.6 MAINS



= Only available on DSE7420 MKII AMF Modules

The *Mains* section is subdivided into smaller sections. Select the required section with the mouse.



3.6.1 FREQUENCY, VOLTAGES AND CURRENT

Shows the module's measurements of the mains supply (DSE7420 MKII only).

Mains		
Frequency		
49.9 Hz		
Phase Rotation		
L1-L2-L3		
Phase To Neutral Voltages		
L1 - N 230.2 V	L2 - N 226.9 V	L3 - N 231.6 V
Phase To Phase Voltages		
L1 - L2 395.1 V	L2 - L3 397.2 V	L3 - L1 401.0 V
Mains Current		
L1 85.0 A	L2 86.0 A	L3 86.0 A
Earth Current		
27.0 A		

Mains current is displayed when the CTs are placed in the *load*, and the mains is on load.


3.6.2 POWER

Shows the modules measurements of the mains supply power (DSE7420 MKII only).

Power				
Watts				
L1	L2	L3	Total	
3.0 kW	3.0 kW	3.0 kW	9.0 kW	
VA				
L1	L2	L3	Total	
10.0 kVA	10.0 kVA	10.0 kVA	30.0 kVA	
VAr				
L1	L2	L3	Total	
8.0 kVAr	8.0 kVAr	8.0 kVAr	24.0 kVAr	
Power factor				
L1	L2	L3	Average	
Lag 0.32	Lag 0.32	Lag 0.31	Lag 0.30	
Accumulated Power				
kWh	kVAh	kVArh		
107.7 kWh	174.2 kVAh	75.0 kVArh		

3.7 GENERATOR

The *Generator* section is subdivided into smaller sections. Select the required section with the mouse.



3.7.1 FREQUENCY, VOLTAGES AND CURRENT

Shows the modules measurements of the generator supply.

A screenshot of a monitoring panel titled 'Frequency, Voltages and Current'. The panel is light blue with a darker blue header. It contains several sections with data:

- Frequency:** 0.0 Hz
- Phase to Neutral Voltages:**


L1 - N	L2 - N	L3 - N
0.0 v	0.0 v	0.0 v
- Phase to Phase Voltages:**

L1 - L2	L2 - L3	L3 - L1
0.0 v	0.0 v	0.0 v
- Current:**

L1	L2	L3
0.0 A	0.0 A	0.0 A
- Earth Current:** 0.0 A

3.7.2 POWER

Shows the module's measurements of the generator supply power.




3.7.3 MULTISET

Allows setting the module’s MSC link parameters.

Parameter	Description
Sets On The Bus	Shows the number of modules currently connected to the MSC link.
MSC ID	Each controller connected to the MSC link must have a unique ID. When all the controllers are powered up “one at a time,” this is automatically set. If powering all modules up at the same time results in “MSC ID alarm,” manually setting the <i>MSC ID</i> here prevents this.
Priority	Used when the <i>Dual Mutual Standby</i> is in operation and the <i>Balancing Mode</i> is configured to <i>Set Priority</i> .
Dual Mutual Time	This is an incremental internal hour’s counter used only for the <i>Dual Mutual Standby</i> when the <i>Balancing Mode</i> is set to <i>Dual Mutual Time</i> . It holds the accumulated hours counter for the <i>Duty Time</i> of operation.

3.8 ENGINE

Shows the modules measurements of the engine parameters.



3.9 FUEL USE AND EFFICIENCY

Shows the measurement of the fuel use and efficiency (If configured)


Fuel Use and Efficiency		
Fuel Consumption		
Instantaneous 100.77 l/hr		Trip 142.38 l/hr
Fuel Use		
	Trip ---	Accumulated 2049 litres
Fuel Efficiency		
Instantaneous 315.65 kWh/l	Trip 0.00 kWh/l	Accumulated 3.40 kWh/l
Run Time Until Empty		
	17:46	

3.10 FLEXIBLE SENSOR

Shows the modules measurements of the flexible sensor's parameters.
The *Flexible Sensor* is subdivided into smaller sections.
Select the required section with the mouse.



3.10.1 FLEXIBLE SENSOR A - C



Flexible Sensor A - C

This page is used when Analogue Inputs are configured as Flexible Sensors


Flexible Sensor A

Flexible Sensor B

Flexible Sensor C

The image shows a configuration page for Flexible Sensor A - C. It has a blue header with the title "Flexible Sensor A - C". Below the header is a subtitle: "This page is used when Analogue Inputs are configured as Flexible Sensors". The main content area contains three vertically stacked, empty rectangular boxes. The top box is labeled "Flexible Sensor A", the middle box is labeled "Flexible Sensor B", and the bottom box is labeled "Flexible Sensor C".

3.10.2 FLEXIBLE SENSOR D - F



Flexible Sensor D - F

This page is used when Analogue Inputs are configured as Flexible Sensors

Flexible Sensor D

Flexible Sensor E

Flexible Sensor F

The image shows a configuration page for Flexible Sensor D - F. It has a blue header with the title "Flexible Sensor D - F". Below the header is a subtitle: "This page is used when Analogue Inputs are configured as Flexible Sensors". The main content area contains three vertically stacked, empty rectangular boxes. The top box is labeled "Flexible Sensor D", the middle box is labeled "Flexible Sensor E", and the bottom box is labeled "Flexible Sensor F".


3.11 CONFIGURABLE CAN INSTRUMENTATION

Shows the module's readings of the configured *CAN Instrumentation*. This is only available if the module is configured for *Configurable CAN Instrumentation*, the *Enhanced Canbus* option is enabled, and the message is available over the relevant configured CANbus.

Configurable CAN Instrumentation		
Configurable CAN Instrumentation		
1	Longitude - VP	210.0072902
2	Engine Oil Pressure - EFL_P1	124 kPa
3	Latitude - VP	1.0036625
4	Engine Coolant Pressure - EFL_P1	234 kPa
5	Engine Fuel Pressure - EFL_P1	0 kPa
6	Engine Hours - HOURS	1000.0 hr
7	Engine Oil Temperature 1 - ET1	84.37042 deg C
8	Engine Coolant Temperature - ET1	55 deg C
9	Engine Fuel Rate - LFE	10.00 L/h
10	Electrical Potencial Plnp - VEP1	0.00 V


3.12 ALARMS

Shows any present alarm conditions.




3.13 ENGINE ALARMS

The *Engine Alarms* page is subdivided into smaller sections. Select the required section with the mouse.




3.13.1 CURRENT ENGINE ALARMS

Shows the current engine alarms.




3.13.2 PREVIOUS ENGINE ALARMS

Shows the previous engine alarms.



3.14 STATUS

Shows the module's current status.

Status	
Supervisor State Running On Load	Software Version 1.0
Engine/Generator State Running	Module ID 218DDA17D
Mains Detection State [Empty]	Mode 
Load Switching State Closed To Generator	
Protections Enabled	
Heater Fitted [Empty]	

3.15 EVENT LOG

Shows the contents of the module's event log.

#	Date	Time	Hours Run	Event	Details
1	02/10/2008	11:41:20	0:12	Shutdown	Oil Pressure Sensor Open Circuit
2	02/10/2008	11:41:19	0:12	Mains	Mains fail
3	02/10/2008	11:41:18	0:12	Restart	Power Up
4	28/09/2008	08:24:43	0:12	Shutdown	Oil Pressure Sensor Open Circuit
5	28/09/2008	08:24:42	0:12	Mains	Mains fail
6	28/09/2008	08:24:40	0:12	Restart	Power Up
7	27/09/2008	07:48:17	0:12	Shutdown	Oil Pressure Sensor Open Circuit
8	27/09/2008	07:48:16	0:12	Mains	Mains fail
9	27/09/2008	07:48:14	0:12	Restart	Power Up
10	27/09/2008	07:31:00	0:12	Shutdown	Oil Pressure Sensor Open Circuit
11	27/09/2008	07:30:59	0:12	Mains	Mains fail
12	27/09/2008	07:30:57	0:12	Restart	Power Up
13	26/09/2008	07:48:19	0:12	Shutdown	Oil Pressure Sensor Open Circuit
14	26/09/2008	07:48:18	0:12	Mains	Mains fail
15	26/09/2008	07:48:17	0:12	Restart	Power Up
16	26/09/2008	07:45:58	0:12	Restart	Power Up
17	26/09/2008	06:54:11	0:12	Shutdown	Oil Pressure Sensor Open Circuit
18	26/09/2008	06:54:10	0:12	Mains	Mains fail
19	26/09/2008	06:54:09	0:12	Restart	Power Up
20	25/09/2008	08:56:38	0:12	Shutdown	Oil Pressure Sensor Open Circuit
21	25/09/2008	08:56:37	0:12	Mains	Mains fail
22	25/09/2008	08:56:35	0:12	Restart	Power Up
23	25/09/2008	08:52:50	0:12	Mains	Mains fail
24	25/09/2008	08:52:48	0:12	Restart	Power Up
25	25/09/2008	06:55:04	0:12	Shutdown	Oil Pressure Sensor Open Circuit
26	25/09/2008	06:55:03	0:12	Mains	Mains fail

Export to Excel
Export to CSV
Export to PDF
Print event log

Click to save the log to an Excel or csv file for use in an external spreadsheet program.

Click to save the log to a pdf (Adobe Acrobat) file.

Click to print the log.

3.16 ENHANCED CANBUS











Shows the module's readings of enhanced Canbus parameters. This is only available if the module is configured for CAN communication and the *Enhanced Canbus* option is enabled.

Enhanced CANbus	
Engine Oil Temperature	Inlet Manifold Temperature
	Temp. 1 Temp. 2
Exhaust Temperature	Coolant Pressure
Temp. 1 Temp. 2	Press. 1 Press. 2
Fuel Pressure	Turbo Pressure
Press. 1 Press. 2	Press. 1 Press. 2

3.17 REMOTE CONTROL


The remote control section of the SCADA section is used for monitoring and control of module 'remote control' sources.

Any of the module outputs, expansion outputs, LED indicators, or remote Annunciator LEDs are to be configured to *Remote Control 1-10*. This output source is energised/de-energised by click the respective check box as shown below in the *Activate* column below.

Remote Control		
Remote Control Sources		
Control	Activate	Active
1	<input checked="" type="checkbox"/>	
2	<input type="checkbox"/>	
3	<input type="checkbox"/>	
4	<input checked="" type="checkbox"/>	
5	<input type="checkbox"/>	
6	<input type="checkbox"/>	
7	<input checked="" type="checkbox"/>	
8	<input type="checkbox"/>	
9	<input type="checkbox"/>	
10	<input type="checkbox"/>	


3.18 MAINTENANCE

The *Maintenance* section is subdivided into smaller sections. Select the required section with the mouse.



3.18.1 RECALIBRATE TRANSDUCERS

The *Recalibrate Transducers* section is subdivided into smaller sections. Select the required section with the mouse.



3.18.1.1 FLEXIBLE SENSORS

Allows the recalibration of the flexible sensors (when enabled in the module configuration).

Flexible Sensor A - C

This page is used when Analogue Inputs are configured as Flexible Sensors

Flexible Sensor A

Flexible Sensor A
0 %

Flexible Sensor B

Flexible Sensor B
0.06 Bar

Flexible Sensor C

Flexible Sensor C
Fault

Flexible Sensor D - F

This page is used when Analogue Inputs are configured as Flexible Sensors

Flexible Sensor D

Not Used

Flexible Sensor E

Configured As Digital Input

Flexible Sensor F

Not Used

3.18.1.2 GENERATOR CT

Allows the recalibration of the generator CT readings.

Generator CT

Current L1



Current L2



Current L3



Current Earth/Neutral



Reset

3.18.1.3 MAINS CT



= Only available on DSE7420 MKII AMF Modules and when the *CT Location* is configured to *Load*.

Mains CT

Current L1



Current L2



Current L3



Current Earth/Neutral



Reset

Reset to Default


3.18.2 EXPANSION CALIBRATION

This section allows the analogue sensor inputs of the DSE2130 and DSE2131 input expansion modules to be calibrated to remove inaccuracies caused by the tolerance of the sensor devices. While the engine is running, the instruments are calibrated, and reference needs to be made to a third party accurate sensing device to ensure accurate recalibration.



3.18.3 HOURS RUN AND NUMBER OF STARTS

This section allows the Hours Run and Number of Starts to be customised on the controller. Typically, this is used when fitting a new controller to an older engine so that the controller display matches the amount of work previously done by the system.



3.18.4 TIME


This section allows the day and time to be set and changed on the controller.

The screenshot displays the 'Date and Time' configuration page, which is divided into several sections:

- Date and Time**: The main title of the configuration page.
- Module Date**: A field showing the current date as 21/01/2014. A callout box points to this field with the text: "Display of the module's current date and time".
- Module Time**: A field showing the current time as 09:53:10.
- Set Date And Time**: A section for manual configuration. It includes:
 - A **Date** field with a dropdown arrow, currently set to 14/02/2000. A callout box points to this field with the text: "Type the new date / time or click the up and down arrows to change the settings".
 - A **Time** field with a dropdown arrow, currently set to 05:29:57.
 - A **Set** button below the date and time fields. A callout box points to this button with the text: "Click Set to adjust the module to the selected date/time."
- Set To PC Time**: A section for synchronizing with the PC. It includes:
 - A **Date** field showing 21/01/2014.
 - A **Time** field showing 09:53:11.
 - A **Set To PC Time** button. A callout box points to this button with the text: "Click Set to adjust the module to the date/time that your PC is set to."

3.18.5 ACCUMULATED INSTRUMENTATION

The *Accumulated Instrumentation* section is subdivided into smaller sections. Select the required section with the mouse.



3.18.5.1 GENERATOR

Allows the user to view or change the module's accumulated instrumentation.

The screenshot shows the "Generator Accumulated Instrumentation" interface. It is divided into four main sections: kWh, kVAh, kVArh, and Reset. Each section contains a current value, a numeric input field with up/down arrows, and a "Set" button. The "Reset" section contains a "Reset all values to zero" button. Callouts provide instructions for each section.

Parameter	Current Value	Input Value
kWh	154.0 kWh	154.0
kVAh	100.0 kVAh	100.0
kVArh	85.0 kVArh	85.0

Callout 1: Display of the module's current value for the parameter.

Callout 2: Type the new value or click the up and down arrows to change.

Callout 3: Click Set to adjust the module to the selected value.

Callout 4: Click to reset all the accumulated instrumentation counters to zero.

3.18.5.2 MAINS



= Only available on DSE7420 MKII AMF Modules and when the *CT Location* is configured to *Load*.

Mains Accumulated Instrumentation

kWh

kWh: 154.0 kWh

kVAh

kVAh: 100.0 kVAh

kVArh

kVArh: 85.0 kVArh

Reset

3.18.6 FUEL USE AND EFFICIENCY

The screenshot displays a SCADA interface with three main sections: 'Accumulated Fuel Use', 'Fuel Efficiency', and 'Reset'. Each section contains a parameter name, a numerical value, and a 'Set' button. The 'Accumulated Fuel Use' section shows 'Fuel Use' with a value of '0 litres' and a 'Set' button. The 'Fuel Efficiency' section shows 'Fuel Efficiency' with a value of '0 kWh/l' and a 'Set' button. The 'Reset' section contains a 'Reset all values to zero' button. Callout boxes provide instructions: 'Display of the module's current value for the parameter.' points to the '0 litres' value; 'Type the new value or click the up and down arrows to change the settings.' points to the input field for '0'; 'Click Set to adjust the module to the selected value.' points to the 'Set' button in the 'Fuel Efficiency' section; and 'Click to reset all the values to zero.' points to the 'Reset all values to zero' button.

Accumulated Fuel Use

Fuel Use 0 litres

Fuel Efficiency 0 kWh/l

Reset

Reset all values to zero

Display of the module's current value for the parameter.

Type the new value or click the up and down arrows to change the settings.

Click Set to adjust the module to the selected value.

Click to reset all the values to zero.

3.18.7 MAINTENANCE ALARM RESET

Three maintenance alarms active in the control module. Each is reset individually.


The screenshot displays a 'Maintenance Alarm Reset' interface with three distinct panels, each for a different alarm. Each panel contains the following information:

- Maintenance Alarm 1:** Running Time Until Next Maintenance: 10:00; Date Of Next Maintenance.
- Maintenance Alarm 2:** Running Time Until Next Maintenance: 1000:00; Date Of Next Maintenance.
- Maintenance Alarm 3:** Running Time Until Next Maintenance: 100:00; Date Of Next Maintenance.

Each panel features a 'Reset' button and a note: 'Press reset to schedule next maintenance, based upon module's maintenance configuration.' A callout box points to the 'Reset' button of Maintenance Alarm 2, containing the text: 'Reset the maintenance alarm based upon the module's configuration.'

3.18.8 ELECTRONIC ENGINE CONTROLS


This section allows settings within the engine's ECU to be altered when supported.



Parameter	Description
DPF Auto Regen Inhibit	<input type="checkbox"/> = The ECU's DPF Auto Regeneration happens automatically. <input checked="" type="checkbox"/> = The ECU's DPF Auto Regeneration is inhibited from activating.
Governor Gain (ECM)	The setting for the <i>Gain (P)</i> of the ECU/ECM's control loop over the engine speed.
Frequency Adjust Offset	A positive/negative offset that is applied to the entire ECU/ECM's droop setting as percentage its configured nominal speed. An <i>Offset</i> of -1% with a nominal speed of 1500 RPM would result in the entire ECU's droop curve being offset by 15 RPM.

3.18.9 MANUAL SPEED TRIM

Allows manual speed trim of the engine (when enabled in the module configuration).




3.18.10 MODULE LOCK

Module Access Password


NOTE : If the PIN is lost or forgotten, it is no more possible to access the module!

Allows a PIN (Personal Identification Number) to be set in the controller. This PIN must be entered to either access the front panel configuration editor or before a configuration file is sent to the controller from the PC software.



Accumulated Instrumentation Lock

NOTE: Enabling the *Accumulated Instrumentation Lock* option is **PERMANENT** and cannot be **REVERSED**. This is used to prevent tampering with the Accumulated Instrumentation such as Engine Hours. For further information, contact DSE Technical Support at Support@deepseaelectronics.com



Parameter	Description
Accumulated Instrumentation Lock Enable	<p>NOTE: Enabling this option in the module's configuration locks the <i>Accumulated Instrumentations</i> permanently and it is not possible to disable it again through the configuration. For more information contact DSE Technical Support at Support@deepseaelectronics.com</p> <p>This feature is used to prevent the <i>Accumulated Instrumentation</i> being reset or edited by any means. The <i>Accumulated Instrumentation</i> consists of <i>Engine Run Hours, Number of Starts, Fuel Use, Generator kwh/kvarh/kvah, and Mains kwh/kvarh/kvah.</i></p> <p><input type="checkbox"/> = The module does not lock its accumulated instrumentations, the <i>Apply Lock (permanent)</i> tab is greyed out. <input checked="" type="checkbox"/> = The <i>Apply Lock (Permanent)</i> tab becomes visible.</p>
Apply Lock Permanent	<p>When pressing the <i>Apply Lock (Permanent)</i> button the below warning message warns the user that this is a PERMANENT lock and once it is written to the module it cannot be changed.</p> <div style="border: 1px solid gray; padding: 5px; margin: 10px 0;"> <p>Warning</p> <p>Accumulated Instrumentation Lock is a permanent setting and cannot be reversed. By enabling this feature the following parameters cannot be reset or altered: Engine Hours Run Engine Number of Starts Engine Fuel Used Generator Accumulated Instrumentation Mains Accumulated Instrumentation</p> <p style="text-align: center;">OK</p> </div> <p>Upon pressing OK, the module LOCKS all its Accumulated Instrumentations (Engine Run Hours, Number of Starts, Generator kwh/kvarh/kvah, and Mains kwh/kvarh/kvah). When the module's Accumulated Instrumentations are locked, the Scada page changes to show the padlock icon indicating that the Accumulated Instrumentations are locked, the checkbox and the button are no longer available.</p> <div style="border: 1px solid gray; padding: 5px; margin: 10px 0;"> <p>Accumulated Instrumentation Lock</p> <p style="text-align: center;"> Module is LOCKED</p> <p>Accumulated Instrumentation Lock is a permanent setting and cannot be reversed. By enabling this feature the following parameters cannot be reset or altered: Engine Hours Run Engine Number of Starts Engine Fuel Used Generator Accumulated Instrumentation Mains Accumulated Instrumentation</p> </div>


3.19 COMMUNICATIONS INFORMATION

Displays the IP connection information.

IP Connection Information	
IP address 255 . 255 . 255 . 255	MAC Address FF : FF : FF : FF : FF : FF
Subnet Mask 255 . 255 . 255 . 255	DNS 255 . 255 . 255 . 255
Host <input type="text"/>	MODBUS Preferred IP Address 255 . 255 . 255 . 255
Domain <input type="text"/>	MODBUS Connection Port <input type="text"/>
Gateway 255 . 255 . 255 . 255	DHCP <input type="text"/>
	TCP Vendor <input type="text"/>

3.20 DATA LOG

Allows viewing of the module datalog (if configured).




3.20.1 DATA LOG STATUS

Data Log Status	
Internal Memory Capacity	1024 kB
Data Logging Status	Not Logging
Remaining Data Log Memory	Space remaining in Internal memory: 1024 kB
Data Log Mode	Keep New
Total Log Pages Available	3
USB Drive Status	Not Fitted
Data Log Destination	Internal

3.21 PLC

NOTE: For further details and instructions on PLC Logic and PLC Functions, refer to the **DSE PLC PROGRAMMING GUIDE**, document part number **057-175**.

The PLC section is subdivided into smaller sections. Select the required section with the mouse.



3.21.1 PLC LOGIC

This section displays the real-time status of the PLC Logic configured within the module. This section is useful for assisting with fault finding issues relating to or caused by the PLC Logic.

The screenshot shows a ladder logic diagram with the following elements and callouts:

- Green highlighting:** A callout points to a green-shaded area containing a timer '10:00 -> 12:00' and a counter '10:19:15', stating: "Green highlighting shows the condition is True."
- Live timer and counter display:** A callout points to the '10:19:15' counter, stating: "Live timer and counter display subject to the speed of update over the communications link."
- Coil State - Clear:** A callout points to a coil labeled 'Clear', stating: "Coil State – Clear means the flag is not set."

3.21.2 PLC STORES

Allows the editing and setting of PLC Stores values.



The screenshot shows a 'PLC Stores' window with a table of six stores. Each store has a current value and a control interface consisting of a numeric input field with up/down arrows and a 'Set' button. Callouts provide instructions: 'Type the value or click the Up or Down arrows.' points to the input field of Store 1, and 'Click to set the new value into the PLC Store.' points to the 'Set' button of Store 2.

Store	Current Value	Control Value	Action
Store 1	15	2	Set
Store 2	47	13	Set
Store 3	2	5	Set
Store 4	10	0	Set
Store 5	0	0	Set
Store 6	0	0	Set

3.22 AVR

3.22.1 FREQUENCY, VOLTAGES AND CURRENT

The screenshot displays a monitoring panel titled 'Frequency, Voltages and Current'. It contains six sections, each showing a specific measurement value:

- Frequency:** 50.0 Hz
- Feedback Voltage:** 120.0 V
- Droop Current:** 0.00 A
- Excitation Voltage:** 14.10 V
- Auxiliary Voltage:** 178.9 V

3.22.2 DIAGNOSTICS

Diagnostics		
External Control		
Potentiometer +++	Voltage 0.02 V	
Set Points		
Voltage 120.0 V	Droop 3.0 %	UFRO Knee 42.7 Hz
Proportional 80.6	Integral 9.7	Derivative 50.0
Excitation Output		
Off Load Duty Cycle 8.0 %	Maximum Duty Cycle 100.0 %	
Soft Start		
Ramp Start Point (% of set point) 27.0 %	Ramp Rate (%/s) 30.0 %	

3.22.3 STATUS

Status

Software Version

1.0.11

Configuration

Active Configuration	Active Stability Configuration
0	1

3.22.4 CONTROL

Control

Set Points

Droop	3.0 %	<input style="width: 90%; border: none;" type="range"/>	3.0 %
Proportional	80.6	<input style="width: 90%; border: none;" type="range"/>	80.6
Integral	9.7	<input style="width: 90%; border: none;" type="range"/>	9.7
Derivative	50.0	<input style="width: 90%; border: none;" type="range"/>	50.0

Excitation Output

Off Load Duty Cycle	8.0 %	<input style="width: 90%; border: none;" type="range"/>	8.0 %
Maximum Duty Cycle	100.0 %	<input style="width: 90%; border: none;" type="range"/>	100.0 %

Soft Start

Ramp Start Point (% of set point)	27.0 %	<input style="width: 90%; border: none;" type="range"/>	27.0 %
Ramp Rate (%/s)	30.0 %	<input style="width: 90%; border: none;" type="range"/>	30.0 %

Configuration

Active Configuration	0	<input style="width: 90%; border: none;" type="range"/>	0
Active Stability Configuration	1	<input style="width: 90%; border: none;" type="range"/>	1


3.22.5 AVR ALARMS

AVR Alarms

AVR Alarms


Start-up failed trip

3.23 EXPANSION



Allows monitoring of the controller's expansion modules (when fitted)

For example:



4 ALARM TYPES

The protection included with the DSE control modules provides increasing levels of notification, depending upon the severity of the situation:

Alarm type	Description
Indication	No audible alarm or common warning signal occurs. <i>Indication</i> alarms are only used to illuminate indicators or to activate outputs.
Warning	Audible alarm and common alarm signal is generated. The set continues to run. <i>Warning alarms</i> are used to draw the operator's attention to a minor issue or to a problem that may escalate to an Electrical Trip or Shutdown Alarm if left untreated.
Electrical Trip	Audible alarm and common alarm signal is generated. The set is taken off load and the cooling timer begins, after which the set is stopped. <i>Electrical Trip alarms</i> are series issues that require the set to be taken off load. As the name implies, this is often electrical faults that occur 'after' the load switch. The set is allowed to cool before stopping.
Shutdown	Audible alarm and common alarm signal is generated. The set is taken off load and immediately stopped. <i>Shutdown alarms</i> are serious issues that demand immediate stopping of the generator. For instance, Emergency Stop or Overspeed alarms require immediate shutdown.

5 ALARM ARMING

The protections on the DSE module are active during their configured *Alarm Arming* setting. The table below shows the timing segment for the different *Alarm Arming* options with regards to the generator status.

Timing Segment	Stopped	Start Delay	ECU Wake Up Delay	Preheat	Cranking	Safety Delay	Smoke Limiting	Smoke Limiting Off	Warming Up	Gen Available / Gen On Load	Cooling	Cooling in Idle
Never												
Always												
When Stationary												
Wait for ECU												
From Starting												
Overfrequency / Overspeed Overshoot												
Engine Protection												
From Safety On												
Loading Alarms												

5.1 NEVER

The protection is never active on the controller. This is used to disable the protection.

5.2 ALWAYS

The protection is always active on the controller. This is used to constantly monitor statuses such as a fuel level switch irrespective of the engine running state.

5.3 WHEN STATIONARY

The protection is active from the moment the engine stops until the beginning of engine cranking.

5.4 WAIT FOR ECU

The protection is active if the ECU Start Up delay has been configured, and the timer is currently active.

5.5 FROM STARTING

The protection is active from the beginning of engine cranking, until the engine stops.

5.6 ENGINE PROTECTION

The protection is active when the engine is running, and all engine protection (for example oil pressure and coolant temperature) are in a 'healthy' state.

Oil Pressure Warning

Oil Pressure Shutdown

Oil Pressure Open Circuit (CANbus engine)

High Coolant Temperature Warning

High Coolant Temperature Shutdown

High Coolant Temperature Electrical Trip

High Coolant Temperature Open circuit (CANbus engine)

CAN ECU Warning

CAN ECU Shutdown

Generator Phase Rotation Shutdown

5.7 FROM SAFETY ON

The protection is active when the set is running at nominal speed, until the engine stops.

5.8 OVERSHOOT

Active during the *Safety Delay* timer, this allows for a temporary raise of the overspeed/overfrequency trip points during start-up.

Protection Level	Over Frequency Trip Level	Over Speed Trip Level
Immediate Shutdown	Over Frequency + Overshoot %	Over Speed + Overshoot %
Delayed Shutdown (Overspeed Overshoot Delay)	Over Frequency	Over Speed

Example

57 Hz *Over Frequency* setting, 10% *Overspeed Overshoot*

During *Safety Delay* a generator frequency above $(57 \text{ Hz} \times 1.1) = 62.7 \text{ Hz}$ results in an immediate shutdown without delay.

After *Safety delay*, a generator frequency above 57 Hz for the period of the *Generator Transient Delay* results in a shutdown

5.9 LOADING ALARMS

This alarm is active after the generator runs, and the voltage and frequency are above their Loading levels, until the generator stops.

This Page Intentionally Blank

This Page Intentionally Blank