



1. 3/4/5/6/7/8号线采用1.5mm²,
其他采用1mm²
2. 9/10和11/12号分别采用双绞线

1	充电指示	charge indicator
2	逆磁	field excitation
3	正极	Battery +
4	正极	Battery +
5	正极	Battery +
6	负极	Battery -
7	负极	Battery -
8	负极	Battery -
9	CAN H	
10	CAN L	
13	ECU上电	ECU Power
15	启动信号	Star
16	GND	
17	GND	
18		
19	18/19短接转速1800转	18/19 Speed switch